



[Manuals.plus](#) /

› [Samsung](#) /

› Samsung Galaxy Z Flip7 5G Smartphone User Manual

Samsung SM-F766B

Samsung Galaxy Z Flip7 5G Smartphone User Manual

Model: SM-F766B | Brand: Samsung

1. INTRODUCTION AND OVERVIEW

This manual provides comprehensive instructions for the safe and efficient use of your Samsung Galaxy Z Flip7 5G Smartphone. The Galaxy Z Flip7 is a cutting-edge foldable device designed for seamless integration into your daily life, featuring advanced AI capabilities and a compact form factor.



Figure 1.1: Samsung Galaxy Z Flip7 5G in Blue Shadow, showcasing its unique foldable design.

Key Features:

- **Pocket-Perfect AI:** Experience next-gen Galaxy AI for enhanced functionality and personalized interactions.
- **Ultra Sleek Design:** The thinnest Galaxy Z Flip yet, with a re-designed cover screen (FlexWindow) and One UI 8 for personalized user interface.
- **Thinnest Yet Strong:** Constructed with a durable Armor Aluminium frame and an innovative Armor FlexHinge, ensuring both strength and a slim profile. Knox Vault provides on-device privacy protection.
- **50MP High-Resolution Camera:** Capture detailed selfies and photos with the ProVisual Engine, utilizing the larger FlexWindow for previews.
- **4300mAh Larger Battery:** Optimized for extended use, providing hours of entertainment and productivity.

Powerful Performance

Camera

Flex your best angles

50 MP



Display



2600 nits

Battery

Battery capacity

4300 mAh

Watch videos up to

31 hrs



Figure 1.2: Overview of the Galaxy Z Flip7's powerful performance, including camera, display, and battery specifications.

2. SETUP

2.1 What's in the Box

Upon unboxing your Samsung Galaxy Z Flip7 5G, verify that all components are present:

What's in the box




Figure 2.1: Contents of the retail package.

- Samsung Galaxy Z Flip7 Smartphone
- Data Cable (USB-C to USB-C)
- SIM Ejection Pin
- Quick Start Guide

2.2 Inserting the SIM Card

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejection pin into the small hole next to the tray to open it.
3. Place your Nano-SIM card into the tray with the gold contacts facing down.
4. Gently push the tray back into the slot until it clicks into place.

2.3 Initial Charging and Power On

- Connect the USB-C cable to the charging port at the bottom of the phone and the other end to a compatible

power adapter (sold separately).

- Allow the device to charge for a few minutes before powering it on.
- To power on, press and hold the Side key until the Samsung logo appears.

2.4 Initial Setup Wizard

Follow the on-screen prompts to complete the initial setup:

- Select your preferred language.
- Connect to a Wi-Fi network.
- Review and accept the End User License Agreement and Privacy Policy.
- Sign in with your Google account or create a new one.
- Set up security features such as fingerprint, face recognition, PIN, or pattern.
- Transfer data from an old device (optional).

3. OPERATING YOUR DEVICE

3.1 Understanding the FlexWindow (Cover Screen)

The FlexWindow allows you to access key information and perform quick actions without unfolding the phone.

Pocket-Perfect AI



Figure 3.1: The FlexWindow in action, providing quick access to information.

- **Widgets:** Customize widgets to display weather, calendar, music controls, and more.
- **Notifications:** View and manage notifications directly from the cover screen.
- **Quick Settings:** Access essential settings like Wi-Fi, Bluetooth, and brightness.
- **Quick Reply:** Respond to messages without opening the phone.

3.2 Using the Main Screen and Flex Mode

Unfold your Galaxy Z Flip7 to access the full main screen. The unique Flex Mode allows the phone to stand upright when partially folded, optimizing certain apps for hands-free use.

- **Flex Mode for Camera:** When partially folded, the camera app automatically adjusts, allowing you to take stable photos and videos without a tripod.
- **Flex Mode for Video Calls:** Enjoy hands-free video calls with the top half of the screen displaying the video and the bottom half showing controls.
- **Multi-Active Window:** Utilize the large screen to run multiple apps simultaneously.

3.3 Camera Features

The Galaxy Z Flip7 features a powerful 50MP main camera and a ProVisual Engine for exceptional photo and video quality.

Now Brief with Galaxy AI ✨

Personalized briefings for your day




Figure 3.2: Personalized briefings available on the FlexWindow.

- **High-Resolution Photography:** Leverage the 50MP sensor for incredibly detailed images.
- **Enhanced Selfies:** Use the main camera for high-quality selfies, previewing them on the FlexWindow.
- **Low Light Performance:** The advanced sensor and ProVisual Engine improve clarity and detail in challenging low-light conditions.
- **AI Zoom:** Utilize AI-powered zoom for clearer distant shots.

3.4 Galaxy AI Features

Your Galaxy Z Flip7 integrates advanced AI features to enhance productivity and personalization.

- **Now Brief:** Receive personalized daily rundowns directly on your FlexWindow, including weather, workout results, and more.

- **Google Gemini Integration:** Access powerful features like video generation and secure cloud storage with a trial of the Gemini app.

3.5 Battery Management

The 4300mAh battery is optimized for extended usage. To maximize battery life:

- Adjust screen brightness.
- Enable Power saving mode when needed.
- Close unused background apps.
- Utilize Dark mode for the display.

4. MAINTENANCE

4.1 Cleaning Your Device

To maintain the appearance and functionality of your Galaxy Z Flip7:

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive materials, or compressed air.
- For stubborn smudges, slightly dampen the cloth with distilled water.

4.2 Software Updates

Regular software updates provide new features, security enhancements, and bug fixes. Ensure your device is connected to Wi-Fi and has sufficient battery before updating.

- Navigate to **Settings > Software update > Download and install**

4.3 Protecting the Foldable Screen

The foldable display is a sophisticated component. Follow these guidelines to ensure its longevity:

- Do not press on the screen with a hard or sharp object.
- Avoid exposing the device to dust or liquids.
- Do not attach adhesives such as screen protectors or stickers to the main screen.
- Fold the device completely when not in use to protect the inner screen.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your Galaxy Z Flip7.

5.1 Common Issues and Solutions

Problem	Possible Solution
Device does not turn on	Ensure the battery is charged. Press and hold the Side key and Volume Down key simultaneously for more than 7 seconds to restart.
Screen is unresponsive	Restart the device. If the issue persists, ensure the screen is clean and free of debris.

Problem	Possible Solution
Battery drains quickly	Check for background apps consuming power. Reduce screen brightness. Enable Power saving mode.
Cannot connect to Wi-Fi/Bluetooth	Toggle Wi-Fi/Bluetooth off and on. Restart the device and the router/Bluetooth accessory.

5.2 Factory Reset (Caution)

A factory reset will erase all data from your device and restore it to its original factory settings. Back up all important data before proceeding.

- Navigate to **Settings > General management > Reset > Factory data reset**

5.3 Contacting Support

If you encounter issues that cannot be resolved using the troubleshooting steps, please contact Samsung customer support or visit an authorized service center. Refer to the warranty information for service details.

6. SPECIFICATIONS

Detailed technical specifications for the Samsung Galaxy Z Flip7 5G (SM-F766B).

Feature	Specification
Operating System	Android 16.0
Product Dimensions	0.65 x 7.52 x 16.67 cm (unfolded)
Item Weight	188 g
RAM Memory Installed Size	12 GB
Memory Storage Capacity	256 GB
CPU Speed	3.3 GHz
Connectivity Technologies	Bluetooth, NFC, USB, Wi-Fi
Special Features	Always On Display, Built-In GPS, Fast Charging Support, Mobile Hotspot Capability, Stereo Speakers
Resolution	2520 x 1080
Colour	Blue Shadow
Battery Power Rating	4300 Milliamp Hours
Manufacturer	Samsung
Country of Origin	India

7. WARRANTY AND SUPPORT

7.1 Product Warranty

Your Samsung Galaxy Z Flip7 5G comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Samsung India website for detailed terms and conditions regarding warranty coverage, duration, and service procedures.

7.2 Customer Support

For technical assistance, service requests, or further inquiries, please contact Samsung customer support through the following channels:

- **Online Support:** Visit the official Samsung India support website for FAQs, troubleshooting guides, and live chat options.
- **Phone Support:** Contact Samsung customer service via the helpline number provided in your Quick Start Guide or on the official website.
- **Service Centers:** Locate authorized Samsung service centers near you for in-person assistance.

Note: No official product videos with 'Seller' creator type were found in the provided data to embed.