

Wyklaus 02001

Wyklaus Head Shaver Model 02001 Instruction Manual

Waterproof Wet & Dry Shaving for Head and Beard Use

[Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Safety Information](#) [Product Overview](#) [Package](#) [Charging](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions before using the Wyklaus Head Shaver. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **WARNING:** Do not use the shaver near water or while charging to prevent electrical hazards.
- Keep the charging cord in good condition and do not overcharge the shaver.
- Be cautious when using the shaver as it has sharp blades that can cause cuts.
- Always unplug the shaver before cleaning or storing it.

2. PRODUCT OVERVIEW

The Wyklaus Head Shaver Model 02001 is designed for efficient wet and dry shaving of the head and beard. It features a multi-head design for comprehensive coverage and includes various attachments for versatile grooming.



Image 2.1: Key features of the Wyklus Head Shaver, including its 7D floating head for contouring, IPX6 waterproof rating for wet or dry use, travel lock function, and LED display for battery and cleaning reminders. It also highlights the double-ring blade design for catching both long and short hairs.

Key Features:

- **7D Floating Head:** Flexible blades designed to contour to the shape of your head and face for a smooth shave.
- **IPX6 Waterproof:** Allows for both wet and dry shaving, and easy cleaning under running water.
- **Travel Lock:** Prevents accidental activation during travel.
- **LED Display:** Provides real-time information on battery power, low battery reminders, and cleaning reminders.
- **Double-Ring Blades:** Efficiently catches both long and short hairs for a close shave.

3. PACKAGE CONTENTS

The Wyklus Head Shaver package typically includes the following components:




Image 3.1: Various attachments included with the Wyklus Head Shaver, such as the cleansing brush, nose hair trimmer, main head shaver, hair trimmer, and massage head.

- Main Head Shaver Unit
- 7D Floating Head Attachment
- Cleansing Brush Attachment
- Nose Hair Trimmer Attachment
- Hair Trimmer Attachment
- Massage Head Attachment
- USB Charging Cable
- Cleaning Brush
- User Manual

4. SETUP

4.1 Initial Charging

Before first use, fully charge the shaver. Connect the USB charging cable to the shaver and a compatible USB power source (e.g., USB charger, power bank, car charger, laptop charger). The LED display will

indicate charging status. A full charge typically takes approximately 120 minutes.



Image 4.1: The shaver is rechargeable via Type-C USB, compatible with various power sources such as USB chargers, power banks, car chargers, and laptops. It offers 60 minutes of running time after 120 minutes of charging.

4.2 Attaching/Detaching Heads

To attach a head, align the desired attachment with the shaver body and gently push until it clicks into place. To detach, firmly pull the attachment away from the shaver body.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button once to turn the shaver on. Press it again to turn it off.

5.2 Using the Travel Lock

To activate the travel lock, press and hold the power button for 3 seconds. The LED display will show a lock icon. To deactivate, press and hold the power button for 3 seconds again.

5.3 Shaving Technique (Head & Beard)

- **Dry Shaving:** Ensure your skin is clean and dry. Move the shaver in small, circular motions over the area to be shaved.
- **Wet Shaving:** Apply shaving foam or gel to your skin. Move the shaver in small, circular motions. The waterproof design allows for use in the shower.
- For best results, stretch the skin slightly with your free hand.
- Avoid pressing too hard, as this can cause irritation and reduce shaving efficiency.
- Rinse the shaver head under running water during shaving to clear accumulated hair and maintain performance.

5 In 1 Head Shavers For Bald Man

Get a Refreshing Look



Image 5.1: Demonstrates the versatility of the 5-in-1 head shaver for different grooming applications, including shaving the head, trimming beards, and using the cleansing brush.

5.4 Using Other Attachments

- **Nose Hair Trimmer:** Gently insert the trimmer into the nostril or ear canal and move it in a circular motion to trim unwanted hair.
- **Hair Trimmer:** Use for detailing sideburns, necklines, or trimming longer hair before shaving.
- **Cleansing Brush:** Apply facial cleanser to your face or the brush head. Gently move the brush in circular motions to cleanse your skin.
- **Massage Head:** Use on your face or scalp for a relaxing massage.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your shaver.

6.1 Daily Cleaning

1. Turn off the shaver and unplug it from any charging source.
2. Detach the shaver head.
3. Rinse the shaver head and the main body (if necessary) under warm running water.
4. Shake off excess water and allow the components to air dry completely before reattaching or storing.

6.2 Deep Cleaning (Weekly/Bi-weekly)

1. Turn off and unplug the shaver.
2. Detach the shaver head and carefully open the individual blade covers.
3. Use the small cleaning brush provided to remove any trapped hair from the blades and inside the shaver head.
4. Rinse all components under warm running water.
5. Allow all parts to dry thoroughly before reassembling.

6.3 Blade Replacement

For optimal shaving performance, it is recommended to replace the shaver heads every 6-12 months, depending on usage. Replacement heads can be purchased from authorized retailers or the manufacturer's website.



Image 6.1: A detailed view of the 7D floating shaver head, showing the individual rotary blades that require periodic cleaning and replacement.

7. CHARGING

The Wyklus Head Shaver is equipped with a rechargeable battery. The LED display indicates the current battery level.

- **Charging Time:** Approximately 120 minutes for a full charge.
- **Running Time:** Up to 60 minutes of continuous use on a full charge.
- **Charging Indicator:** The LED display will show charging progress.
- **Power Source:** Use the provided Type-C USB cable with a standard USB power adapter (not included), power bank, car charger, or laptop.
- Do not charge the shaver in wet conditions or near water.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted. Travel lock is activated.	Charge the shaver. Deactivate travel lock by pressing and holding the power button for 3 seconds.
Poor shaving performance.	Blades are dull or clogged with hair.	Clean the shaver head thoroughly. Consider replacing the shaver head if blades are dull.
Shaver stops during use.	Battery is low.	Recharge the shaver.
Skin irritation after shaving.	Pressing too hard. Dry shaving on sensitive skin. Blades are dull.	Use lighter pressure. Try wet shaving with foam/gel. Replace shaver heads if dull.

9. SPECIFICATIONS

Model Name:	02001
Brand:	Wyklus

Power Source:	Battery Powered
Special Features:	Adjustable Handle, Anti-Scratch, Cordless, Fast Charging, Floating Head
Recommended Uses:	Back Hair, Chest, Face, Leg, Lip (<i>Note: Use appropriate attachments for specific areas.</i>)
Product Dimensions:	24 x 25 x 28 inches; 15.2 ounces
Batteries:	1 Nonstandard Battery (included)

10. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please contact Wyklaus customer service. Refer to the product packaging or the official Wyklaus website for contact details.