

LDAILY LD-10116US-BK-MU

LDAILY 61 Key Keyboard Piano Instruction Manual

Model: LD-10116US-BK-MU

1. INTRODUCTION

This manual provides essential information for the safe and effective operation of your LDAILY 61 Key Keyboard Piano. Please read this manual thoroughly before use and retain it for future reference. This electronic digital piano is designed for beginners and features 61 keys, built-in speakers, and various functions to support musical learning and practice.

2. SAFETY INFORMATION

- **Power Source:** Use only the provided AC adapter or 4 AA batteries. Ensure the voltage matches the product requirements.
- **Battery Safety:** Do not mix old and new batteries, or different types of batteries. Remove batteries if the unit will not be used for an extended period.
- **Water and Moisture:** Keep the keyboard away from water, moisture, and high humidity. Do not operate with wet hands.
- **Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the unit.
- **Cleaning:** Clean only with a dry, soft cloth. Do not use liquid cleaners or aerosols.
- **Children:** This product contains small parts and electronic components. Adult supervision is recommended for young children.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x LDAILY 61 Key Keyboard Piano
- 1 x Music Stand
- 1 x Keynote Stickers
- 1 x Microphone
- 1 x Power Adapter

- 1 x Carrying Case
- 1 x User Guide (this manual)



Image 3.1: The LDAILY 61 Key Keyboard Piano with its complete set of accessories, including the music stand, microphone, power adapter, and carrying case.

4. PRODUCT OVERVIEW

4.1 Keyboard Layout and Controls

Familiarize yourself with the main controls and features of your keyboard piano.




Image 4.1: Top-down view of the keyboard showing the control panel with buttons for Tones, Rhythms, Demo Songs, Percussion, Metronome, Record, Playback, Sustain, and Programming. The digital display is centrally located.

- **Power Button:** Turns the keyboard on or off.
- **Volume Control:** Adjusts the overall sound output level.
- **Tone Selection:** Buttons to select from 100 different instrument sounds.
- **Rhythm Selection:** Buttons to select from 100 rhythmic patterns.
- **Demo Songs:** Buttons to play 10 pre-recorded demonstration songs.
- **Percussion:** Buttons for 5 different percussion sounds.
- **Metronome:** Provides a steady beat for practice.
- **Record/Playback:** Records and plays back your performances.
- **Sustain:** Adds a sustain effect to notes.
- **Programming:** Allows for custom rhythm programming.
- **Digital Display:** Shows current settings (e.g., tone number, rhythm number).

4.2 Connectivity Ports

MULTIPLE CONNECTIONS



Image 4.2: Close-up view of the connectivity panel, showing the Power input (DC 5V), Audio Output (for headphones), Audio In, and Microphone input ports.

- **DC 5V Power Input:** Connect the included AC adapter here.
- **Audio Output (Earphone):** Connect headphones for private practice.
- **Microphone Input:** Connect the included microphone.

4.3 Built-in Speakers



Image 4.3: Diagram illustrating the location of the dual built-in speakers on the keyboard, designed for enhanced sound output.

The keyboard features dual high-fidelity speakers for clear sound reproduction.

5. SETUP

5.1 Power Connection

1. **AC Adapter:** Connect the small end of the power adapter to the DC 5V input port on the keyboard. Plug the other end into a standard wall outlet.
2. **Batteries (Optional):** If using batteries, open the battery compartment on the underside of the keyboard. Insert 4 AA batteries (not included), ensuring correct polarity (+/-). Close the compartment securely.

5.2 Music Stand Assembly

Insert the music stand into the designated slots on the top panel of the keyboard. Ensure it is firmly seated.

5.3 Keynote Stickers Application

For beginners, apply the included keynote stickers to the keys as guided by the sticker sheet. This aids in learning note identification.

3. Use the **+** or **-** buttons to cycle through the available rhythms.
4. Press **START/STOP** to begin or end the rhythm playback.
5. Adjust the rhythm tempo using the **TEMPO +** or **TEMPO -** buttons.

6.4 Playing Demo Songs

1. Press the **DEMO SONG** button. The display will show the current demo song number.
2. Use the number buttons (0-9) or **+/ -** buttons to select a demo song.
3. The selected demo song will begin playing automatically. Press **DEMO SONG** again to stop playback.

6.5 Recording and Playback

1. Press the **RECORD** button. The keyboard is now in recording mode.
2. Play your desired melody on the keys.
3. Press the **PLAYBACK** button to stop recording and listen to your recorded performance.

6.6 Metronome Function

1. Press the **METRONOME** button to activate the metronome.
2. Use the **TEMPO +** or **TEMPO -** buttons to adjust the metronome speed.
3. Press the **METRONOME** button again to turn it off.

6.7 Sustain Function

Press the **SUSTAIN** button to apply a sustain effect to the notes played. Press it again to deactivate.

6.8 Microphone and Headphone Use

- **Microphone:** Plug the included microphone into the **MIC** input port. Adjust the keyboard's volume for microphone output.
- **Headphones:** Plug standard 3.5mm headphones into the **AUDIO OUT (EARPHONE)** port for private listening. The built-in speakers will mute automatically.



Image 6.1: A user playing the LDAILY keyboard piano while wearing headphones, demonstrating the private practice capability.

7. MAINTENANCE

- **Cleaning:** Wipe the keyboard surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or waxes.
- **Storage:** When not in use, store the keyboard in its carrying case in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Removal:** If storing for an extended period, remove the batteries to prevent leakage.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard does not power on.	No power, low batteries, or faulty adapter.	Ensure AC adapter is properly connected or replace batteries.

Problem	Possible Cause	Solution
No sound from speakers.	Volume too low, headphones connected, or speaker issue.	Increase volume, disconnect headphones, or check power.
Microphone not working.	Microphone not plugged in correctly or volume too low.	Ensure microphone is fully inserted into the MIC port and adjust keyboard volume.
Keys are unresponsive.	Keyboard may be in a specific mode (e.g., programming) or a temporary glitch.	Try turning the keyboard off and on again. Check if any special function is active.

9. SPECIFICATIONS

Feature	Detail
Model Number	LD-10116US-BK-MU
Number of Keys	61
Dimensions (L x W x H)	23" x 7" x 2" (58.4 cm x 17.8 cm x 5.1 cm)
Item Weight	2.2 lbs (1 kg)
Tones	100
Rhythms	100
Demo Songs	10
Percussion Sounds	5
Power Input	100V-240V~50/60Hz
Power Output	5V 1A
Battery Type	4 x AA batteries (not included)
Headphones Jack	3.5mm
Special Features	Built-In Speaker, Digital Display, Portable, Record/Playback, Metronome, Sustain

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official LDAILY website. Keep your proof of purchase for warranty claims.

<div><div>SAMSUNG</div><div>Samsung Portable SSD T7</div><div>Manuale (pdf) Utent</div><div><div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div></div>	<p>Samsung Portable SSD T7: Manwal tal-Utent u Gwida Komprensiva</p> <p>Gwida komprensiva għas-Samsung Portable SSD T7. Dan il-manwal tal-utent jipprovdi struzzjonijiet dettaljati dwar installazzjoni, karatteristiċi ta' sigurtà, u speċifikazzjonijiet tekniċi għall-SSD estern tiegħek.</p>
<div><div>McGREY</div><div>McGrey BK-5410 Beginner Keyboard</div><div><div><div></div><div></div><div></div></div></div></div> <div><div>Bedenungsanleitung / User manual</div></div>	<p>McGrey BK-5410 Beginner Keyboard User Manual</p> <p>This user manual provides comprehensive instructions for operating the McGrey BK-5410 Beginner Keyboard, covering setup, controls, functions, and maintenance.</p>
<div><div>SAMSUNG</div><div>Samsung Portable SSD T7</div><div>User Manual</div><div><div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div></div>	<p>Samsung Portable SSD T7 User Manual</p> <p>User manual for the Samsung Portable SSD T7, covering features, setup, usage, security, and troubleshooting.</p>
<div><div>SAMSUNG</div><div>Samsung Portable SSD T7</div><div>Manuale (pdf) Utent</div><div><div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div></div>	<p>Samsung Portable SSD T7 User Manual - Fast, Secure External Storage</p> <p>Comprehensive user manual for the Samsung Portable SSD T7, covering setup, usage, security features, software installation, troubleshooting, and specifications. Learn how to connect, transfer data, and protect your files with this high-speed external SSD.</p>
<div><div>Installation Instructions</div><div><div><div></div><div></div><div></div></div></div></div>	<p>Lucci Decor Manor Pendant Light Installation Instructions</p> <p>Detailed installation instructions, safety tips, and specifications for the Lucci Decor Manor cord pendant light. Includes guidance on wiring, mounting, and shade compatibility.</p>
<div><div>SAMSUNG</div><div>Przenośny dysk Samsung Portable SSD T7</div><div>Podręcznik użytkownika</div><div><div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div></div>	<p>Przewodnik użytkownika dysku Samsung Portable SSD T7</p> <p>Kompleksowy podręcznik użytkownika dla dysku Samsung Portable SSD T7, zawierający informacje o instalacji, obsłudze, funkcjach bezpieczeństwa i rozwiązywaniu problemów.</p>