

artfone ARF-G3+001

artfone G3 Flip Cell Phone User Manual

Model: ARF-G3+001

1. INTRODUCTION

This manual provides comprehensive instructions for the artfone G3 Flip Cell Phone. Designed for ease of use, this device features large buttons, a clear display, and essential communication functions. Please read this manual thoroughly to understand the phone's operation and ensure proper use.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- artfone G3 Flip Cell Phone
- Rechargeable Battery (1300mAh)
- USB Cable
- Charging Cradle
- User Manual



Image: The complete package contents of the artfone G3 Flip Cell Phone, showing the phone, charging accessories, and documentation.

3. PHONE OVERVIEW

The artfone G3 features a clamshell design with a 2.4-inch color display and a large, easy-to-use keypad.

3.1 Front and Keypad



Image: The artfone G3 flip phone in red, opened to display its large, well-spaced keypad and internal screen.

The keypad includes 21 large, distinct buttons for dialing and navigation. Green and red buttons are dedicated for answering and ending calls, respectively. The 2.4-inch display provides clear icons and supports large font sizes for improved visibility.



Image: A detailed view of the phone's screen and keypad, highlighting the SOS function, large buttons, and large font option for enhanced readability.

3.2 Side Buttons and SOS Function

Two side buttons and SOS, tailored design for old people



Image: The side profile of the artfone G3, illustrating the location of the SOS emergency button and additional side controls.

The phone features dedicated side buttons for volume control and a prominent SOS button on the back for emergency situations.

4. SETUP

4.1 Battery Installation

1. Remove the back cover of the phone.
2. Insert the 1300mAh battery into the battery compartment, ensuring the gold contacts align.
3. Replace the back cover until it clicks securely into place.

4.2 SIM Card Installation

The artfone G3 supports 4G, 3G, and 2G networks. It is compatible with T-Mobile, MetroPCS, SpeedTalk, Tello, and RedPocket GSM SIM cards. This phone is not compatible with AT&T, Cricket, or any CDMA networks such as Verizon, Sprint, and Boost Mobile.

1. Ensure the phone is powered off and the battery is removed.
2. Locate the SIM card slot(s) beneath the battery compartment.

3. Carefully insert your compatible SIM card(s) into the slot(s) as indicated by the diagram.
4. Reinstall the battery and back cover.

4.3 Initial Charging

Before first use, fully charge the phone's battery.

1. Connect the USB cable to the charging cradle and a power adapter (not included).
2. Place the artfone G3 into the charging cradle, ensuring it is seated correctly. The phone will indicate charging status on its screen.
3. Allow the phone to charge until the battery indicator shows a full charge.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Press and hold the red 'End Call' button until the screen lights up.
- **To Power Off:** Press and hold the red 'End Call' button until the power-off option appears, then confirm.

5.2 Making Calls

1. Open the flip phone.
2. Dial the desired phone number using the keypad.
3. Press the green 'Call' button to initiate the call.

5.3 Receiving Calls

- When the phone rings, open the flip to answer, or press the green 'Call' button.
- To end a call, press the red 'End Call' button or close the flip.

5.4 Speed Dial

The phone supports speed dial for quick access to favorite contacts.

- **Dedicated A/B Keys:** Assign frequently called numbers to the 'A' and 'B' buttons. Refer to the phone's menu for setup instructions.
- **Number Keys 1-9:** Assign contacts to number keys 1 through 9. Long-press the assigned number key to dial the contact.

5.5 SOS Emergency Button

The SOS function allows programming up to five emergency contacts. In a crisis, a single press of the SOS button triggers the phone to call each contact sequentially until someone answers.

1. **Setup:** Navigate to the SOS settings in the phone's menu to add up to five emergency contact numbers.
2. **Activation:** In an emergency, press and hold the SOS button on the back of the phone. The phone will automatically dial the programmed contacts.

5.6 Photo Contacts

The phone supports assigning photos to contacts, making it easier to identify callers or dial frequently used numbers visually.

Housing with high level painting and good keypad with PU



Image: The artfone G3 in hand, illustrating the large keypad and the photo contact feature on the display.

5.7 Talking Numbers

For users with visual impairments, the phone offers a real-time voice broadcast function that reads out the time and dialed numbers.

- **Time Broadcast:** Long-press the volume button to hear the current time announced.
- **Dialed Number Announcement:** This feature can be enabled in the phone's settings to audibly announce each number as it is pressed on the keypad.

5.8 Volume Adjustment

Use the dedicated volume buttons on the side of the phone to adjust the call volume during a conversation or the ringtone volume when idle.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's exterior. Avoid liquid cleaners.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. Charge the phone regularly, but do not leave it fully discharged for extended periods.

- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.
- **Reliability:** The phone is designed for durability, tested to withstand frequent opening and closing.

Reliability Test

Standard:120K times.



Image: The artfone G3 flip phone demonstrating its durability through a reliability test of its hinge mechanism.

7. TROUBLESHOOTING

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly installed and fully charged. Connect to the charging cradle to check if the charging indicator appears.
No network signal	Verify that a compatible SIM card is correctly inserted. Check your location for network coverage. Restart the phone.
Cannot make/receive calls	Check network signal strength. Ensure your SIM card is active and has sufficient credit/plan. Verify the number dialed is correct.
Charging issues	Ensure the charging cradle and USB cable are properly connected. Check for debris in the charging port. Ensure the phone is correctly seated in the cradle.







Problem	Possible Solution
Keypad unresponsive	Restart the phone. Ensure no physical obstruction is preventing button presses.

8. SPECIFICATIONS

Feature	Detail
Model Name	ARF-G3+001
Brand	artfone
Operating System	Nucleus OS
Connectivity Technologies	4G LTE, 3G, 2G
Screen Size	2.4 Inches
Resolution	320 x 240
Battery Capacity	1300 Milliamp Hours
Phone Talk Time	Up to 6 Hours
Memory Storage Capacity	1 GB
RAM Memory Installed Size	48 MB
Special Features	Time reporting function, 4G unlocked, SOS button, Speed Dial, Photo Contact, Talking Numbers
Item Weight	10.4 ounces
Color	Red

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact artfone customer service. Specific warranty terms and support channels may vary by region and retailer.

<p>ARTPHONE C1</p> 	<p>Artfone C1 Senior Mobile Phone User Manual - Features, SOS, and FAQ</p> <p>Explore the Artfone C1 senior mobile phone with this comprehensive user manual. Learn about its SOS function, speed dial, volume controls, and answers to frequently asked questions. Designed for simplicity and ease of use.</p>
<p>artfone® F20</p>  <p>English P1-7 Deutsch P8-15 Français P16-23 Italiano P24-30 Español P31-38 Dutch P39-46</p>	<p>Artfone F20 User Manual - Guide and Instructions</p> <p>Comprehensive user manual for the Artfone F20 mobile phone, covering setup, features, SOS function, and troubleshooting. Available in multiple languages.</p>
<p>ARTPHONE C1</p> 	<p>Artfone C1 User Manual: Simple Mobile Phone Guide with SOS</p> <p>This user manual provides comprehensive instructions for the Artfone C1 mobile phone, covering device layout, button functions, icon meanings, and step-by-step guides for operations like making calls, using the SOS feature, and adjusting settings. Includes a FAQ section.</p>
<p>Artfone G3 Flip</p> 	<p>Artfone G3 Flip Phone User Manual</p> <p>Comprehensive user manual for the Artfone G3 Flip phone, detailing features, operation, and FAQs. Learn how to make calls, use the flashlight, SOS function, and manage settings.</p>
<p>ARTPHONE CF241A</p> 	<p>Artfone CF241A Senior Flip Phone User Manual</p> <p>User manual for the Artfone CF241A, a senior-friendly flip phone designed for ease of use. Features include large buttons, SOS function, FM radio, and clear display. This guide covers setup, operation, and FAQs.</p>
	<p>Artfone CF241A Flip Phone User Guide</p> <p>User guide for the Artfone CF241A flip phone, covering features like the keypad, SOS function, making calls, and common questions.</p>

