

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOOBRO](#) /

› [HOOBRO BF16XY01 6-Section Laundry Sorter Instruction Manual](#)

HOOBRO BF16XY01

HOOBRO BF16XY01 6-Section Laundry Sorter Instruction Manual

Model: BF16XY01 | Brand: HOOBRO

INTRODUCTION

Thank you for choosing the HOOBRO BF16XY01 6-Section Laundry Sorter. This manual provides essential information for the safe assembly, operation, and maintenance of your new laundry sorter. Please read these instructions carefully before assembly and retain them for future reference.

SAFETY INFORMATION

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the laundry bags or the top shelf. Refer to specifications for weight limits.
- Use the product on a level surface to prevent tipping.
- Lock the casters when the unit is stationary to prevent unintended movement.
- This product is intended for indoor use only.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Metal Frame Components
- Wooden Top Shelf
- 6 Removable Oxford Fabric Laundry Bags (3 small, 3 large)
- 4 Lockable Casters
- Assembly Hardware (screws, Allen wrench)
- Instruction Manual

ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your HOOBRO BF16XY01 Laundry Sorter.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list to ensure everything is present.
2. **Assemble the Metal Frame:** Connect the vertical and horizontal metal frame components using the provided screws and Allen wrench. Ensure all connections are firm but do not overtighten initially.
3. **Attach the Top Shelf:** Place the wooden top shelf onto the designated area of the metal frame. Secure it with the appropriate screws. Ensure the guarded edges are facing upwards to prevent items from falling off.
4. **Install Casters:** Screw the four lockable casters into the pre-drilled holes at the bottom of the metal frame. Tighten them securely.
5. **Insert Laundry Bags:** Place the three smaller Oxford fabric bags into the upper compartments and the three larger bags into the lower compartments. The bags feature a pull-out design for easy access. Secure the bags to the frame using the integrated hook-and-loop fasteners at the top edges of the bags.



Image: Fully assembled HOOBRO BF16XY01 Laundry Sorter, showcasing its 6 sections and top storage shelf.



Image: Detail of the 360-degree rotating lockable casters, allowing for easy movement and secure positioning.



Image: Close-up showing the detachable Oxford fabric bags, secured by hook-and-loop fasteners for easy removal and cleaning.

OPERATING INSTRUCTIONS

- **Sorting Laundry:** Utilize the six individual bags to sort laundry by color, fabric type, or washing requirements. The three smaller bags (5.5 Gal / 20.8 L each) are ideal for delicates or smaller loads, while the three larger bags (10.6 Gal / 40.3 L each) accommodate bulkier items.
- **Using the Top Shelf:** The sturdy wooden top shelf provides additional storage space for laundry detergents, fabric softeners, folded clothes, or decorative items. The guarded edges help prevent items from falling off.
- **Moving the Sorter:** Unlock the casters to easily roll the laundry sorter to your washing machine or any desired location. Once positioned, lock the casters to keep the unit stable.
- **Removing Laundry Bags:** The bags feature a convenient pull-out design. Simply slide a bag forward to access its contents. For washing, detach the bag from the frame by releasing the hook-and-loop fasteners.



Image: A hand demonstrating the pull-out design of the laundry bags for easy access to contents.

CARE AND MAINTENANCE

- **Cleaning the Frame:** Wipe the metal frame and wooden top shelf with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Washing Laundry Bags:** The Oxford fabric bags are removable and can be hand-washed or machine-washed on a gentle cycle with cold water. Air dry only; do not tumble dry. Ensure bags are completely dry before reattaching to the frame.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Unit wobbles or is unstable.	Loose screws; uneven surface.	Ensure all assembly screws are tightened. Move the unit to a level surface. Lock the casters.
Laundry bags sag or fall off.	Bags overloaded; hook-and-loop fasteners not properly secured or worn.	Do not overload bags beyond their capacity. Ensure hook-and-loop fasteners are firmly attached to the frame. Replace bags if fasteners are worn.
Castors do not roll smoothly.	Debris in casters; casters locked.	Check for and remove any debris (lint, hair) from the caster wheels. Ensure casters are in the unlocked position for movement.

SPECIFICATIONS

- **Model:** BF16XY01
- **Overall Dimensions:** 35.4 x 13 x 43.3 inches (90 x 33 x 110 cm)
- **Small Bag Capacity:** 5.5 Gallons (20.8 Liters) each
- **Large Bag Capacity:** 10.6 Gallons (40.3 Liters) each
- **Total Capacity:** Approximately 48.3 Gallons (183 Liters)
- **Materials:** Engineered Wood, Metal, Oxford Fabric
- **Color:** Rustic Brown (shelf), Black (frame and bags)
- **Item Weight:** 25.7 pounds (11.66 kg)



Image: Detailed diagram illustrating the overall dimensions of the laundry sorter.



Image: Diagram showing the individual dimensions of both the small and large removable laundry bags.

CUSTOMER SUPPORT

For any questions, missing parts, or assistance with your HOOBRO BF16XY01 Laundry Sorter, please contact HOOBRO customer service. Refer to your purchase documentation for specific contact details or visit the official HOOBRO website.