Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- advwin /
- > advwin 20-inch Carry-On Luggage with Seat (Model US890201) Instruction Manual

advwin US890201

advwin 20-inch Carry-On Luggage with Seat (Model US890201) Instruction Manual

Lightweight Hardside Ride-On Suitcase with Front Opening, TSA Lock, and 360° Spinner Wheels

1. Introduction

This manual provides comprehensive instructions for the safe and effective use of your advwin 20-inch Carry-On Luggage with Seat, Model US890201. Please read this manual thoroughly before operating the product and retain it for future reference. This luggage is designed for convenient travel, offering both storage and a seating solution for children and adults.



Image 1.1: The advwin 20-inch Carry-On Luggage with Seat, shown open to display its interior organization.

2. KEY FEATURES

- Spacious and Versatile: 43L capacity, compact dimensions (20.8 x 14.1 x 9.8 inches), and lightweight at approximately 10 lbs.
- **Heavy-Duty & Comfortable Seat:** Integrated seat supports up to 200 lbs, suitable for both children and adults. Features a foldable seat back, a bag hook, and a seatbelt for safety.
- Shock Absorption & 360° Spinner Wheels: Four smooth-gliding 360° spinner wheels with an integrated braking system for stability and a comfortable ride.
- Smart Storage & Front-Open Design: 43L interior with breathable mesh pockets, wet-dry compartments, and zippered sections. The front-opening design allows for quick, one-hand access to items.
- Built-in USB Charging Port: Conveniently charge your devices on the go (power bank not included).

- TSA Lock: Integrated TSA-approved lock for enhanced security.
- Durable Construction: All-aluminum 3-stage telescoping handle for easy maneuverability.

3. SETUP

3.1. Setting the TSA Combination Lock

Your luggage comes with a pre-set combination of 0-0-0. To set your personal combination:

- 1. Ensure the lock is set to the initial password (000). Turn the password wheels to 000 to unlock.
- 2. Locate the reset button (usually a small, recessed button) and push it from position A to B.
- 3. Turn the dials to set your desired three-digit combination.
- 4. Push the reset button back to position A to confirm your new combination.

Remember your new combination. If you forget it, you will not be able to open the lock.




Image 3.1: Visual guide for setting the TSA combination lock.

3.2. Deploying the Integrated Seat

To use the integrated seat:

- 1. Ensure the luggage is on a stable, flat surface.
- 2. Engage the wheel brakes to prevent movement (refer to Section 4.1).
- 3. Gently pull up the foldable seat back until it locks into an upright position.
- 4. For children, secure them with the provided seatbelt.




Image 3.2: The foldable seat back, bag hook, and seat belt for secure seating.

4. OPERATING INSTRUCTIONS

4.1. Using the 360° Spinner Wheels and Brakes

The luggage is equipped with four 360° spinner wheels for effortless maneuverability. Each wheel includes a brake mechanism. To engage the brake, press down on the lever located on the wheel. To release, lift the lever. Always engage the brakes when using the integrated seat to ensure stability.



Image 4.1: The 360° silent airwheels with integrated brakes for stability.

4.2. Utilizing the Front-Open Design

The front-opening design allows for quick access to your belongings without fully opening the main compartment. Simply unlock the front panel and lift the lid. This is ideal for retrieving items like documents, electronics, or snacks while on the go.



Image 4.2: The front-opening design offers convenient, one-hand access compared to traditional clamshell luggage.

4.3. Using the USB Charging Port

A built-in USB charging port is provided for charging your electronic devices. Connect your power bank (not included) to the internal USB cable, and then connect your device to the external USB port. This allows for convenient charging without opening the main compartment.




Image 4.3: Effortless charging of devices via the built-in USB port.

4.4. General Use and Safety

- Always ensure the luggage is stable before allowing anyone to sit on it.
- Do not exceed the maximum weight capacity of 200 lbs for the seat.
- When pulling the luggage, ensure the telescoping handle is fully extended and locked into place.
- · Avoid placing excessively heavy items in the front-opening compartment to maintain balance.

Your browser does not support the video tag.

Video 4.4: Official product video demonstrating the features of the advwin carry-on luggage with seat, including its design, functionality, and ease of use.

5. MAINTENANCE

5.1. Cleaning

- Wipe the exterior hardshell with a soft, damp cloth and mild soap. Avoid abrasive cleaners.
- For interior lining, spot clean with a damp cloth and mild detergent. Allow to air dry completely.
- Clean wheels periodically to remove dirt and debris, ensuring smooth operation.

5.2. Storage

Store the luggage in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the seat back is folded down when not in use to save space.

6. TROUBLESHOOTING

6.1. Wheels Not Rolling Smoothly

Check for debris (hair, lint, dirt) caught in the wheel axles. Clean thoroughly. If the issue persists, ensure the brakes are fully disengaged.

6.2. TSA Lock Issues

If the lock does not open with your combination, double-check that each digit is correctly aligned. If you have forgotten your combination, there is no master reset. You may need to contact customer support for assistance.

6.3. Telescoping Handle Sticking

Ensure no foreign objects are obstructing the handle mechanism. Gently extend and retract the handle several times. Avoid forcing the handle.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	15 x 11 x 20 inches
Item Weight	11.7 pounds
Department	Unisex Adult
ASIN	B0FDQ4KPHH
Item Model Number	US890201
Capacity	43 Liters



Image 7.1: Detailed dimensions and capacity of the 20-inch luggage.

8. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official advwin website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

You can visit the advwin store at: advwin Store on Amazon

© 2025 advwin. All rights reserved.

Related Documents - US890201



Upright Freezer User Manual - BD-88-E | Installation, Operation, Safety & Care

Comprehensive user manual for the ADVWIN BD-88-E upright freezer. Covers important safety instructions, installation, operation, features, defrosting, cleaning, food storage, and troubleshooting for optimal use and maintenance.



Musical Boxing Pro: Smart Music Wall Mounted Boxing Training Machine User Manual

Learn how to set up and operate the Musical Boxing Pro, a smart music wall-mounted boxing training machine for home workouts and stress relief. Includes technical data, operation guide, assembly instructions, and safety precautions.



Portable Washing Machine User Manual

This manual provides instructions and specifications for the Advwin portable washing machine, covering its electrical principle, parts, operation, maintenance, and troubleshooting.



Advwin BCD-90 Refrigerator User Manual

User manual for the Advwin BCD-90 refrigerator, detailing safety precautions, installation, features, operation, care, and troubleshooting. Includes model numbers 140900200 and 141100800.



ADVWIN Vibration Exercise Platform User Manual

Comprehensive user manual for the ADVWIN Vibration Exercise Platform, detailing safety information, package contents, unit components, specifications, operation, maintenance, troubleshooting, and exercise guides.



ADVWIN HZB-12E Portable Ice Maker User Manual

Comprehensive user manual for the ADVWIN HZB-12E portable ice maker, detailing setup, operation, maintenance, troubleshooting, and technical specifications. Learn how to make ice cubes and dispense water with this user-friendly appliance.