



Manuals.plus /

› FAMAPY /

› FAMAPY Display Cabinet with Glass Doors Instruction Manual

FAMAPY B0FFMYBXM4

FAMAPY Display Cabinet with Glass Doors Instruction Manual

Model: B0FFMYBXM4

INTRODUCTION

Thank you for choosing the FAMAPY Display Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new display cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

This display cabinet features a farmhouse style with a black-grey wood grain finish, three glass doors, and a drawer, offering ample storage and display space for collectibles, trophies, and books.

SAFETY INFORMATION

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Contact customer support immediately if any parts are missing or damaged.
- Do not overtighten screws, as this may damage the material.
- For safety, it is highly recommended to secure the cabinet to a wall using the provided anti-tip hardware to prevent accidental tipping, especially in homes with children or pets.
- Keep small parts and packaging materials away from children.
- Use appropriate tools as specified in the assembly guide.
- Do not stand or climb on the cabinet.
- Distribute weight evenly on shelves to maintain stability.

PARTS LIST AND HARDWARE

Your FAMAPY Display Cabinet will arrive in two separate boxes. Please ensure both boxes have arrived and all contents are accounted for before beginning assembly. A detailed assembly manual with a complete parts list and numbered

accessories is included in the packaging. Refer to this guide to identify all components.

Note: The two boxes may not arrive at the same time. Please wait patiently for both packages before starting assembly.



Image: All components of the FAMAPY Display Cabinet are shown disassembled, including panels, glass doors, drawer parts, and hardware, ready for assembly.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the FAMAPY Display Cabinet requires careful attention to detail. Follow the step-by-step instructions

provided in the separate assembly manual included with your product. It is recommended to have two people for assembly to ensure safety and ease of construction.

1. **Unpack and Verify:** Carefully unpack all components from both boxes. Compare them against the parts list in your assembly manual to ensure nothing is missing or damaged.
2. **Prepare Workspace:** Clear a spacious area and lay down a blanket or cardboard to protect the cabinet parts and your floor during assembly.
3. **Follow Manual:** Adhere strictly to the numbered steps in the provided assembly manual. Each step will guide you through attaching panels, installing shelves, assembling the drawer, and mounting the glass doors.
4. **Secure Connections:** Ensure all screws, cam locks, and dowels are securely fastened. Do not overtighten.
5. **Install Anti-Tip Hardware:** Once assembled, position the cabinet in its desired location. Attach the anti-tip hardware to the top rear of the cabinet and secure it to a wall stud according to the instructions. This is a critical safety step.

Assembly Overview



Image: A detailed diagram illustrating the overall dimensions (15.7"D x 46.1"W x 79.9"H) and internal measurements of the display cabinet, including shelf heights and drawer dimensions.

Assembly Videos

Your browser does not support the video tag.

Video: An instructional video demonstrating the assembly process of the FAMAPY Display Cabinet. (Duration: 1 minute 20 seconds)

Your browser does not support the video tag.

Video: A video guide showcasing key steps in assembling the display cabinet. (Duration: 50 seconds)

Your browser does not support the video tag.

Video: Detailed assembly instructions for the FAMAPY Display Cabinet. (Duration: 1 minute 17 seconds)

Your browser does not support the video tag.

Video: Comprehensive assembly tutorial for the display cabinet. (Duration: 4 minutes 42 seconds)

Your browser does not support the video tag.

Video: Step-by-step guide for putting together the FAMAPY Display Cabinet. (Duration: 4 minutes 52 seconds)

Your browser does not support the video tag.

Video: Assembly instructions for the FAMAPY Display Cabinet. (Duration: 1 minute 29 seconds)

Your browser does not support the video tag.

Video: Visual guide to assembling the display cabinet. (Duration: 1 minute 59 seconds)

Your browser does not support the video tag.

Video: Quick overview of the display cabinet assembly. (Duration: 19 seconds)

Your browser does not support the video tag.

Video: Assembly demonstration for the FAMAPY Display Cabinet. (Duration: 2 minutes 47 seconds)

Your browser does not support the video tag.

Video: Final steps and tips for assembling the display cabinet. (Duration: 1 minute 8 seconds)

OPERATING INSTRUCTIONS

The FAMAPY Display Cabinet is designed for displaying and storing various items. Its features include glass doors for visibility, adjustable shelves (if applicable), and a functional drawer.

- **Using Glass Doors:** Gently open and close the glass doors using the metal handles. Avoid slamming the doors to prevent damage to the hinges and glass.
- **Utilizing Shelves:** The upper section features shelves behind glass doors, ideal for displaying decorative items, books, or collectibles. Distribute weight evenly across the shelves.
- **Drawer Functionality:** The central drawer provides enclosed storage for smaller items. Pull the drawer out smoothly and push it back in completely to ensure it is closed.
- **Bottom Cabinet:** The lower section offers additional enclosed storage behind solid doors for items you wish to keep out of sight.



Image: The display cabinet with its three glass doors and lower solid doors open, along with the central drawer pulled out, revealing the interior storage compartments and shelves.



Image: The display cabinet with its glass doors open, revealing shelves filled with books, decorative objects, and other items, demonstrating its display capabilities.



Image: A close-up view of the upper section of the display cabinet, showcasing items like books and decorative objects behind the clear glass doors.



Image: A detailed view of the central drawer of the display cabinet, shown partially open to illustrate its storage capacity.

MAINTENANCE

Proper care will extend the life and appearance of your FAMAPY Display Cabinet.

- **Cleaning Wood Surfaces:** Wipe wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that can damage the finish. Dry immediately with a clean cloth.
- **Cleaning Glass Doors:** Use a standard glass cleaner and a lint-free cloth to clean the glass. Spray cleaner onto the cloth, not directly onto the glass, to prevent overspray from damaging wood finishes.
- **Dusting:** Regularly dust all surfaces with a soft, dry cloth.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood finish.

- **Humidity Control:** Maintain a stable humidity level in the room to prevent wood from warping or cracking.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose fasteners; uneven floor; anti-tip hardware not installed.	Ensure all screws and cam locks are tightened. Adjust leveling feet if present, or place shims under the base. Install anti-tip hardware securely to a wall stud.
Drawer does not slide smoothly.	Drawer slides misaligned; debris in tracks; drawer assembled incorrectly.	Check that drawer slides are correctly installed and aligned. Clean tracks of any dust or debris. Re-check drawer assembly steps in the manual.
Doors do not close properly or are misaligned.	Hinges are loose or misadjusted; cabinet frame is not square.	Tighten hinge screws. Adjust hinges as per the assembly manual to align doors. Ensure the cabinet is assembled squarely and is on a level surface.
Missing parts or damaged components upon arrival.	Shipping damage; packaging error.	Do not proceed with assembly. Contact FAMAPY customer support immediately with your purchase details and a description/photos of the issue.

PRODUCT SPECIFICATIONS

Brand	FAMAPY
Model Number	B0FFMYBXM4
Color	Black
Product Dimensions	15.7"D x 46.1"W x 79.9"H
Material	MDF/PB/Glass (Engineered Wood)
Mounting Type	Floor Mount
Installation Type	Freestanding
Number of Shelves	3 (visible in upper section)
Assembly Required	Yes
Room Type	Entryway, Hallway, Home Office, Kitchen, Living Room

WARRANTY INFORMATION

FAMAPY products typically come with a limited manufacturer's warranty covering defects in materials and workmanship. For specific warranty terms and conditions applicable to your display cabinet, please refer to the warranty card included in your product packaging or contact FAMAPY customer support directly. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions regarding the assembly, operation, or maintenance of your FAMAPY Display Cabinet, or if you encounter any issues, please do not hesitate to contact FAMAPY customer support.

For assistance, please refer to the contact information provided in your product packaging or visit the official FAMAPY website. When contacting support, please have your model number (B0FFMYBXM4) and purchase details readily available.

You can also visit the FAMAPY Store on Amazon for more information.

