

Manuals.plus /
› YESHOMY /
› YESHOMY 65 inch Fireplace TV Stand, Fire Place TV Stands for Living Room, Storage Cabinet, Entertainment Center with Storage, Gray Grey

YESHOMY YH-TS23-215-GY2

YESHOMY 65 inch Fireplace TV Stand Instruction Manual

Brand: YESHOMY | Model: YH-TS23-215-GY2

1. INTRODUCTION

The YESHOMY 65 inch Fireplace TV Stand is designed to enhance your living space with both functional storage and a comforting electric fireplace. This unit provides a warm ambiance and practical solutions for organizing your entertainment devices.



Image: The YESHOMY 65 inch Fireplace TV Stand, showcasing its design and how it fits into a modern living room setup with a television.

Key Features:

- **Integrated Electric Fireplace:** Provides warmth and ambiance, ideal for cold weather.
- **Farmhouse Style Design:** Features a solid classic top and distressed aging texture in grey, suitable for various decor styles.
- **Round Cable Management Holes:** Designed at the back for neat organization of TV and electronic device power supplies.
- **Ample Storage Space:** Offers significant storage for electronic devices and other household items, ensuring easy access.
- **Versatile Decor Functionality:** Beyond its primary use, the stand serves as a decorative piece, enhancing your living room's aesthetic.



Image: Detailed view of the TV stand's features, including the barn door design, magnetic door closures, and the waterproof surface finish.

2. WHAT'S IN THE BOX

Your YESHOMY Fireplace TV Stand package includes the following components. Please verify all items are present and undamaged upon receipt. The item will be delivered in two separate packages.

- One (1) TV Stand (unassembled components)
- One (1) Electric Fireplace insert
- One (1) Technical Manual (this document)
- All necessary hardware for assembly

3. PRODUCT SPECIFICATIONS

Feature	Detail
Model	Fireplace TV Stand (YH-TS23-215-GY2)
Color	Grey
Material	Wood
Product Dimensions (L x W x H)	58 x 15 x 23.8 inches
Item Weight	77 pounds
Number of Drawers	1 (Note: This refers to a cabinet section with an adjustable shelf, not a pull-out drawer.)
Special Feature	Adjustable Shelf
Construction	Floor-standing

PRODUCT SIZE



Image: A visual representation of the product's dimensions, indicating its length, width, and height for accurate placement planning.



Image: This illustration demonstrates the compatibility of the TV stand with various television sizes, specifically showing it can support TVs up to 80 inches.

4. SETUP AND ASSEMBLY

Assembly of the YESHOMY Fireplace TV Stand requires careful attention to detail. It is recommended to have two people for assembly, though one person can manage. Please follow these general steps:

1. **Unpack and Identify Parts:** Carefully unpack all components from both packages. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided diagrams in the assembly guide (not included in this manual, refer to the separate assembly guide that came with your product). Pay close attention to finished and unfinished sides to ensure correct orientation.
2. **Gather Tools:** Ensure you have the necessary tools for assembly (e.g., screwdriver, hammer if needed).
3. **Assemble Frame:** Begin by assembling the main frame of the TV stand according to the step-by-step instructions in your assembly guide. Secure all connections firmly.
4. **Install Shelves and Doors:** Attach any adjustable shelves and install the barn-style doors. Ensure the magnetic door

closures align properly.

5. **Insert Fireplace:** Carefully slide the electric fireplace insert into its designated opening. Ensure it is securely seated and any necessary electrical connections are accessible.
6. **Cable Management:** Utilize the round cable holes at the back of the unit to route and organize your TV and other electronic device cables neatly.
7. **Final Placement:** Once assembled, carefully move the TV stand to its desired location. Ensure it is on a stable, level surface.

***Important:** Always refer to the detailed assembly instructions provided in the separate manual that accompanies your product for specific diagrams and step-by-step guidance.*

5. OPERATING INSTRUCTIONS

Electric Fireplace Operation:

The integrated electric fireplace provides warmth and visual appeal. It can be controlled via the display screen on the unit or a remote control (if included).

Electric fireplace TV cabinet with remote control

Quickly raise the temperature in your room and provide you with a warm place to stay in cold weather



Three flame effects



Up to 7 days of time timing effect



Turn on/off the heater



Temperature 60-82°F

Display screen



Control panel



Image: An overview of the electric fireplace's control features, including flame effects, timer settings, heater function, temperature range, and the physical control panel and display screen.

- **Power On/Off:** Use the power button on the control panel or remote to turn the fireplace on or off.
- **Temperature Control:** Adjust the desired room temperature between 60°F and 82°F using the temperature controls. The heater will activate to reach and maintain the set temperature.
- **Flame Effects:** Select from three different flame effects to customize the visual ambiance.
- **Timer Function:** Set a timer for the fireplace to operate for up to 7 days, allowing for scheduled warmth.
- **Display Screen:** The integrated display screen shows current settings and status.

TV Stand Features:

- **Storage Cabinets:** Utilize the spacious cabinets behind the barn doors for storing media devices, books, or other items. The adjustable shelves allow for flexible organization.
- **Cable Management:** The pre-drilled round cable holes on the back panel help keep your electronic cables organized and out of sight, preventing clutter.

6. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your YESHOMY Fireplace TV Stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish. For the fireplace glass, use a glass cleaner specifically designed for fireplaces or non-abrasive glass cleaner.
- **Dusting:** Regularly dust the unit with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage. The surface is waterproof, but prolonged exposure to liquids should be avoided.
- **Fireplace Maintenance:** Ensure the fireplace vents are clear of obstructions to allow for proper airflow. Refer to the fireplace insert's specific manual for any additional maintenance requirements.
- **Hardware Check:** Periodically check all assembly hardware and tighten any loose screws to maintain stability.

7. TROUBLESHOOTING

If you encounter issues with your TV stand or electric fireplace, refer to the following common solutions:

- **Assembly Difficulties:**
 - **Parts not fitting/misaligned:** Double-check the part numbers and orientation against the assembly manual diagrams. Some parts may have specific finished/unfinished sides.
 - **Missing hardware/parts:** Review the components list. If items are missing, contact customer support immediately.
- **Electric Fireplace Not Turning On:**
 - **No power:** Ensure the fireplace is properly plugged into a functional electrical outlet. Check the circuit breaker.
 - **Remote not working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace sensor.
- **Fireplace Heater Not Producing Heat:**
 - **Temperature setting:** Verify the desired temperature is set higher than the current room temperature.
 - **Vents blocked:** Ensure the air intake and output vents on the fireplace are not obstructed.
- **Stand Instability:**
 - **Loose connections:** Re-tighten all screws and fasteners.
 - **Uneven surface:** Ensure the TV stand is placed on a flat, level surface. Use shims if necessary.

If the issue persists after attempting these solutions, please contact customer support.

8. WARRANTY AND SUPPORT

YESHOMY is committed to providing quality products and customer satisfaction.

Returns and Replacements:

This product is eligible for 90-day free returns, refunds, or replacements through Amazon. Please refer to Amazon's return policy for detailed information and procedures.

Protection Plans:

Extended protection plans may be available for purchase separately to cover your product beyond the standard return

period. Options may include 2-Year and 3-Year Protection Plans, or a Complete Protect plan.

Customer Support:

For any questions, concerns, or assistance with your YESHOMY Fireplace TV Stand, please contact YESHOMY customer support or Amazon customer service. You can typically find contact information on the YESHOMY brand store page on Amazon or through your Amazon order details.

Visit the official YESHOMY Store on Amazon for more information:[YESHOMY Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FDQLBK9H>

More documents and user manuals: <https://manuals.plus/>