

[Manuals.plus](#) /

› [FIVMEN](#) /

› FIVMEN Garden Pergola Gazebo 3x3m - User Manual

## FIVMEN YYT-WR-(ZP02855BE-1+ZP02856BE-2)

# FIVMEN Garden Pergola Gazebo 3x3m - User Manual

Model: YYT-WR-(ZP02855BE-1+ZP02856BE-2)

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your FIVMEN Garden Pergola Gazebo. Please read all instructions carefully before installation and use. Keep this manual for future reference.



Image 1.1: The FIVMEN Garden Pergola Gazebo providing shade over an outdoor dining area.

The FIVMEN Garden Pergola Gazebo is designed to offer elegant sun and rain protection, enhancing your outdoor living space. Its modern metal frame and individually adjustable shade sail provide maximum comfort and versatility for gardens, terraces, balconies, or commercial outdoor areas.

## 2. SAFETY WARNINGS

---

**WARNING:** Failure to follow these safety instructions may result in injury or damage to the product.

- Ensure the pergola is securely anchored to a stable base to prevent overturning in strong winds or heavy rain.
- Carefully follow all instructions in this manual and use only the provided accessories for safe installation and disassembly.
- Avoid assembling or disassembling the pergola in adverse weather conditions, such as strong winds, heavy rain, or thunderstorms, to prevent injury.
- Regularly inspect all components for wear, damage, or loose connections. Replace damaged parts immediately.
- Do not hang heavy objects from the pergola frame or shade sail.

- Keep children and pets away from the assembly area during installation.

### 3. PACKAGE CONTENTS

---

Before beginning assembly, verify that all components listed below are present and undamaged. The product is shipped in two packages.

- 1 x Pergola Frame Kit (metal tubes, connectors, hardware)
- 1 x Adjustable Shade Sail (polyester fabric with PA coating)
- 1 x Assembly Kit (including 16 ground nails)
- 1 x User Manual

### 4. SPECIFICATIONS

---

Feature	Specification
Brand	FIVMEN
Model Number	YYT-WR-(ZP02855BE-1+ZP02856BE-2)
Dimensions (L x W x H)	3 x 3 x 2.45 meters (9.8 x 9.8 x 8.0 feet)
Frame Material	High-strength Iron
Tube Dimensions	Lower tube: 8 x 8 cm (3.1 x 3.1 in), Upper tube: 5 x 5 cm (2 x 2 in)
Shade Sail Material	100% Polyester fabric with PA coating (160g/m <sup>2</sup> )
Color	Beige
UV Protection	Yes (UPF30+)
Water Resistance Level	Waterproof
Floor Area	9 square meters (96.8 square feet)
Assembly Required	Yes



Image 4.1: Detailed dimensions of the pergola structure.

## 5. SETUP AND INSTALLATION

The FIVMEN Pergola Gazebo is designed for easy installation with detailed instructions and included accessories. No complicated tools are required for assembly.

### 5.1 Site Selection

- Choose a flat, stable, and level surface for installation.
- Ensure adequate clearance around the pergola for safe use and maintenance.
- Consider sun exposure and wind patterns when selecting the location.

### 5.2 Assembly Steps

1. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, soft surface to prevent scratches. Refer to the package contents list to ensure all items are present.
2. **Assemble Frame:** Follow the step-by-step diagrams in the included assembly guide to connect the metal tubes and frame components. Ensure all connections are secure. The frame is constructed from high-strength metal,

designed for stability.

3. **Attach Shade Sail Mechanism:** Install the smooth rails and manual rope pull system for the adjustable shade sail onto the upper frame.
4. **Install Shade Sail:** Carefully attach the polyester shade sail to the installed mechanism. Ensure it slides smoothly.
5. **Anchor the Pergola:** Use the provided 16 ground nails to securely anchor each of the four stable columns to the ground. For different ground types, consider using appropriate anchors or bolts to ensure maximum stability and safety.



Image 5.1: Securing the pergola columns with ground anchors for stability.



Image 5.2: Key features of the pergola frame and shade mechanism.

## 6. OPERATING INSTRUCTIONS

The pergola features an adjustable roof cover, allowing you to control the amount of sun and shade.

### 6.1 Adjusting the Shade Sail

- The shade sail can be freely adjusted using the manual rope pull system.
- To **open** the shade, gently pull the rope to extend the fabric across the frame.
- To **close** or retract the shade, pull the rope in the opposite direction to gather the fabric.
- You can adjust the sail to achieve full sun protection, partial shade, or a fully open sky view, depending on weather conditions and your preference.
- A magnetic fixation system helps secure the shade in its desired position.



Image 6.1: Retractable awning mechanism for adjusting shade.

## 7. MAINTENANCE

Proper maintenance will extend the lifespan of your pergola and ensure its continued performance.

### 7.1 Cleaning

- **Frame:** Clean the metal frame with a soft cloth and mild soap and water. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners or harsh chemicals.
- **Shade Sail:** The polyester fabric with PA coating is sun-resistant and waterproof. Clean the shade sail with a soft brush or cloth and mild soap and water. Allow it to air dry completely before retracting or storing. Do not machine wash or tumble dry.

### 7.2 Seasonal Care

- **Regular Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight. Re-tighten as necessary.

- **Winter Storage:** While the pergola is designed to be winter-resistant, it is recommended to retract and secure the shade sail during heavy snow or prolonged periods of strong winds to prevent damage. In areas with extreme winter conditions, consider disassembling and storing the shade sail indoors.
- **Wind and Rain:** In anticipation of strong winds or heavy rain, retract the shade sail to prevent damage to the fabric and frame.



Image 7.1: The shade sail material offers all-weather protection, including UV resistance and a water-repellent surface.

## 8. TROUBLESHOOTING

This section addresses common issues you might encounter with your pergola.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Pergola feels unstable or wobbly.	Ground anchors not properly secured; uneven ground; loose frame connections.	Ensure all 16 ground nails are fully inserted and secure. Verify the installation surface is level. Check and tighten all frame bolts and screws.
Shade sail does not slide smoothly.	Obstruction in the rails; rope mechanism tangled; fabric misaligned.	Inspect the rails for debris or obstructions and clear them. Untangle the rope if necessary. Ensure the fabric is correctly aligned within the rails.
Water pooling on shade sail.	Insufficient tension in fabric; heavy rainfall.	Ensure the shade sail is fully extended and taut. Retract the shade during heavy rainfall to prevent excessive water accumulation.
Frame components do not fit during assembly.	Incorrect orientation of parts; manufacturing defect.	Double-check the assembly diagrams to ensure parts are oriented correctly. If a part appears defective, contact customer support.

## 9. WARRANTY AND SUPPORT

---

FIVMEN products are designed for quality and durability. For specific warranty information, please refer to the documentation provided at the time of purchase or contact your retailer.

If you encounter any issues not covered in this manual or require further assistance, please contact FIVMEN customer support through your purchase platform or the official FIVMEN website. Please have your model number (YYT-WR-(ZP02855BE-1+ZP02856BE-2)) and purchase details ready when contacting support.