

Faber 325.0737.662

Faber Hood Venice 75 cm Autoclean Curved Chimney User Manual

Model: 325.0737.662

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Faber Hood Venice 75 cm Autoclean Curved Chimney. Please read these instructions carefully before using the appliance and retain them for future reference. This chimney is designed to remove smoke, grease, and odors from your kitchen environment, featuring filterless technology, auto-clean function, and touch/gesture controls.

2. SAFETY INFORMATION

General Safety Precautions

- Ensure the appliance is installed by a qualified technician in accordance with local regulations.
- Do not operate the chimney without proper ventilation.
- Keep children away from the appliance during operation and cleaning.
- Never flambé under the chimney.
- Do not leave frying food unattended, as overheated oil can ignite.
- Clean the appliance regularly to prevent grease buildup, which can be a fire hazard.
- Disconnect the power supply before any cleaning or maintenance.

Electrical Safety

- Ensure the power supply voltage matches the rating label on the appliance (230 Volts).
- Do not use extension cords or adapters.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Ensure the appliance is properly earthed.

3. PRODUCT OVERVIEW

The Faber Hood Venice 75 cm Autoclean Curved Chimney is a wall-mounted kitchen appliance designed for efficient air purification. Key features include:

- **Filterless Technology:** Eliminates the need for frequent filter cleaning.
- **Autoclean Function:** Simplifies internal cleaning by collecting oil in a detachable tray.
- **High Suction Power:** 1200 m³/hr for effective smoke and odor removal.
- **Touch & Gesture Control:** Intuitive operation with touch buttons and motion sensors.
- **LED Lighting:** Provides illumination for your cooking area.
- **Low Noise Level:** Operates at 59dB for a quieter kitchen environment.



Silent. Smart. Stunning.

The perfect blend of silent operation, gesture control, and premium black glass finish

Front view of the Faber Hood Venice 75 cm Autoclean Curved Chimney, showcasing its curved glass design and control panel.

4. SETUP AND INSTALLATION

The chimney is designed for wall-mounted installation. Proper installation is crucial for optimal performance and safety. It is

recommended to have the installation performed by a qualified service technician.

Installation Type: Ducted vs. Ductless

Your chimney supports both ducted and ductless installation methods:

- **Ducted Installation:** Smoke and odors are expelled outside through a duct pipe. This method offers maximum efficiency.
- **Ductless Installation:** Air is filtered through an optional charcoal filter (purchased separately) and recirculated into the kitchen. Contact customer support for information on compatible charcoal filters.



Illustration showing both ducted and ductless installation options for the chimney, highlighting the external duct pipe for ducted and the internal charcoal filter for ductless.

Mounting and Dimensions

Ensure adequate space above your cooking range for optimal performance. The recommended distance from the gas stove to the chimney base is 71-76 cm.



EXTEND YOUR WARRANTY TODAY

EXTRA

3 YEARS COVERAGE

More protection. More confidence.



Diagram illustrating the key dimensions of the 75 cm chimney: 43.5 cm height, 75 cm width, and 41 cm front-to-back depth. Also shows recommended distance from stove.

5. OPERATING INSTRUCTIONS

The chimney can be operated using its touch control panel or gesture control feature.

Control Panel Functions

- **Power Button:** Turns the chimney ON/OFF.
- **Speed Selection:** Adjusts suction power across 3 speeds (1, 2, 3). Use higher speeds for heavier cooking.
- **Light Button:** Controls the LED lighting.
- **Autoclean Button:** Initiates the auto-clean cycle.

Gesture Control

The chimney features motion sensors for hands-free operation. Wave your hand in front of the sensor to turn the chimney ON/OFF or to cycle through speed settings.

FABER
FRANKE'S AIR EXPERT



Premium
Black Glass
Finish

Seamlessly Complements
Modern Modular Kitchens

Demonstration of gesture control (waving hand) and touch control (finger press) for operating the chimney's functions.

Filterless Operation

The filterless design ensures powerful suction without the need for traditional filters. This design directs smoke and grease directly into the oil collector, simplifying maintenance.



Visual representation of the chimney's filterless operation, showing smoke being drawn upwards, and indicating a 1200 m³/hr suction capacity.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your chimney. Always disconnect the power supply before performing any cleaning or maintenance.

Autoclean Function

The auto-clean feature uses heat to melt and collect oil and grease into a dedicated oil collector. Activate this function regularly, depending on your cooking frequency.

Cleaning the Oil Collector

1. Ensure the chimney is turned OFF and cooled down.
2. Locate the oil collector tray at the bottom of the chimney.
3. Gently pull out the oil collector.

4. Empty the collected oil and wash the tray with warm, soapy water. Rinse thoroughly and dry completely before reinserting.
5. Reinsert the oil collector securely into its position.



Detailed view of the detachable oil collector, shown being removed for cleaning, and the integrated LED light panel.

Exterior Cleaning

- Wipe the exterior surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the finish.
- For glass surfaces, use a glass cleaner and a soft cloth.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues.

Problem	Possible Cause	Solution
Chimney does not turn ON.	No power supply. Power cord not properly connected.	Check the main power switch. Ensure the power cord is securely plugged into the outlet.

Problem	Possible Cause	Solution
Low suction power.	Oil collector is full. Obstruction in the ducting (ducted models). Charcoal filter clogged (ductless models).	Empty and clean the oil collector. Check ducting for blockages. Replace the charcoal filter if applicable.
Unusual noise during operation.	Loose components. Obstruction in the fan.	Ensure all parts are securely fastened. Turn off and disconnect power, then check for foreign objects near the fan.
Autoclean function not working.	Chimney not at operating temperature. Electrical fault.	Ensure the chimney has been running for a short period. Contact customer support if the issue persists.

8. SPECIFICATIONS

Brand	Faber
Model Number	325.0737.662
Product Dimensions (D x W x H)	41D x 75W x 45.5H Centimeters
Colour	Black
Material Type	Stainless Steel
Finish Type	Powder Coated
Air Flow Capacity	1200 Cubic Meters Per Hour
Noise Level	59 Decibels
Mounting Type	Wall Mount
Control Method	Gesture, Touch
Number Of Speeds	3
Light Source	LED
Filter Type	Filterless
Ventilation Type	Ducted (Ductless with optional charcoal filter)
Voltage	230 Volts
Item Weight	13.1 Kilograms

9. WARRANTY AND SUPPORT

Warranty Information

The Faber Hood Venice 75 cm Autoclean Curved Chimney comes with a comprehensive warranty:

- **2 Years Comprehensive Warranty** on the product.
- **8 Years Warranty** on the motor.

Warranty claims require the Amazon Invoice as proof of purchase. For detailed terms and conditions, please refer to the official Faber website or contact customer support.

Customer Support

For any queries, service requests, or technical assistance, please contact Faber customer support:

- **Toll-Free Contact Number:** 1800-209-3484
- Refer to the official Faber website for additional support resources and service center locations.