Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UR ADVANCE mason jar vacuum sealer

UR ADVANCE 3-in-1 Electric Mason Jar Vacuum Sealer Kit Instruction Manual

Model: Mason Jar Vacuum Sealer

1. Introduction

The UR ADVANCE 3-in-1 Electric Mason Jar Vacuum Sealer Kit is designed to extend the freshness of your food by removing air from Mason jars, vacuum bags, and compatible containers. This cordless, portable device features auto-stop technology and a clear display for monitoring progress and battery level, ensuring optimal sealing without over-processing. It supports both wide and regular mouth Mason jars without requiring additional adapters.

2. Safety Information

- Read all instructions before use.
- Keep the device away from water or other liquids.
- Do not attempt to open or repair the device yourself. Contact customer support for assistance.
- Use only the provided charging cable.
- Ensure jars, lids, and bags are clean and dry before sealing.
- This device is intended for household use only.

3. Package Contents

Your UR ADVANCE 3-in-1 Electric Mason Jar Vacuum Sealer Kit includes:

- 1 x Electric Canning Jar Vacuum Sealer (Black)
- 1 x USB-C Charging Cable
- 10 x Reusable Wide Mouth Jar Lids (3.31 in/84 mm)
- 10 x Reusable Regular Mouth Jar Lids (2.67 in/68 mm)
- 1 x Lid Opener Tool
- 2 x Vacuum Sealer Bags
- 1 x Slider Clip (for bags)
- 1 x User Manual



Image: The complete UR ADVANCE 3-in-1 Electric Mason Jar Vacuum Sealer Kit, showing the main unit, various jar lids, vacuum bags, charging cable, and lid opener.

4. Setup

4.1 Charging the Device

1. Connect the provided USB-C charging cable to the charging port on top of the vacuum sealer.
2. Plug the other end of the USB-C cable into a compatible USB power adapter (not included).
3. The display will show the charging progress. A full charge takes approximately 1 hour and provides up to 4 hours of runtime (over 250 seals).
4. To check the battery level, press the power button twice. The display will show the current percentage.

4.2 Attaching Sealer Heads (for Jars)

The sealer is designed to work with both wide and regular mouth Mason jars without needing separate adapters for the main unit. Ensure the correct size lid is used for your jar.



Image: A visual guide demonstrating the process of placing the sealer onto a Mason jar lid for vacuum sealing.

4.3 Attaching Bag Adapter (for Bags)

For vacuum bags, attach the small nozzle adapter to the bottom of the sealer unit by sliding it in and twisting to secure. This nozzle will then align with the air valve on the vacuum bags.

5. Operating Instructions

5.1 Sealing Mason Jars

1. Ensure your Mason jar rim is clean and dry.
2. Place a compatible air-valve lid (wide or regular mouth) onto the jar.
3. Place the electric vacuum sealer directly on top of the lid, ensuring it is centered over the air valve.
4. Press down firmly on the sealer until it creates a snug fit.
5. Press the power button once to start the vacuum sealing process. The display will show a countdown.
6. The sealer will automatically stop when a perfect vacuum seal is achieved (typically 8-15 seconds for jars).
7. Carefully remove the sealer from the jar. The lid should now be securely sealed.




Image: A four-step visual demonstration of how to vacuum seal a Mason jar, from placing the lid to automatic shut-off.

5.2 Sealing Vacuum Bags

1. Place food into a compatible vacuum sealer bag and zip it closed, leaving the air valve accessible.
2. Attach the bag adapter nozzle to the electric sealer unit (refer to Section 4.3).
3. Place the sealer with the attached nozzle directly over the air valve on the bag.
4. Press the power button once to start the vacuum sealing process.
5. The sealer will automatically stop when the air is removed and the bag is sealed (typically 7-12 seconds for bags).



Image: A four-step visual guide illustrating how to prepare a vacuum bag, attach the sealer, and initiate the vacuum process.

5.3 Sealing Containers

1. Place food into a compatible vacuum container and ensure the lid is securely locked.
2. Place the electric vacuum sealer directly on top of the container's air valve.
3. Press the power button once to start the vacuum sealing process.
4. The sealer will automatically stop when the air is removed and the container is sealed (typically 12-20 seconds for containers).



Image: A four-step visual guide demonstrating how to vacuum seal a food container, including checking the seal and automatic shut-off.

5.4 Opening Sealed Jars

To open a vacuum-sealed Mason jar, use the provided lid opener tool. Gently lift the edge of the lid until you hear the air release, then remove the lid.

6. Maintenance

6.1 Cleaning the Sealer Unit

- Wipe the exterior of the sealer unit with a damp cloth. Do not immerse the unit in water.
- Ensure the sealing area on the bottom of the unit is free from food debris.

6.2 Care for Lids and Bags

- Wash reusable lids and vacuum bags with warm, soapy water and rinse thoroughly. Allow them to air dry completely before reuse.
- Inspect lids and bags for any damage or wear before each use to ensure an effective seal.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Low battery.	Charge the device using the provided USB-C cable.
Cannot achieve a vacuum seal.	Jar rim/lid/bag valve is dirty or wet; lid/bag is damaged; sealer not properly aligned.	Clean and dry sealing surfaces. Inspect lids/bags for damage. Ensure sealer is centered and pressed firmly.
Seal is lost shortly after sealing.	Food particles on sealing surface; lid/bag is faulty.	Ensure no food debris is on the sealing surface. Use a new lid or bag.

8. Specifications

- **Brand:** UR ADVANCE
- **Model:** Mason Jar Vacuum Sealer
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Color:** Black
- **Product Dimensions:** 3.35"L x 3.35"W x 2.44"H
- **Item Weight:** 5.8 ounces
- **Power Source:** Battery Powered
- **Operation Mode:** Automatic
- **Wattage:** 5 Watt-hours
- **Voltage:** 3.7 Volts
- **Battery Life:** Up to 4 hours runtime (over 250 seals) on a 1-hour charge.
- **Charge Cycles:** Built to endure 1,000+ cycles.

9. Warranty and Support

This product includes a **180-Day Protection Plan**. If you encounter any issues within 180 days of purchase, please contact UR ADVANCE customer support for assistance or a replacement.

For further support or inquiries, please visit the UR ADVANCE Store on Amazon.

10. Product Videos

Watch these official product videos for a visual guide on using your UR ADVANCE Electric Mason Jar Vacuum Sealer Kit:

Your browser does not support the video tag.

Video: "Auto Canner Mason Jar Sealer Watch How to Use Full Overview See it Work Whats Included UR ADVANCE Ad" - A comprehensive overview of the product, its components, and usage demonstrations.

Your browser does not support the video tag.

Video: "Electric Mason Jar Vacuum Sealer Kit Auto-Stop" - Demonstrates the automatic stop feature and general operation of the vacuum sealer.

Your browser does not support the video tag.

Video: "Can seal jars, bags and containers!" - Shows the versatility of the sealer across different storage types.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FDQYZDGT

More documents and user manuals: **https://manuals.plus/**