

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [VGR](#) /
- > [VGR 739 3-in-1 Epilator for Women - Instruction Manual](#)

VGR VGR 739

VGR 739 3-in-1 Epilator for Women - Instruction Manual

Model: VGR 739 | Brand: VGR

1. INTRODUCTION

Thank you for choosing the VGR 739 3-in-1 Epilator. This versatile device combines an epilator, shaver, and callus remover into a single, portable unit, designed for efficient and comfortable hair removal and skin care. Its cordless, rechargeable design and IPX4 waterproof rating make it suitable for both wet and dry use. Please read this instruction manual carefully before first use to ensure proper operation, maintenance, and safety.

2. PRODUCT OVERVIEW

2.1 Components

3 in 1 Lady Epilator

Interchangeable blades for all your hair removal needs



Image: The VGR 739 epilator main body, epilator head, shaver head, callus remover head, shaver cutting guide, bikini cup, USB charging cable,


cleaning brush, and protection cap.

- **Main Unit:** Ergonomic body with power button and LED light.
- **Epilator Head:** Equipped with 32 tweezers for efficient hair removal from the root.
- **Shaver Head:** For quick and gentle shaving.
- **Callus Remover Head:** Designed to smooth rough skin on feet.
- **Shaver Cutting Guide:** For trimming hair to a desired length before shaving.
- **Bikini Cup:** An attachment for precise epilation in sensitive areas.
- **USB Charging Cable:** For convenient recharging.
- **Cleaning Brush:** For maintaining the device heads.
- **Protection Cap:** To cover the epilator head when not in use.

2.2 Key Features

Multi-functional all-round hair removal

3-in-1 Precision Replaceable Bits



Underarm Arm

Legs Back

Image: Detailed view of the VGR 739 epilator highlighting its main features.

- **3-in-1 Functionality:** Epilator, shaver, and callus remover in one device.
- **32 Tweezers System:** Efficiently removes even short and fine hairs from the root.
- **Built-in LED Light:** Illuminates the skin for better visibility of fine hairs.
- **Two-Speed Settings:** Low speed for sensitive areas, high speed for larger areas.
- **IPX4 Waterproof:** Suitable for wet and dry use, and easy to clean under running water.
- **USB Rechargeable & Cordless:** Provides up to 60 minutes of cordless operation after a 1.5-hour charge.
- **Portable Design:** Compact and lightweight for travel and convenient use.

3. SETUP

3.1 Charging the Device



Image: The VGR 739 epilator being charged via its USB cable.

1. Ensure the device is turned off before charging.
2. Connect the USB charging cable to the charging port on the device.
3. Plug the other end of the USB cable into a suitable USB power adapter (not included) or a computer USB port.
4. The charging indicator light will illuminate. A full charge takes approximately 1.5 hours.
5. Once fully charged, the device provides up to 60 minutes of continuous cordless use.

3.2 Attaching and Changing Heads

Charging & Working time

USB charging provides you with portability anytime, anywhere.



Charge time: **1.5** hours

Working time: **60** minutes

Image: The three main interchangeable heads: epilator, shaver, and callus remover.

1. To remove a head, press the release button (usually located on the side of the device) and gently pull the head upwards.
2. To attach a head, align the desired head with the main unit and press it down until you hear a click, indicating it is securely fastened.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Speed Settings



Image: Illustration of the two-speed settings for the VGR 739 epilator.

- Press the power button once to turn on the device at Level 1 (low speed), suitable for sensitive areas.
- Press the power button a second time to switch to Level 2 (high speed), ideal for faster results on larger areas.
- Press the power button a third time to turn off the device.
- The built-in LED light will activate automatically when the device is turned on.

4.2 Using the Epilator Head

Efficient And Painless Hair Removal



Built-in 32 high-speed rotating precision tweezer wheels set to capture hairs of different lengths and thicknesses accurately



90 Degree Angle Hair Removal
Use against hair growth for best results

32 Tweezers System

Image: The 32 tweezers system of the epilator head in action, demonstrating hair removal from the root.

- Ensure your skin is clean and dry, or slightly damp if using for wet epilation.
- Hold the device at a 90-degree angle to your skin.
- Gently glide the epilator against the direction of hair growth.
- Stretch the skin taut with your free hand to minimize discomfort.
- Move the device slowly and steadily. Avoid pressing too hard.
- Suitable for legs, arms, underarms, and bikini area. For sensitive areas, use the lower speed setting.

4.3 Using the Shaver Head

- Attach the shaver head to the main unit.
- For best results, use on clean, dry skin.
- Glide the shaver gently over the skin in the direction of hair growth.
- The shaver cutting guide can be used to trim longer hairs before a closer shave.

4.4 Using the Callus Remover Head

- Attach the callus remover head to the main unit.
- Use on dry skin.
- Gently move the callus remover over areas with calluses or rough skin.
- Do not apply excessive pressure or use on irritated or broken skin.

4.5 Wet & Dry Use



Image: The VGR 739 epilator demonstrating its IPX4 waterproof feature with water droplets.

The VGR 739 is IPX4 waterproof, allowing for both wet and dry use. You can use it in the shower or bath for a more comfortable experience. However, the device should **not** be fully submerged in water.

5. MAINTENANCE

5.1 Cleaning the Device Heads

- After each use, turn off the device and detach the head.
- Use the provided cleaning brush to remove any trapped hairs or skin particles from the head.
- For a more thorough clean, rinse the detached head under running water. Ensure the head is completely dry before reattaching or storing.
- Do not use harsh chemicals or abrasive cleaners on any part of the device.

5.2 Storage

- Store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the protection cap on the epilator head when not in use to prevent damage.
- Ensure the device is fully charged before long-term storage to maintain battery health.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device for 1.5 hours.
Device does not remove hair effectively.	Incorrect angle or speed; hair too short/long; head is dirty.	Ensure device is held at a 90-degree angle and moved against hair growth. Use appropriate speed setting. Clean the head thoroughly. For epilation, hair length between 0.5mm and 5mm is ideal.

Problem	Possible Cause	Solution
Device stops working during use.	Battery is low.	Recharge the device.
Charging cable is difficult to plug in.	Misalignment or obstruction.	Ensure the cable is aligned correctly with the port. Do not force it.

7. SPECIFICATIONS

- **Model Number:** VGR 739
- **Power Source:** Battery Powered
- **Battery Type:** 1 C battery (included)
- **Battery Capacity:** 600mAh (approximate, derived from 1.5hr charge/60min use)
- **Charging Time:** Approximately 1.5 hours
- **Working Time:** Up to 60 minutes (cordless)
- **Waterproof Rating:** IPX4 (splash-proof)
- **Product Dimensions:** 2.95 x 1.97 x 4.33 inches
- **Item Weight:** 147 Grams (5.19 ounces)
- **Voltage:** 12 Volts (DC)
- **Manufacturer:** VGR

8. SAFETY INFORMATION

- Keep the device out of reach of children.
- Do not use the device on irritated, inflamed, or broken skin. Consult a doctor if you have any skin conditions.
- Do not use the callus remover head on areas other than callused skin on the feet.
- The device is IPX4 waterproof, meaning it is protected against splashing water. Do not submerge the device in water.
- Always ensure the device is turned off before cleaning or changing heads.
- If the device shows any signs of damage, do not use it. Contact customer support.
- Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the packaging or contact the manufacturer, VGR, directly. Keep your purchase receipt as proof of purchase.

