

PKBD QJJ-202403

PKBD 1200W Handheld Steam Cleaner

INSTRUCTION MANUAL

Model: QJJ-202403

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your PKBD 1200W Handheld Steam Cleaner. Please read all instructions carefully before using the appliance and retain this manual for future reference.

2. Important Safety Instructions

WARNING: Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before filling with water, emptying, cleaning, or performing any maintenance.
- Do not leave the steam cleaner unattended while it is plugged in or operating.
- Keep the appliance out of reach of children and pets.
- Do not direct steam at people, animals, or electrical appliances. Steam is extremely hot and can cause severe burns.
- Use only clean tap water in the water tank. **Never add oils, detergents, perfumes, or any other chemical cleaning solutions to the water tank**, as this can damage the appliance and create hazardous fumes.
- Do not immerse the steam cleaner in water or any other liquid.
- Inspect the power cord and plug for damage before each use. Do not operate the appliance if the cord or plug is damaged.
- Allow the appliance to cool completely before storing.

- This appliance is intended for household use only. Do not use it for commercial or industrial purposes.

The PKBD Handheld Steam Cleaner operates without chemicals, making it safe for use around children and pets. The steam button is designed for easy and safe operation.



Figure 1: Chemical-free operation and steam button. This image illustrates the safety aspect of using only water for cleaning, highlighting the steam button for user interaction.

3. Product Overview and Components

Your PKBD Handheld Steam Cleaner comes with an 11-piece accessory kit designed for various cleaning tasks.



Figure 2: PKBD Handheld Steam Cleaner and included accessories. This image displays the main unit alongside all 11 attachments, providing a visual guide to the complete product package.

Included Accessories:

- Steam cleaner main unit
- Extension nozzle
- Small brush head (2 types)
- Scouring pad brush head
- Silicone soft scraper
- Multi-in-one brush body
- Cloth cover (2 pieces)
- Steel wool ball
- Extension tube
- Measuring Cup



Figure 3: Detailed view of the 11-piece accessory kit. This image provides a clear visual breakdown of each accessory, aiding in identification and understanding their purpose.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Ensure all accessories listed in Section 3 are present.
2. **Fill Water Tank:** Ensure the steam cleaner is unplugged. Open the water tank cap. Use the provided measuring cup to fill the 450ml visualization tank with clean tap water. Do not overfill. The transparent tank allows you to monitor the water level.
3. **Attach Desired Accessory:** Select the appropriate accessory for your cleaning task (e.g., extension nozzle, brush head). Attach it securely to the main unit.

5. Operating Instructions

1. **Power On:** Plug the steam cleaner into a suitable electrical outlet. The appliance will begin heating immediately.
2. **Heating Time:** The steam cleaner features 20-second fast heating. It will be ready for use in approximately 20 seconds, indicated by a change in indicator light (if present, refer to specific model

indicators).



Figure 4: Fast heating mechanism. This image visually explains the rapid heating process, highlighting the 20-second readiness and the 120°C steam temperature.

3. **Begin Cleaning:** Point the attached accessory towards the surface to be cleaned. Press and hold the steam button to release steam. Move the steam cleaner slowly over the surface.
4. **Using Different Attachments:**
 - **Brushes:** Ideal for scrubbing stubborn dirt and grime on surfaces like kitchen stovetops, grout, and tiles.
 - **Extension Nozzle/Tube:** For reaching difficult areas or for general steam application.
 - **Scraper/Cloth Cover:** Suitable for windows, mirrors, and upholstery.



Figure 5: Versatile cleaning applications. This collage demonstrates the steam cleaner's effectiveness across different surfaces, including tiled walls, floors, kitchen areas, car interiors, windows, and fabric upholstery.

POWERFUL & EFFICIENT

Subverting traditional cleaning methods



Figure 6: Cleaning effectiveness. This image shows a 'before and after' comparison of a heavily soiled stovetop, illustrating the steam cleaner's ability to remove tough grease and grime.

5. **Refilling Water:** If the water tank runs low during operation, unplug the unit, allow it to cool slightly, and then refill as per step 2 of the Setup section. The 450ml capacity is designed for cleaning entire kitchens or cars on a single fill.
6. **Power Off:** Once cleaning is complete, release the steam button and unplug the appliance from the power outlet.

6. Maintenance

1. **Emptying Water:** After each use, ensure the appliance is unplugged and cooled. Carefully open the water tank cap and empty any remaining water.
2. **Cleaning Accessories:** Wash removable accessories with warm, soapy water. Rinse thoroughly and allow them to air dry completely before storing.
3. **Cleaning the Main Unit:** Wipe the exterior of the steam cleaner with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
4. **Storage:** Store the steam cleaner and its accessories in a cool, dry place, out of direct sunlight and away from children.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam produced	No water in tank or insufficient heating time.	Fill water tank. Allow 20 seconds for heating after plugging in.
Steam leakage from accessory connection	Accessory not securely attached.	Ensure accessory is firmly clicked into place. Allow unit to cool before reattaching.
Appliance not turning on	Not plugged in or power outlet issue.	Check power connection. Test outlet with another appliance.
Reduced steam output	Mineral buildup (limescale) or low water level.	Empty and refill water tank. If persistent, consider descaling with white vinegar (refer to manufacturer's guidelines for descaling).

8. Specifications

- **Model Number:** QJJ-202403
- **Brand:** PKBD
- **Power/Wattage:** 1200 Watts
- **Water Tank Capacity:** 450 Milliliters
- **Heating Time:** Approximately 20 seconds
- **Steam Temperature:** Up to 120°C (248°F)
- **Item Weight:** 1.57 Kilograms
- **Manufacturer:** Wenzhou Fangchu Electronic Technology Co., Ltd

9. Warranty and Support

This product is manufactured by Wenzhou Fangchu Electronic Technology Co., Ltd under the PKBD brand. For warranty information, please refer to the terms and conditions provided at the point of purchase or contact your retailer. For technical support or inquiries, please reach out to the customer service department of your retailer.