

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bedsure](#) /

› [Bedsure Cordless Heated Wearable Blanket Hoodie \(Model BS-2501PW\) - Instruction Manual](#)

Bedsure BS-2501PW

Bedsure Cordless Heated Wearable Blanket Hoodie

Model: BS-2501PW

PRODUCT OVERVIEW

The Bedsure Cordless Heated Wearable Blanket Hoodie provides versatile warmth with dual power modes, allowing for both portable and fixed use. It features multiple heating zones, adjustable heat and timer settings, and is designed for comfort and convenience.



Image: The Bedsure Cordless Heated Wearable Blanket Hoodie offers warmth anytime, anywhere, supporting both indoor plug-in and outdoor power bank modes.

Key Features:

- **Dual Power Modes:** Supports AC power for indoor use and a 20,000mAh portable battery for up to 6.5 hours of warmth on the go.
- **Full Body Coverage:** Equipped with 8 large heating panels across shoulders, chest, back, pockets, and legs.
- **Reliable Safety Controls:** 4 adjustable temperature levels, 4 timer settings (1-4 hours), built-in overheat protection, and automatic shut-off after 3 hours of inactivity. FCC certified.
- **Adjustable Hooded Fit:** Stylish wearable blanket with a cozy hood and adjustable waist drawstring.
- **Premium Materials:** Made with soft 280GSM faux cashmere outside and warm 200GSM milk fleece inside.
- **Smart Eco-Sleep Mode:** Power bank enters standby to save energy when the blanket is off.

SETUP

Charging the Power Bank:

1. For first use, ensure the 20,000mAh power bank is fully charged.
2. Connect one end of the provided connecting cable to the power bank.
3. Connect the other end of the cable to the adapter.
4. Plug the adapter into a standard wall outlet. The power bank display will show charging progress.



Image: Diagram illustrating the two power options: fixed use (plugged into wall) and portable use (with power bank), along with instructions for charging the power bank.

Connecting the Power Source to the Blanket:

The blanket supports two power options: Fixed Use (AC power) and Portable Use (Power Bank).

1. Fixed Use (AC Power):

1. Locate the power connector inside the blanket's pocket.
2. Connect one end of the provided connecting cable to the blanket's power connector.
3. Connect the other end of the cable to the adapter.
4. Plug the adapter into a standard wall outlet.

2. Portable Use (Power Bank):

1. Ensure the power bank is fully charged.
2. Locate the power connector inside the blanket's pocket.
3. Connect the blanket's power connector to the Type-C port of the power bank.
4. Place the power bank securely in the blanket's designated pocket and snap it closed.

Your browser does not support the video tag.

Video: This video provides a general overview of the Bedsure Cordless Wearable Heated Blanket, demonstrating its features and how it can be worn.

OPERATING INSTRUCTIONS

Powering On and Adjusting Settings:

1. Once the blanket is connected to a power source (AC adapter or power bank), press and hold the digital silicone power button on the blanket for 3 seconds to turn it on. The display will illuminate.

2. To adjust the heat level, press the power button briefly. There are 4 heat levels (01-04).
3. To set a timer, press the timer button (clock icon) briefly. You can select from 1, 2, 3, or 4 hours. If no timer is set, the blanket will automatically shut off after 3 hours for safety.
4. To turn off the blanket, press and hold the power button for 3 seconds.



Image: The smart control panel features a digital display for 4 heat levels and 4 timer settings, ensuring easy and precise temperature management.

Your browser does not support the video tag.

Video: This video demonstrates the power-on operation of the Bedsure Heated Wearable Blanket, showing how to activate and use the heating functions.

Smart Eco-Sleep Mode:

After the blanket is turned off, the power bank will enter standby mode to conserve energy. To reactivate power for subsequent use, press the button on the blanket or unplug and replug the cable to the power bank.

MAINTENANCE

Cleaning Instructions:

- Always remove the power connector and power bank before washing.
- The blanket is machine washable. To protect the heating elements and prolong the product's life, use a laundry bag during machine washing.
- Wash on a gentle cycle with cold water.
- Tumble dry on low heat or air dry. Do not iron.

TROUBLESHOOTING

Controller Error (F1, F2, F3, etc.) or Black Screen:

1. Ensure the controller is not wrapped into the product or placed near a heated object, as overheating might trigger self-protection mode.
2. Unplug the power cord from the outlet/power bank and disconnect the cable from the blanket.
3. Reconnect the cable plug to the blanket and then to the power source, and restart the controller by pressing and holding the power button for 3 seconds.
4. If the issue persists after multiple attempts, please contact customer service for assistance.

Power Bank Shows Error or Doesn't Work:

1. When the blanket is powered by a power bank, do not charge other electronic devices simultaneously, as this may cause an error.
2. To save power, the power bank may enter eco-sleep mode after being powered off for a while. If the

blanket doesn't work, unplug and reconnect the cable to the power bank to restore power.

Your browser does not support the video tag.

Video: This video provides solutions for common issues such as controller errors (F1, F2, F3) or a black screen, and power bank malfunctions.

SPECIFICATIONS

- **Model Number:** BS-2501PW
- **Power Bank Capacity:** 20,000mAh (included)
- **Heat Levels:** 4
- **Timer Settings:** 1, 2, 3, 4 hours
- **Automatic Shut-off:** 3 hours (if no timer set)
- **Material (Outer):** 280GSM Faux Cashmere
- **Material (Inner):** 200GSM Milk Fleece
- **Dimensions (Standard):** 22" x 43"
- **Item Weight:** 5.06 pounds
- **Safety Certifications:** FCC

WARRANTY AND SUPPORT

For warranty information or further assistance, please refer to the product packaging or contact Bedsure customer service directly. Keep your purchase receipt for any warranty claims.