

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Losfom](#) /

› [Losfom Z11 4K Body Camera User Manual](#)

Losfom Z11

Losfom Z11 4K Body Camera User Manual

Model: Z11

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Losfom Z11 4K Body Camera. Please read this manual thoroughly before using the device to ensure optimal performance and longevity. The Losfom Z11 is a compact, wearable camera designed for high-quality audio and video recording, featuring 4K resolution, night vision, and dual battery support.

WHAT'S IN THE BOX

- Losfom Z11 4K Body Camera
- Two 1400mAh Rechargeable Batteries (one pre-installed)
- Charging Dock
- Bike Mount
- Lanyard
- USB Charging Cable
- Micro SD Card (capacity may vary by package)



Figure 1: Losfom Z11 4K Body Camera with all included accessories.

SETUP

1. Charging Batteries

The Losfom Z11 comes with two 1400mAh rechargeable batteries. One battery is typically pre-installed in the camera, and a spare is provided. Use the included charging dock to charge both batteries simultaneously.

1. Insert the batteries into the designated slots on the charging dock.
2. Connect the USB charging cable to the charging dock and a power source (e.g., USB wall adapter, computer USB port).
3. The indicator lights on the dock will show the charging status. Once fully charged, remove the batteries.

Replaceable 2pcs Batteries Equipped



Figure 2: Replacing the Losfom Z11 battery. Press the latch, pop out the battery, and insert a new one.

Charge One, Use One

Stay powered with dual batteries and dock



Figure 3: The charging dock allows for simultaneous charging of both batteries.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Losfom Z11 4K Body Camera, including its dual battery system and charging dock.

2. Inserting the Micro SD Card

The camera requires a Micro SD card for storing recordings. A card is typically included with your purchase.

1. Locate the Micro SD card slot on the side of the camera.
2. Gently insert the Micro SD card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.
3. To remove, gently press the card inward until it springs out.

3. Attaching Accessories

The Losfom Z11 offers various wearing and mounting options for different scenarios.

- **Back Clip:** Attach the camera to your uniform, shirt pocket, or belt for hands-free recording.
- **Neck Lanyard:** Wear the camera around your neck for easy access and portability.
- **Bike Mount:** Use the included mount to secure the camera to bicycle handlebars for outdoor activities.

Tiny Size, Big Potential

Compact to carry anywhere, anytime.



Figure 4: Versatile wearing options for the Losfom Z11 body camera.

Many Ways to Wear



▲
**Back
Clip**

▲
**Neck
strap**

▲
**Bike
mount**

Figure 5: The Losfom Z11 securely attached to a bicycle handlebar using the provided mount.

OPERATING INSTRUCTIONS

1. Power On/Off

- To power on, press and hold the Power button until the screen illuminates.
- To power off, press and hold the Power button until the device shuts down.

2. Recording Video and Taking Photos

The camera features dedicated buttons for video and photo capture.

- **Video Recording:** Press the Video button once to start recording. Press it again to stop. The screen will indicate recording status.
- **Photo Capture:** Press the Photo button once to take a still image.

Sharper. Smoother. **4K**.

Records every moment in 4K video

4K

2K

Figure 6: Visual comparison illustrating the enhanced clarity of 4K video recording.

Easy Control, Flexible Mounting

Quick Start, Steady Setup



Figure 7: The Losfom Z11's intuitive control buttons for easy operation.

3. Night Vision

The camera is equipped with 6 IR lights for enhanced night vision capabilities, allowing for clear recordings in low-light or total darkness.

- Refer to the on-screen menu or dedicated button (if available) to activate or deactivate night vision mode.
- Ensure no obstructions block the IR lights for optimal performance.

Always On, Always Ready

Capture Every Ride with Clarity



Figure 8: Night vision in action, capturing clear footage in dark environments.

4. Adjusting Camera Angle

The camera features a 180° rotating lens, allowing you to adjust the recording angle as needed. Gently pivot the top section of the camera to achieve the desired view.

5. Reviewing and Transferring Files

You can review recordings directly on the camera's 1.3-inch LCD screen or transfer them to a computer for larger viewing and storage.

- **On-Device Review:** Use the navigation buttons below the screen to browse and play back recorded videos and photos.
- **File Transfer:** Connect the camera to your computer using the provided USB cable. The camera will appear as a removable disk drive. You can then copy files directly from the Micro SD card to your computer. Alternatively, remove the Micro SD card and insert it into a card reader connected to your computer.

Night Vision, No Compromise

Record crisp video even in total darkness



Figure 9: The compact design of the Losfom Z11 allows for easy portability.

MAINTENANCE

- Battery Care:** To prolong battery life, avoid fully discharging the batteries frequently. Store them in a cool, dry place when not in use.
- Cleaning:** Use a soft, dry cloth to clean the camera body and lens. Avoid using harsh chemicals or abrasive materials.
- Storage:** Store the camera in a protective case or pouch to prevent scratches and damage. Keep it away from extreme temperatures and humidity.

TROUBLESHOOTING

Issue	Possible Solution
Camera does not power on.	Ensure batteries are fully charged and correctly inserted. Try using the spare battery.

Issue	Possible Solution
Cannot record video/take photos.	Check if a Micro SD card is inserted and has sufficient free space. Ensure the camera is not in playback mode.
Poor video quality.	Ensure the lens is clean. Check recording resolution settings (set to 4K for best quality). Ensure adequate lighting or activate night vision if in low light.
Files not transferring to computer.	Verify the USB cable connection. Try a different USB port or computer. Ensure the camera is powered on when connected.

SPECIFICATIONS

Feature	Detail
Brand	Losfom
Model Number	Z11
Video Capture Resolution	4K
Photo Sensor Technology	CMOS
Flash Memory Type	Micro SD
Screen Size	1.3 Inches
Special Features	HD Resolution, Portable, 6 IR Night Vision Lights, Dual Batteries
Item Weight	1.2 pounds
Package Dimensions	5.91 x 3.86 x 2.72 inches
Batteries	2 A batteries required (1400mAh Lithium)
Video Capture Format	MOV
Supported Audio Format	AAC
Connectivity Technology	Wired

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the official Losfom website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Related Documents - Z11

<p>Losfom</p> <p>MINIBODY CAMERA MODEL: Z01</p>  <p>User Manual</p>	<p><u>Losfom Z01 Mini Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom Z01 Mini Body Camera, detailing its features, basic operation, specifications, and troubleshooting.</p>
<p>Losfom</p> <p>WD1 Body Camera Model: WD1</p>  <p>User Manual</p>	<p><u>Losfom WD1 Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom WD1 Body Camera, detailing its features, operation, system settings, specifications, troubleshooting, and package contents. Learn how to use your WD1 camera for recording, photography, and more.</p>
 <p>User Manual</p>	<p><u>Losfom EM0 Body Camera User Manual</u></p> <p>Comprehensive user manual for the Losfom EM0 body camera, detailing its structure, operation, system settings, indicator lights, troubleshooting, specifications, and package contents. Learn how to use and maintain your Losfom EM0 device effectively.</p>