

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GEEZER](#) /

› [GEEZER AK96 Mechanical Gaming Keyboard User Manual](#)

GEEZER AK-96

GEEZER AK96 Mechanical Gaming Keyboard User Manual

Model: AK-96

INTRODUCTION

Thank you for choosing the GEEZER AK96 Mechanical Gaming Keyboard. This keyboard features a compact 96-key layout, pre-lubed red mechanical switches, and vibrant LED backlighting. Designed for both gaming and productivity, it offers a responsive typing experience and multi-system compatibility. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

Plug and Play

One USB cable for mechanical keyboard, do not need any extra software, super easy to connect to your PC/MAC

Win / iOS / Android



No Need
Batteries



Include USB To
Type-C Adapter

Image: The GEEZER AK96 Mechanical Gaming Keyboard, showcasing its compact layout and colorful backlighting.

SETUP INSTRUCTIONS

Package Contents:

- GEEZER AK96 Mechanical Gaming Keyboard
- USB Cable (Type-C to USB-A)
- USB to Type-C Adapter
- User Manual (this document)

Connecting the Keyboard:

1. Locate the USB Type-C port on the keyboard, typically on the top edge.
2. Connect the USB Type-C end of the provided cable to the keyboard.
3. Connect the USB-A end of the cable to an available USB port on your PC or Mac. If your device only has Type-C ports, use the included USB to Type-C adapter.
4. The keyboard is plug-and-play and should be recognized automatically by your operating system (Windows or Mac) without requiring additional drivers.




Image: Diagram showing the GEEZER AK96 keyboard connected to a PC, Laptop, and Mac using the USB cable and Type-C adapter.

Your browser does not support the video tag.

Video: An overview of the GEEZER AK96 Mechanical Gaming Keyboard, demonstrating its features and backlighting.

OPERATING INSTRUCTIONS

Backlight Control:

The AK96 keyboard features 17 built-in lighting modes and multi-color options, along with side lights for enhanced visual effects. Use the following key combinations to control the backlighting:

- **Fn + |**: Switch between 17 different backlight modes.
- **Fn + Enter**: Turn the backlight On/Off.
- **Fn + ↑ / ↓**: Adjust backlight brightness.
- **Fn + ← / →**: Change backlight speed.
- **Fn + L**: Control side atmosphere lights.

Multiple LED Effects Backlight

With 17 lighting effects to add a great atmosphere to the game



Image: The GEEZER AK96 keyboard displaying various LED backlight effects and key combinations for control.

Your browser does not support the video tag.

Video: A demonstration of the GEEZER AK96 Mechanical Gaming Keyboard's various LED lighting modes and effects.

Media Control and Volume Knob:

The keyboard is equipped with a dedicated volume knob and quick-access media keys for convenient control over your audio and media playback.

- **Volume Knob:** Rotate to adjust volume. Press to mute/unmute audio.
- **Fn + F1:** Media Player
- **Fn + F2:** Volume Down
- **Fn + F3:** Volume Up
- **Fn + F4:** Mute
- **Fn + F5:** Play to Suspend
- **Fn + F6:** Previous Track
- **Fn + F7:** Play / Pause
- **Fn + F8:** Next Track
- **Fn + F9:** Email
- **Fn + F10:** Web Home
- **Fn + F11:** My Computer

- **Fn + F12:** Calculator
- **Fn + PrtSc:** PrtSc (Print Screen)
- **Fn + SCRLK:** SCRLK (Scroll Lock)
- **Fn + Pause:** Pause
- **Fn + W:** Swap W, A, S, D and ↑, ↓, ←, → keys.
- **Fn + Win:** Lock/Unlock Windows key.



Image: The GEEZER AK96 keyboard highlighting the volume knob and a list of shortcut key functions.

Ergonomic Adjustments:

The keyboard features two adjustable-height kickstands on the underside. Flip these kickstands out to adjust the typing angle for maximum comfort during extended use. The non-slip rubber pads ensure stability.

Ergonomic Design for All-Day Use...

3 Angle Adjustments with the Kickstands



Image: The underside of the GEEZER AK96 keyboard, illustrating the adjustable kickstands and non-slip rubber pads.

MAINTENANCE

To ensure the longevity and optimal performance of your GEEZER AK96 Mechanical Gaming Keyboard, follow these maintenance guidelines:

- **Cleaning Keycaps:** Use a soft, damp cloth to wipe down the keycaps. For deeper cleaning, you may carefully remove keycaps (using a keycap puller, if available) and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- **Cleaning Switches:** Use compressed air to remove dust and debris from between the keycaps and around the switches. Avoid spraying liquids directly into the switches.
- **Cable Care:** Avoid sharp bends or kinks in the USB cable. Store the cable neatly when not in use to prevent damage.
- **General Care:** Keep the keyboard away from excessive moisture, extreme temperatures, and direct sunlight. Avoid dropping the keyboard or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter any issues with your GEEZER AK96 Mechanical Gaming Keyboard, please refer to the following common troubleshooting steps:

- **Keyboard Not Responding:**

- Ensure the USB cable is securely connected to both the keyboard and your computer.
- Try connecting the keyboard to a different USB port on your computer.
- If using the USB to Type-C adapter, ensure it is properly connected and try a different adapter if possible.
- Restart your computer.

- **Backlight Not Working or Incorrect:**

- Press **Fn + Enter** to toggle the backlight On/Off.
- Press **Fn + |** to cycle through different lighting modes.
- Adjust brightness using **Fn + ↑ / ↓**.
- Ensure your computer's USB port is providing sufficient power.

- **Keys Not Registering or Double-Typing:**

- Clean the affected key switch with compressed air to remove any debris.
- Ensure the keycap is properly seated on the switch.
- Test the keyboard on another computer to rule out software or driver issues.

- **Volume Knob Not Functioning:**

- Ensure the keyboard is properly connected.
- Check your computer's audio settings to ensure the volume is not controlled by another device or software.

If the issue persists after trying these steps, please contact GEEZER customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	AK-96
Layout	96-Key (96% layout)
Switch Type	Red Mechanical Switches (Pre-lubed)
Keycap Material	PBT
Backlighting	LED Colorful Backlit (17 modes) & 2-Side LED
Connectivity	USB Wired (USB-A to Type-C)
Compatibility	PC, Mac, Windows, Laptop, Smart TV, Tablet
Special Features	Volume Knob, Full Key Rollover, Ergonomic Design, Adjustable-height Kickstands, Hotkeys and Media Keys
Product Dimensions	15.35 x 5.51 x 1.18 inches
Item Weight	1.9 pounds
Color	White
Material	Plastic

WARRANTY AND SUPPORT

The GEEZER AK96 Mechanical Gaming Keyboard comes with a standard manufacturer's warranty. For detailed

information regarding warranty coverage, terms, and conditions, please refer to the product packaging or contact GEEZER customer support directly.

For technical support, troubleshooting assistance, or any product-related inquiries, please visit the official GEEZER website or contact their customer service team. Contact information can typically be found on the product packaging or on the brand's official online store.