

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR 880C Professional Cordless Hair Clippers User Manual](#)

VGR 880C

VGR 880C Professional Cordless Hair Clippers

User Manual

INTRODUCTION

This manual provides essential information for the safe and effective use of your VGR 880C Professional Cordless Hair Clippers. Please read all instructions carefully before first use and retain this manual for future reference.

SAFETY INFORMATION

To reduce the risk of electric shock, injury, or damage to the appliance, always follow these basic safety precautions:

- Always unplug the trimmer before cleaning or storing.
- Keep the trimmer away from water sources. Do not use it near bathtubs, showers, basins, or other vessels containing water.
- Avoid using the trimmer on infants or near the face without proper guard combs.
- Always use the trimmer with caution to avoid skin irritation or eye injury.
- Follow the manufacturer's instructions for cleaning and maintenance.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x VGR 880C Hair Clipper
- 10 x Guide Combs (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm)
- 1 x Lubricating Oil
- 1 x Cleaning Brush

- 1 x USB Charging Cable
- 1 x Type-C Charging Cable
- 1 x Charging Dock



Image: The VGR 880C hair cutting kit with all included accessories.




Image: Visual representation of 'What's Included' with the VGR 880C.

PRODUCT FEATURES

- **Professional Blades:** Equipped with durable ceramic and MIM (Metal Injection Molding) blades for smooth, precise, and cool cutting performance.
- **Adjustable Taper Lever:** Integrated taper lever allows for fine-tuning cutting lengths from 0.8mm to 2mm without a guide comb.
- **High-Performance Motor:** Features an advanced outer rotor BLDC motor operating at 7200 RPM for strong, consistent power and low noise.
- **Long-Lasting Battery:** Powered by a 2500mAh lithium battery, providing up to 150 minutes of cordless operation after a 3-hour charge.
- **LED Indicator:** Integrated LED display shows battery status and charging progress.
- **Dual Charging Options:** Convenient charging via USB or Type-C cable, directly or using the included charging dock.
- **Comprehensive Guide Combs:** Includes 10 guide combs ranging from 1.5mm to 25mm for various haircut styles and lengths.
- **Ergonomic Design:** Compact body with an anti-slip textured grip for comfortable handling during extended use.




Image: Detail of the ceramic and MIM blades for precise cutting.



Image: External Rotor BLDC Motor for powerful and quiet operation.

SETUP

1. **Unpack:** Carefully remove all components from the packaging. Inspect the clipper and accessories for any damage.
2. **Initial Charge:** Before first use, fully charge the clipper. Refer to the 'Charging' section for detailed instructions.
3. **Lubricate Blades:** Apply a few drops of the included lubricating oil to the blades. Turn on the clipper for a few seconds to distribute the oil, then wipe off any excess. This ensures optimal performance and blade longevity.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button located on the front of the clipper to turn it on or off.
2. **Attaching Guide Combs:** Select the desired guide comb (1.5mm to 25mm). Align the comb with the clipper blade and push it firmly until it clicks into place. Ensure it is securely attached before use.
3. **Adjusting Taper Lever:** The taper lever on the side of the clipper allows for fine adjustments to cutting length without a comb, from 0.8mm (fully closed) to 2mm (fully open). Use this for blending and precise detailing.
4. **Hair Cutting:** For best results, use the clipper on clean, dry hair. Start with a longer guide comb than desired and gradually reduce the length. Move the clipper against the direction of hair growth for an even cut.
5. **Removing Guide Combs:** Gently pull the comb away from the blade to remove it.



Image: VGR 880C in use for hair trimming.

CUTTING GUIDES

5-LEVEL UNLIMITED

Without a guide comb: 0.8mm to 2mm




Image: Taper lever adjustment for precise cutting lengths.

GUIDE COMBS

The length of the cut is shown on the guide combs



Image: Guide combs for various hair lengths.

CHARGING

The VGR 880C hair clipper is equipped with a 2500mAh lithium battery, providing up to 150 minutes of cordless operation. A full charge takes approximately 3 hours.

- 1. Charging Methods:** You can charge the clipper directly using the USB or Type-C cable, or by placing it on the included charging dock.
- 2. LED Indicator:** The integrated LED display will show the charging status. It typically indicates battery percentage or a charging animation. Once fully charged, the indicator will show 100% or a steady light.
- 3. Power Source:** Connect the USB or Type-C cable to a compatible USB power adapter (not included) or a computer USB port.

USB CHARGING

2500 mAh lithium battery

3
Hours
charging

150
Minutes
working



Image: VGR 880C charging on its dock with dual charging options.




Image: USB charging details and battery information.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your VGR 880C hair clipper.

- Cleaning Blades:** After each use, turn off and unplug the clipper. Use the included cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, the blades can be rinsed under running water (ensure the clipper body remains dry). Allow blades to air dry completely before reattaching or storing.
- Oiling Blades:** After cleaning and drying, apply 1-2 drops of the provided lubricating oil across the top of the blades. Turn on the clipper for a few seconds to distribute the oil evenly. Wipe off any excess oil with a soft cloth. This should be done after every few uses or as needed to maintain smooth operation.
- Storage:** Store the clipper and its accessories in a dry, cool place, away from direct sunlight and moisture. Use the original packaging or a suitable storage case to protect the blades.

TROUBLESHOOTING

If you encounter any issues with your VGR 880C hair clipper, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully.
Clipper pulls hair or cuts unevenly.	Blades are dull or dirty; insufficient oil; guide comb not properly attached.	Clean and oil the blades. Ensure guide comb is securely attached. If blades are dull, consider professional sharpening or replacement.
Clipper makes unusual noise.	Blades require lubrication; foreign object caught in blades.	Clean and oil the blades. Inspect for any obstructions and carefully remove them.
Charging indicator not working.	Charging cable or adapter faulty; poor connection.	Check cable and adapter. Ensure secure connection to clipper and power source. Try a different cable or adapter.

SPECIFICATIONS

Feature	Detail
Model	VGR 880C
Blade Material	Ceramic and MIM (Metal Injection Molding)
Motor Type	External Rotor BLDC Motor
Motor Speed	7200 RPM
Battery Type	Lithium Ion
Battery Capacity	2500mAh
Cordless Usage Time	Up to 150 minutes
Charging Time	Approximately 3 hours

Feature	Detail
Charging Interface	USB, Type-C (via charging dock or direct)
Taper Lever Adjustment	0.8mm - 2mm
Guide Comb Lengths	1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm
Overall Adjustable Cutting Lengths	0.8mm - 27mm (with guide combs)
Power Source	Battery Powered
Manufacturer	VGR
Country of Origin	China

WARRANTY AND SUPPORT

The VGR 880C Professional Cordless Hair Clippers come with a **1-Year Warranty** from the date of purchase, covering manufacturing defects. For technical assistance, product inquiries, or warranty claims, please contact VGR customer support. We aim to provide **24-hour support** to address your needs.




Image: VGR brand and customer support information.