

## TABWEE T80

# TABWEE T80 Tablet User Manual

Model: T80 | Brand: TABWEE

### 1. INTRODUCTION

The TABWEE T80 Tablet is a versatile device designed for various uses, from entertainment to productivity. Featuring a 10-inch display with 1200\*800 pixels per inch resolution, it runs on Android 15 and is powered by a Unisoc processor. With 128 GB of flash memory, it offers ample space and performance for your daily tasks. The tablet boasts a 6000mAh battery, providing up to 72 hours of average battery life.



This image displays the TABWEE T80 Tablet, showcasing its front screen with highlighted features such as 5G WiFi, 6000mAh battery, 1080P resolution, GeminiAI, Android 15, and storage capacity. The rear view of the tablet, including its camera module, is also visible.

## 2. SETUP GUIDE

### 2.1 Unboxing

Carefully remove all components from the packaging: the TABWEE T80 Tablet, charging cable, and power adapter.

### 2.2 Charging the Tablet

Before first use, fully charge the tablet. Connect the charging cable to the tablet's charging port and the other end to the power adapter. Plug the adapter into a wall outlet. The charging indicator on the screen will show the charging status.

### 2.3 Powering On/Off

- **To Power On:** Press and hold the power button located on the side of the tablet until the screen lights up.
- **To Power Off:** Press and hold the power button, then select 'Power off' from the options that appear on the

screen.

## 2.4 Initial Setup

Upon first power-on, follow the on-screen prompts to complete the initial setup. This includes selecting your language, connecting to a Wi-Fi network, setting up your Google account, and configuring security options like a PIN or pattern.

## 3. OPERATING INSTRUCTIONS

### 3.1 Basic Navigation

The TABWEE T80 features a responsive touchscreen. Use the following gestures for navigation:

- **Tap:** To select an item, open an app, or confirm an action.
- **Swipe:** To scroll through pages, menus, or switch between home screens.
- **Pinch:** To zoom in or out on images, maps, or web pages.
- **Long Press:** To access contextual menus or move app icons.

### 3.2 App Management

Install new applications from the Google Play Store. To uninstall an app, long-press its icon on the home screen or in the app drawer, then drag it to the 'Uninstall' option. Manage app permissions and notifications through the Settings menu.

### 3.3 Connectivity (Wi-Fi & Bluetooth)

- **Wi-Fi:** Access Wi-Fi settings via the Quick Settings panel (swipe down from the top of the screen) or the main Settings app to connect to available networks.
- **Bluetooth:** For Bluetooth devices, enable Bluetooth in Settings, scan for devices, and pair with your desired accessory like headphones or speakers.

### 3.4 Camera Usage

The tablet includes a camera. Open the Camera application to capture photos and videos. Select modes such as photo, video, or panorama. Adjust settings like flash, timer, and resolution within the camera app.

### 3.5 Storage Management

Monitor your storage usage in the Settings menu under 'Storage'. Regularly clear cache, delete unnecessary files, and uninstall unused apps to maintain optimal performance. The tablet has 128 GB of internal storage and supports expandable storage via a microSD card (card not included).

## 4. MAINTENANCE AND CARE

### 4.1 Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics. Avoid harsh chemicals or abrasive materials.

## 4.2 Battery Care

To prolong battery life, avoid exposing the tablet to extreme temperatures (very hot or very cold). Do not leave the tablet fully charged or fully discharged for extended periods. It is recommended to keep the battery level between 20% and 80% for optimal longevity.

## 4.3 Software Updates

Regularly check for system updates in the Settings menu under 'System' or 'About tablet'. Updates provide performance improvements, security patches, and new features. Ensure your tablet is connected to Wi-Fi and has sufficient battery before starting an update.

## 4.4 Storage Optimization

Periodically review your installed applications and media files. Uninstall apps you no longer use and transfer large files to cloud storage or an external drive to free up internal memory and improve performance.

# 5. TROUBLESHOOTING

This section addresses common issues you might encounter with your TABWEE T80 Tablet.

## 5.1 Tablet Not Turning On

- **Solution:** Ensure the tablet is sufficiently charged. Connect it to the charger and wait a few minutes before attempting to power it on again. If it still doesn't turn on, try holding the power button for 10-15 seconds for a forced restart.

## 5.2 Wi-Fi Connectivity Issues

- **Solution:** Check if Wi-Fi is enabled in settings. Restart your Wi-Fi router. Forget the network on your tablet and reconnect. Ensure you are within range of the Wi-Fi signal.

## 5.3 Apps Crashing or Freezing

- **Solution:** Close and reopen the app. Clear the app's cache and data in Settings > Apps. If the issue persists, uninstall and reinstall the app. Ensure your tablet's software is up to date.

## 5.4 Slow Performance

- **Solution:** Close background applications. Clear cached data. Restart the tablet. Consider performing a factory reset as a last resort, but back up all important data first.

# 6. TECHNICAL SPECIFICATIONS



Feature	Specification
Brand	TABWEE
Model Name	T80

Operating System	Android 15
Standing Screen Display Size	10 Inches
Max Screen Resolution	1200*800 Pixels Per Inch
Processor Brand	Unisoc
Flash Memory Size	128 GB
Average Battery Life	72 Hours
Item Weight	13.9 ounces
Product Dimensions	9 x 0.7 x 6 inches
Batteries	1 9V battery required (included)

## 7. WARRANTY AND SUPPORT

For technical assistance, warranty inquiries, or customer support, please refer to the contact information provided with your purchase. You may also visit the official TABWEE support website for further assistance and resources. Keep your proof of purchase for warranty claims.

### Related Documents - T80

	<p><a href="#">TABWEE T80 User Manual and Warranty Information</a></p> <p>Comprehensive user manual and warranty details for the TABWEE T80 tablet, covering activation, features, safety, maintenance, and regulatory compliance.</p>
	<p><a href="#">TABWEE W90 Tablet - Produktdatenblatt und Reparierbarkeitsinformationen</a></p> <p>Offizielles Produktdatenblatt für das TABWEE W90 Tablet, das technische Spezifikationen, Energieeffizienz und den Reparierbarkeitsindex gemäß der EU-Verordnung 2023/1669 detailliert beschreibt.</p>

## TABWEE T90 Tablet Product Data Sheet - Technical Specifications & Energy Labeling

## TABWEE T90 Tahvelarvuti Toote Teabeleht

FCC Part 22/24 Test Report for TABWEE W90 Tablet Computer