

IAGREEA BFM001

IAGREEA BFM001 Baby Food Maker Instruction Manual

Brand: [IAGREEA](#) | Model: [BFM001](#)

[Introduction](#)

[Safety Precautions](#)

[Product Components](#)

[Setup](#)

[Operation](#)

[Cleaning & Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. WELCOME TO YOUR IAGREEA BFM001 BABY FOOD MAKER

The IAGREEA 9-in-1 glass baby food maker combines a steamer and blender in one device. With preset programs for vegetables, fruits, beans, fish, chicken, beef, and eggs, this baby food processor makes healthy homemade meals fast and easy for new parents.

- **All-in-One Functionality:** Steams and blends in one device, offering 9 smart programs for diverse ingredients.
- **Premium Materials:** Features a durable glass bowl and 6-piece 3D stainless steel blades, ensuring no plastic contact with food.
- **Nutrient Preservation:** Utilizes gentle water-bath steaming to lock in vitamins and minerals, preserving natural taste and texture.

- **Certified Safety:** CPC certified, BPA-free, lead-free, and phthalate-free for your baby's health.
- **Thoughtful Design:** Includes features like 2-24 hour reservation, self-cleaning, and touch screen control for convenience.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before using the IAGREEA BFM001 Baby Food Maker to prevent injury or damage.

- Always read the entire instruction manual carefully before using the product.
- Ensure the power supply voltage (120V~, 60Hz) matches the product's rated voltage.
- Do not immerse the main unit in water. Avoid water contact with the charging port and the bottom of the machine to prevent damage.
- Be extremely careful of steam during operation and when opening the lid to avoid burns.
- Avoid contact with any moving parts (e.g., blades) while the machine is running.
- Do not use the product if the power cord or plug is damaged. Contact customer support immediately.
- Keep the appliance and its cord out of reach of children.
- Ensure all parts are correctly assembled and locked into place before operation.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals to clean the product.
- Always allow hot food to cool to a safe temperature before serving to your child.
- The transparent outer wall of the host is made of BPA-free plastic. The inner mixing bowl is glass.
- One batch can produce approximately 200mL - 250mL of baby food.
- **CARE INSTRUCTIONS:** Water stains may appear on the stainless steel base due to mineral deposits from tap water, cleaning, or environmental factors. To prevent this, use distilled or softened water. After each use, wipe the base dry with a soft cloth. Regularly clean the water boiler with white vinegar or a suitable cleaner to maintain performance and appearance.

3. PRODUCT COMPONENTS

Familiarize yourself with the various parts of your IAGREEA BFM001 Baby Food Maker:

- **Main Unit:** The base of the appliance containing the motor, heating plate, and control panel.
- **Main Unit Cover:** Protects the motor and internal components.
- **Mixing Bowl:** A 300mL high borosilicate glass container for steaming and blending ingredients.
- **Knife Assembly:** Features six stainless steel blades for efficient and smooth pureeing.
- **Cup Holder:** Secures the mixing bowl to the main unit and provides handles for safe handling.

- **Cup Cover:** Stainless steel cover for the mixing bowl to prevent spills.
- **Control Panel:** Intuitive touch screen interface for selecting functions and settings.



Figure 1: Exploded view showing main unit cover, cup cover, knife assembly, mixing bowl, cup holder, and main unit.

No Plastic Touching Food

Food-Safe Stainless Steel & Glass, BPA-Free

CPC



Figure 2: Illustrates the food-safe stainless steel blades and glass bowl, ensuring no plastic contact with food.



Figure 3: Highlights the use of 100% food-grade glass jar and stainless steel blades for safety.

4. SETUP

Unboxing and First Use

Carefully unpack all components from the packaging. Before initial use, wash all removable parts (mixing bowl, knife assembly, cup cover, cup holder) with warm soapy water, rinse thoroughly, and dry completely.



Figure 4: Shows all included accessories: baby bib, product manual, spoon, spork, cleaning brush, spatula, power cord, and recipes.

Assembly

1. Place the main unit on a stable, flat, and dry surface.
2. Ensure the mixing bowl is clean and dry.
3. Carefully insert the knife assembly into the center of the mixing bowl.
4. Place the mixing bowl (with the knife assembly) into the cup holder, ensuring it sits securely.
5. Position the assembled cup holder and mixing bowl onto the main unit.
6. Place the cup cover on top of the mixing bowl, ensuring it is properly sealed.
7. Plug the power cord into the machine's charging port and then into a suitable power outlet.

Video 1: This video demonstrates the unboxing and initial assembly of the IAGREEA Baby Food Maker, showing all included components and how to put them together.

5. OPERATION

Basic Cooking Steps

1. **Add Water:** Fill the main unit's water reservoir with purified water up to the indicated water level (250ml MAX).
2. **Prepare Ingredients:** Peel, core, and cut large or long ingredients into small, uniform pieces

(approximately 1 cm cubes) to ensure even cooking and blending.

3. **Load Ingredients:** Place the prepared food into the mixing bowl and add pure water as needed, depending on the desired consistency.
4. **Assemble Machine:** Place the mixing bowl with ingredients and knife assembly into the main unit, then secure the cup cover.
5. **Select Function:** Use the "Menu" button on the touch screen control panel to select the desired cooking program (Veg, Fruit, Fish, Meat, Bean, Rice Paste, Warm Milk, Egg, Reheat).
6. **Select Stage:** Choose the appropriate age-specific stage (Fine 4-6M, Medium 6-9M, Coarse 9M+) using the "Stage" button for the desired food texture.
7. **Start Cooking:** Press the "Start/Cancel" button to begin the cooking process. The machine will automatically steam and blend according to the selected program.
8. **Serve:** Once the program finishes, unplug the power cable, carefully remove the mixing bowl, and pour the freshly prepared baby food into a serving bowl.




Figure 5: Visual guide illustrating the four basic steps of operating the baby food maker, from adding water to serving.

Functions and Age Stages

The IAGREEA BFM001 offers 9 specialized cooking programs and 3 age-specific stages to cater to your baby's developmental needs:



Figure 6: Displays the 9 cooking programs (Veg, Fruit, Bean, Fish, Meat, Rice Paste, Warm Milk, Egg, Reheat) with their default times and adjustable time ranges.



Figure 7: Illustrates the three age-specific stages: Stage 1 (4-6 months) for smooth fruit puree, Stage 2 (6-9 months) for thick creamy puree, and Stage 3 (9 months+) for granular food supplements.

Pulse Function

For manual blending or achieving specific textures, press and hold the "Pulse" button. The motor will run for 12 seconds per cycle. Release the button to stop. After 4 consecutive cycles, the machine will automatically pause for 1 minute to prevent overheating.

Reservation Function

The "Preset" button allows you to set a delayed start time for cooking, ranging from 2 to 24 hours. Press the button to increase the time by 1 hour, or press and hold to adjust quickly.

Important Tips for Best Results

- Ensure beans are fully cooked before processing.
- Cut all large ingredients into 1 cm cubes for optimal stirring and blending.
- For smoother purees, add a small amount of water, breast milk, or formula.



Figure 8: Visual reminder to ensure beans are fully cooked and to cut ingredients into 1 cm cubes for fine blending.

Video 2: This video from IAGREEA Kitchen demonstrates how to prepare Egg Custard using the baby food maker.

Video 3: This video from IAGREEA Kitchen demonstrates how to prepare Beef & Mashed Potatoes puree using the baby food maker.

Video 4: This video from IAGREEA Kitchen demonstrates how to prepare Spinach Puree using the baby food maker.

6. CLEANING & MAINTENANCE

Proper cleaning and maintenance are essential for the longevity and hygienic operation of your IAGREEA BFM001 Baby Food Maker.

Removable Parts

- The mixing bowl, knife assembly, cup cover, and cup holder are dishwasher-safe for convenient cleaning.
- Alternatively, wash these parts with warm, soapy water, rinse thoroughly, and allow them to air dry.
- Use the provided cleaning brush to reach and clean any hidden corners or crevices.



Figure 9: Shows dishwasher-safe accessories and highlights the design with no hidden corners for easy, residue-free cleaning.

Main Unit

- Wipe the main unit with a soft, damp cloth. **Do not immerse the main unit in water or any other liquid.**
- For water stains on the stainless steel heating plate, use distilled or softened water to prevent mineral deposits. After each use, wipe the base dry with a soft cloth.
- Regularly clean the water boiler with white vinegar or a suitable descaling cleaner to maintain performance and appearance.

7. TROUBLESHOOTING

If you encounter any issues with your IAGREEA BFM001 Baby Food Maker, please refer to the following common problems and solutions:

Issue	Possible Cause / Solution
-------	---------------------------

Issue	Possible Cause / Solution
Machine does not turn on.	Ensure the power cord is securely plugged into both the machine and a working power outlet. Check for power outages.
Food not blending smoothly or uneven texture.	Ensure ingredients are cut into small, uniform pieces (approx. 1 cm cubes). Add sufficient liquid (water, breast milk, formula) to achieve desired consistency. Do not overload the mixing bowl.
Steam not generating or insufficient.	Check the water level in the main unit's reservoir. Ensure it's filled to the 250ml mark. Use distilled or softened water to prevent mineral buildup.
Unusual or excessive noise during operation.	The product will produce some noise (65-75dB) due to the motor's nature. If the noise is excessive or unusual, ensure all parts are correctly assembled. If the problem persists, contact customer support.
Metal shavings found in food.	Immediately discontinue use. This indicates a potential defect with the blade assembly. Contact customer support for assistance and replacement.
Water stains on the heating plate.	These are mineral deposits. Use distilled or softened water. Clean regularly with white vinegar or a descaling solution.

**Please make sure the beans are fully cooked.
Cut the large pieces of ingredients into 1 cm cubes.
Otherwise, the mixture will not be stirred finely.**



Figure 10: Indicates the normal operating noise level of the machine is between 65-75dB.

8. PRODUCT SPECIFICATIONS

- **Product Dimensions:** 9.02 x 7.71 x 11 inches
- **Item Weight:** 5.46 pounds
- **Item Model Number:** BFM001
- **Stirring Power:** 150W
- **Heating Power:** 450W

- **Rated Voltage:** 120V~
- **Rated Frequency:** 60Hz
- **Mixing Bowl Capacity:** 300mL (High borosilicate glass)
- **Water Reservoir Capacity:** 250mL
- **Materials:** Food-grade plastic (BPA-free) for outer wall, high borosilicate glass for mixing bowl, stainless steel for blades.



Figure 11: Front view of the IAGREEA BFM001 Baby Food Maker, highlighting its compact dimensions.

9. WARRANTY & SUPPORT

IAGREEA is committed to providing high-quality products and excellent customer service. Your satisfaction is our priority.

- **Customer Service:** For any questions, concerns, or assistance with your IAGREEA BFM001 Baby Food Maker, please do not hesitate to contact our dedicated support team.
- **Replacement Service:** If you find any damaged or missing parts upon receiving your product, please contact us immediately for a replacement.

Contact Email: support@iagreemall.com



Figure 12: Illustrates the 24-hour customer service and replacement service available for damaged or missing parts.