

MIATONE QBOX

MIATONE QBOX Bluetooth Speaker User Manual

Model: QBOX

1. INTRODUCTION

Thank you for purchasing the MIATONE QBOX Bluetooth Speaker. This portable speaker is designed to deliver powerful 360-degree sound with enhanced bass, featuring IPX7 waterproofing for versatile use. It supports TWS (True Wireless Stereo) pairing for an immersive audio experience, AUX connectivity for non-Bluetooth devices, and includes a built-in microphone for hands-free calls. Please read this manual carefully to ensure proper use and optimal performance of your speaker.

2. PACKAGE CONTENTS

- MIATONE QBOX Bluetooth Speaker x1
- USB Charging Cable x1
- AUX Cable x1
- User Manual x1

3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Image: Front, side, back, and bottom views of the MIATONE QBOX Bluetooth Speaker, highlighting button layout and port locations.

Controls and Ports:

- **Power Button:** Press and hold to power on/off. Short press for playback control.
- **Volume Up / Next Track Button:** Short press to increase volume. Long press to skip to the next track.
- **Volume Down / Previous Track Button:** Short press to decrease volume. Long press to go to the previous track.
- **Play/Pause / Call Button:** Short press to play/pause music. Press to answer/end calls. Long press to reject calls.
- **Mode Button (M):** Press to switch between Bluetooth and AUX modes.
- **USB-C Charging Port:** For charging the speaker.
- **AUX-in Port:** For wired audio connection.
- **LED Indicator:** Displays power, charging, and Bluetooth status.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's USB-C port and a power adapter (not included). The LED indicator will show charging status and turn off when fully charged. A full charge takes approximately 3 hours.

4.2 Power On/Off

- **Power On:** Press and hold the Power button for 2-3 seconds until the LED indicator lights up and you hear a power-on tone.
- **Power Off:** Press and hold the Power button for 2-3 seconds until the LED indicator turns off and you hear a power-off tone.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (LED indicator will flash blue). If not, press the 'M' button to switch to Bluetooth mode.
2. Enable Bluetooth on your device (smartphone, tablet, PC).
3. Search for 'MIATONE QBOX' in your device's Bluetooth settings and select it to connect.
4. Once connected, the LED indicator will turn solid blue, and you will hear a confirmation tone.

4.4 TWS (True Wireless Stereo) Pairing

For an enhanced stereo experience, you can pair two MIATONE QBOX speakers together.



Image: Two MIATONE QBOX speakers wirelessly connected to a smartphone, illustrating the TWS stereo pairing function.

1. Ensure both QBOX speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the Power button. The speaker will enter TWS pairing mode, indicated by a flashing LED.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone, and the LED on the primary speaker will flash blue, while the secondary speaker's LED will be solid blue.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 4.3.
5. To disconnect TWS, double-press the Power button on either speaker.

4.5 AUX Connection

Use the provided 3.5mm AUX cable to connect the speaker to non-Bluetooth devices like TVs or CD players.

1. Connect one end of the AUX cable to the speaker's AUX-in port.
2. Connect the other end to the audio output jack of your device.
3. The speaker will automatically switch to AUX mode, or you may need to press the 'M' button to select AUX mode.

5. OPERATING INSTRUCTIONS

5.1 Music Playback

- **Play/Pause:** Short press the Play/Pause button.
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.

5.2 Call Functions

When connected via Bluetooth to a smartphone, you can manage calls using the speaker's built-in microphone.

- **Answer Call:** Short press the Play/Pause button.

- **End Call:** Short press the Play/Pause button during a call.
- **Reject Call:** Long press the Play/Pause button when an incoming call rings.

6. MAINTENANCE

To ensure the longevity and optimal performance of your MIATONE QBOX speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or harsh chemicals.
- **Water Resistance (IPX7):** The speaker is IPX7 waterproof, meaning it can be submerged in up to 1 meter of water for 30 minutes. Ensure the charging port and AUX port covers are securely closed before exposing the speaker to water. After exposure to water, dry the speaker thoroughly before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.



Image: The MIATONE QBOX speaker in water, showcasing its IPX7 waterproof capability.

7. TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker fully.

Problem	Possible Cause	Solution
No sound	Volume too low; Incorrect mode; Device not connected	Increase volume on speaker and device. Ensure correct mode (Bluetooth/AUX). Re-pair Bluetooth or check AUX cable connection.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is flashing blue. Move speaker closer to device. Turn off other Bluetooth devices.
TWS pairing fails	Speakers already connected to other devices	Disconnect both speakers from any other Bluetooth devices before initiating TWS pairing.
Poor sound quality	Low battery; Device too far; Audio source quality	Charge speaker. Move device closer. Try a different audio source.

8. SPECIFICATIONS

Feature	Detail
Brand	MIATONE
Model	QBOX
Speaker Max Output	16 Watts (2 x 8W drivers)
Connectivity Technology	Bluetooth 5.0
Audio Output Mode	Stereo
Speaker Type	Portable Speaker
Special Features	Stereo Pairing (TWS), Portable, Built-in Microphone, Lightweight, Waterproof (IPX7), Enhanced Bass
Recommended Uses	For Computers, Smartphones/Tablets, TVs
Color	Black
Waterproof Rating	IPX7
Charging Time	Approximately 3 Hours
Playback Time	Up to 12 hours (at 50% volume)
Dimensions (D x W x H)	7 x 7 x 10 cm
Origin	China

9. WARRANTY AND SUPPORT

Your MIATONE QBOX Bluetooth Speaker comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

The warranty does not cover:

- Damage caused by misuse, abuse, accident, or negligence.
- Normal wear and tear.
- Unauthorized repairs or modifications.

For warranty claims, technical support, or any questions regarding your product, please contact MIATONE customer service through the retailer where you purchased the product or visit our official website for contact information.