

Boult W60

GOBOULT W60 True Wireless Earbuds User Manual

Model: W60 | Brand: Boult

INTRODUCTION

Welcome to the user manual for your new GOBOULT W60 True Wireless Earbuds. These earbuds are designed to provide a superior audio experience with features like extended playtime, environmental noise cancellation, and ultra-low latency. This manual will guide you through the setup, operation, and maintenance of your device to ensure optimal performance.



Image: GOBOULT W60 True Wireless Earbuds in their green charging case, showcasing the product's design.

WHAT'S IN THE BOX

Your GOBOULT W60 package includes the following items:

- GOBOULT W60 True Wireless Earbuds
- Wireless Charging Case
- Extra Pair of Eartips (for customized fit)
- Type-C Fast Charging Cable
- User Manual (this document)
- Warranty Card

PRODUCT FEATURES

The GOBOULT W60 earbuds are equipped with advanced features for an enhanced audio experience:

- **60 Hours Playtime:** Enjoy extended listening sessions with the combined battery life of the earbuds and charging case.
- **Quad Mic ENC:** Environmental Noise Cancellation with four microphones ensures crystal-clear calls by filtering out ambient noise.
- **Bluetooth 5.4:** Provides faster pairing, stable connectivity, and energy-efficient performance.
- **50ms Ultra-Low Latency:** Ideal for gaming and video streaming, ensuring audio and video synchronization.
- **Voice Assistant Enabled:** Supports Google Assistant and Siri for hands-free control.
- **Type-C Fast Charging:** Quick charging capability to get you back to your music faster.
- **Compact & Pocket-Friendly Design:** Lightweight and easy to carry for daily use and travel.
- **IPX5 Water Resistant:** Sweatproof and splashproof design for durability during workouts or light rain.
- **10mm Dynamic Drivers:** Deliver punchy bass and immersive sound.



Image: An overview of key features of the GOBOULT W60 earbuds, highlighting 60 hours playtime, ZEN Quad Mic ENC, Lightning Fast Charging, Pocket Friendly design, Made in India, Bluetooth 5.4, and 50ms Ultra Low Latency.

IPX5

Water Resistant




Image: Demonstrates the IPX5 water resistance, indicating sweatproof and splashproof capabilities, and the voice assistant integration with examples for Google Assistant and Siri.

SPECIFICATIONS

Feature	Detail
Model Name	W60 (AirBass)
Connectivity Technology	Bluetooth 5.4, Wireless
Bluetooth Range	10 Metres
Audio Driver Size	10 Millimetres
Audio Latency	45 Milliseconds (Ultra-low latency mode: 50ms)
Noise Control	Passive Noise Cancellation, Quad Mic ENC

Playtime (Total)	Up to 60 Hours (with charging case)
Charging Time (Case)	10 Minutes for significant playtime
Headphones Jack	Type-C Fast Charging Jack
Water Resistance Level	IPX5 (Water Resistant, Sweatproof, Splashproof)
Control Type	Touch Controls, Google Assistant, Siri
Item Weight	52 Grams
Product Dimensions	6 x 2.7 x 5.3 cm
Battery Type	Lithium Polymer (included)
Country of Origin	India

SETUP

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged.

1. Connect the provided Type-C charging cable to the charging port on the case.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator on the case will show charging status. Once fully charged, the indicator will change or turn off.
4. Place the earbuds into the charging case. They will automatically begin charging.

Note: A 10-minute charge can provide several hours of playtime.

60 hrs Massive Playtime



Type-C
Lightning 
Fast Charging

10 mins charge
4 hrs playtime

Image: Illustrates the Type-C fast charging port on the case and highlights the 60 hours of massive playtime, with a note that 10 minutes of charge provides 4 hours of playtime.

2. Pairing with Your Device

1. Open the charging case. The earbuds will automatically enter pairing mode (indicated by flashing LED lights on the earbuds).
2. On your smartphone or Bluetooth-enabled device, go to Bluetooth settings.
3. Search for available devices and select "GOBOULT W60" from the list.
4. Once connected, the LED indicators on the earbuds will stop flashing or turn off.
5. The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

📶 New Gen

Bluetooth 5.4

Blink & pair™
instantly

SBC & AAC
codec
supported

Drop-free
stable
connection



Image: Highlights the new generation Bluetooth 5.4 technology, emphasizing instant "Blink & pair" functionality, support for SBC & AAC codecs, and a drop-free stable connection.

OPERATING INSTRUCTIONS

Touch Controls

The GOBOULT W60 earbuds feature intuitive touch controls for easy management of music, calls, and voice assistant:

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause Music	Single Tap	Single Tap
Next Track	Double Tap	Double Tap
Previous Track	Triple Tap	Triple Tap
Answer/End Call	Single Tap	Single Tap

Reject Call	Long Press (2 seconds)	Long Press (2 seconds)
Activate Voice Assistant	Long Press (3 seconds)	Long Press (3 seconds)
Toggle Gaming Mode	Quad Tap	Quad Tap

Tap to Command

User-
friendly
touch
controls

Seamless
multitasking



Image: Illustrates the "Tap to Command" feature, highlighting user-friendly touch controls and seamless multitasking capabilities of the earbuds.

Calling

The Quad Mic ENC system ensures clear communication during calls:

- **Answering/Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Long press either earbud for 2 seconds.
- The Environmental Noise Cancellation (ENC) actively reduces background noise for both you and the person on the other end.

ZEN™ Quad Mic ENC

Environmental
Noise Cancellation

4 Mics 
to filter noise



Crystal Clear
Calling 

Say it once, say it clear

Image: Focuses on the ZEN Quad Mic ENC technology, showing the four microphones designed to filter noise for crystal clear calling.

Gaming Mode (Ultra-Low Latency)

Activate gaming mode for a synchronized audio-visual experience during gaming or video playback:

- **Activation:** Quad tap either earbud to toggle gaming mode on/off.
- This mode reduces audio latency to 50ms, minimizing delay between on-screen action and sound.

50ms

Ultra Low Latency



Lightning-fast response for smooth, lag-free play.



Combat™ Gaming



Precision-tuned audio built for intense combat zones

Image: Illustrates the 50ms Ultra Low Latency feature, showing its benefit for smooth, lag-free play and precision-tuned audio for intense combat zones in gaming.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove eartips and clean them with mild soap and water if necessary, ensuring they are completely dry before reattaching.
- Use a cotton swab or a small, soft brush to gently clean the charging contacts on both the earbuds and the case.
- Avoid using abrasive materials, alcohol, or chemical cleaners.

Storage

- When not in use, always store the earbuds in their charging case to protect them and keep them charged.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your GOBOULT W60 earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Turn off and on Bluetooth on your device.◦ Forget "GOBOULT W60" from your device's Bluetooth list and re-pair.◦ Place earbuds back in the case, close, wait 5 seconds, then open again.
Only one earbud working	<ul style="list-style-type: none">◦ Ensure both earbuds are charged.◦ Place both earbuds back in the case, close the lid, and then open it again to reset the connection.◦ Try re-pairing the earbuds with your device.
Low volume or poor sound quality	<ul style="list-style-type: none">◦ Adjust volume on your connected device.◦ Clean the earbud mesh and eartips to remove any debris.◦ Ensure eartips provide a proper seal in your ear. Try different sized eartips.
Charging issues	<ul style="list-style-type: none">◦ Check if the charging cable is securely connected to both the case and the power source.◦ Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.◦ Try a different charging cable or power adapter.
Voice Assistant not responding	<ul style="list-style-type: none">◦ Ensure your device's voice assistant is enabled and configured.◦ Check the touch control gesture for activating the voice assistant (Long Press 3 seconds).

WARRANTY AND SUPPORT

Your GOBOULT W60 True Wireless Earbuds come with a warranty. Please refer to the included Warranty Card for detailed terms and conditions, including warranty period and coverage.

For technical support, service, or further inquiries, please contact Boulton customer service through the contact information provided on your Warranty Card or the official Boulton website.

Manufacturer: Boulton Audio, Exotic Mile Private Limited

Country of Origin: India

ADDITIONAL INFORMATION

The GOBOULT W60 earbuds are available in multiple colors: Green, Black, and White. Choose the color that best matches your personal style.

Three Shades

One Vibe



Image: Displays the GOBOULT W60 earbuds and their charging cases in three available colors: Green, Black, and White.



[\[pdf\]](#) User Manual

HiFi Stereo Review 1963 12 10 mar 2023 — switches to stereo thus eliminating any manual operation
325 G regan S t L ouis 3 M issouri WRITE F or Service —Satisfaction p revail h ere l f y worldradiohistory

Archive All Audio HiFi 60s RICHARD WAGNER TWILIGHT OF AGOD |||

Hil/StewoReview D MB R 0 CENTS RICHARD WAGNER: TWILIGHT OF AGOD

***** ROUNDU ... eo-headphone control center , Feb. 41 KLH

Model 14, Dec. 28 University Senior I, Sep. 34 Wharfedale **W60**, Mar. 34 Tape
Recorders Bell RT360, Nov. 30 Concord 880, Jan. 36 Dual TG12SK, Aug. 28 Norelco
Co...

lang:en **score:7** filesize: 18.85 M page_count: 138 document date: 2019-11-16