



[Manuals.plus](#) /

> [SEDETA](#) /

> SEDETA Farmhouse 67" L Shaped Desk User Manual

SEDETA 22_2-ssy

SEDETA Farmhouse 67" L Shaped Desk User Manual

Model: 22_2-ssy | Brand: SEDETA

1. INTRODUCTION

Thank you for choosing the SEDETA Farmhouse 67" L Shaped Desk. This executive desk is designed to enhance your home office or study space with its ample storage, integrated power outlets, and classic farmhouse style. This manual provides detailed instructions for assembly, operation, and maintenance to ensure you get the most out of your new desk.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully. Do not skip steps.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the desk or shelves beyond their stated weight capacity (Maximum load capacity: 200 lbs).
- Keep small parts and assembly hardware away from children and pets to prevent choking hazards.
- Place the desk on a flat, stable surface to prevent tipping.
- When using the integrated power outlets, ensure devices are compatible with the specified voltage and current (120V/12A for AC outlets, 5V/2A for USB ports). Do not exceed the maximum power support of 1500W.
- Unplug the power strip from the wall outlet when not in use or during electrical storms.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
Desk Panels	Various engineered wood panels for desktop, sides, and shelves.	Varies

Part	Description	Quantity
Drawer Components	Panels and hardware for three drawers, including one file drawer.	Set
Hardware Pack	Screws, dowels, cam locks, drawer slides, handles, etc.	1 Set
Power Outlet Unit	Integrated charging station with 2 AC outlets and 2 USB ports.	1
Instruction Manual	This document.	1

Note: A screwdriver is recommended for assembly, but not included.

4. SETUP AND ASSEMBLY

Assembly typically requires two people. Follow the numbered steps provided in the included pictorial instructions. Do not fully tighten all fasteners until the desk is completely assembled to allow for adjustments.

4.1 Overview and Dimensions

Familiarize yourself with the overall dimensions and layout of the L-shaped desk before starting assembly. This desk measures 67 inches in length on one side and 55.1 inches in depth on the other, with a height of 29.5 inches.



Maximum load capacity:

200 lbs




Figure 4.1: Desk Dimensions and Load Capacity (Maximum 200 lbs)




Figure 4.2: Spacious Desktop Overview

4.2 Assembling the Main Frame

Begin by connecting the main desktop panels and the supporting side panels. Ensure the pre-drilled holes align correctly for cam locks and dowels. Use the provided hardware to secure these connections.

4.3 Drawer Assembly and Installation

Assemble the three drawers according to the pictorial guide. Pay close attention to the orientation of the drawer slides. The bottom drawer is designed as a file drawer, accommodating A4 and letter-sized files. Ensure the full-pull slides are installed correctly for smooth operation.





Figure 4.3: Drawer Features and Capacity

Classic American style



Figure 4.4: Farmhouse Style Drawer Design

4.4 Installing Storage Shelves

The open storage shelves on the side of the desk offer flexible storage. The lower shelves are adjustable, allowing you to customize the height based on your storage needs, such as accommodating a CPU tower or various office items.

Adjustable Shelf

Meet your diverse storage needs, practical and convenient.



Tiered Storage



CPU Stand

Figure 4.5: Adjustable Shelf Configurations

4.5 Power Outlet Unit Installation

Carefully integrate the charging station into the designated cutout on the desktop. Ensure the power cord is routed safely and the unit is flush with the desk surface. The unit includes 2 AC outlets and 2 USB ports, with an on-off switch for safety.

Convenient Charging Station

Maximum power support of 1500w.



Power Cord
6.5-Foot



Safety
switch



2 AC Outlets
120V/12A



2 USB Ports
5V/2A



Figure 4.6: Convenient Charging Station

5. OPERATING INSTRUCTIONS

5.1 Using the Drawers

The desk features three drawers. The top two are standard storage drawers for office supplies and personal items. The bottom drawer is a file drawer designed to hold A4 and letter-sized hanging files. Pull drawers out smoothly using the handles. Avoid forcing them if they feel stuck.

5.2 Utilizing the Storage Shelves

The open shelves on the side provide additional storage. To adjust the height of the lower shelves, remove any items, lift the shelf, and reposition the support pins into the desired holes. Ensure the shelf is level and secure before placing items on it.

5.3 Power Outlet Operation

Plug the desk's power cord into a standard wall outlet. Use the integrated AC outlets (120V/12A) for laptops, monitors, or other electronic devices. Use the USB ports (5V/2A) to charge mobile phones, tablets, and other USB-powered devices. The on-off switch controls power to all outlets and USB ports. Flip the switch to the 'ON' position to supply power and to the 'OFF' position to cut power for safety and energy saving.

6. MAINTENANCE

- **Cleaning:** Dust regularly with a soft, dry cloth. For spills, wipe immediately with a damp cloth and dry thoroughly. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Hardware Check:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone lubricant can be applied to the drawer slides.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the desk finish.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent damage to the desktop surface.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk wobbles or is unstable.	Loose fasteners; uneven floor.	Check and tighten all assembly screws. Ensure the desk is on a level surface; use shims if necessary.
Drawers do not slide smoothly.	Improperly installed slides; debris in tracks; overloaded drawer.	Verify drawer slides are correctly aligned and installed. Clean tracks of any debris. Reduce weight in the drawer.
Power outlets are not working.	Power switch off; desk not plugged in; circuit overload.	Ensure the power unit's on-off switch is in the 'ON' position. Check if the desk's power cord is securely plugged into a working wall outlet. Unplug some devices to prevent overload.
Missing or damaged parts upon arrival.	Shipping damage or packing error.	Contact SEDETA customer service immediately for replacement parts or assistance.

8. SPECIFICATIONS

Brand: SEDETA

Model: 22_2-ssy

Product Dimensions (D x W x H): 55.1" x 67" x 29.5"

Material: Engineered Wood

Color: Grey

Style: Farmhouse

Number of Drawers: 3 (including 1 file drawer)

Number of Shelves: 3 (open, adjustable)

Power Outlet Unit: 2 AC Outlets (120V/12A), 2 USB Ports (5V/2A)

Maximum Power Support: 1500W

Maximum Load Capacity: 200 lbs

Assembly Required: Yes (Recommended 2 people)

9. WARRANTY AND SUPPORT

SEDETA stands behind the quality of its products. If your executive desk arrives damaged, scratched, or with parts missing, please contact our customer service team for assistance. We are committed to providing free replacements or partial refunds for such issues.

For any questions, concerns, or support needs regarding your SEDETA Farmhouse L Shaped Desk, please refer to your purchase documentation for contact information or visit the official SEDETA website.

Contact Information: Please refer to your purchase receipt or the SEDETA brand store on Amazon for the most current customer service contact details.

