

[Manuals.plus](#) /

> [Veken](#) /

> Veken 63 x 28 Inch Electric Standing Desk User Manual (Model ODHOME123)

Veken ODHOME123

Veken 63 x 28 Inch Electric Standing Desk User Manual

Model: ODHOME123

1. PRODUCT OVERVIEW

The Veken 63 x 28 Inch Electric Standing Desk (Model ODHOME123) is designed to provide a versatile and ergonomic workspace. It features a spacious desktop, smooth electric height adjustment, and a robust metal frame for stability. This desk is suitable for various uses including home office work, study, and gaming.

Key Features:

- **Spacious Worksurface:** An expansive 63" x 28" desktop accommodates multiple monitors and office supplies, promoting an organized and efficient workflow.
- **Ergonomic Curved Edge:** A smooth, human-centric curved edge reduces arm strain and allows easy access to items, enhancing comfort during long work hours.
- **Rock-Solid Stability:** A reinforced structure ensures exceptional stability and shake-free operation, even at full height.
- **Heavy-Duty Metal Frame:** Constructed with premium cold-rolled steel, the desk legs offer robust load-bearing capacity and long-lasting durability.
- **Smooth Height Adjustment:** Easily switch between sitting and standing positions with an electric motor, offering a wide height range from 27.9" to 45.6".



Image 1.1: Veken Electric Standing Desk showcasing its dimensions (63"W x 28"D) and adjustable height range (27.9" to 45.6"). The control panel is visible on the right side of the desk.

Large desktop storage space




Image 1.2: Top-down view of the desk surface, illustrating its large storage space and highlighting properties such as scratch-resistance, corrosion-resistance, and eco-friendly materials.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use to prevent injury or damage.

- Ensure proper assembly and stability by following all user manual instructions carefully.
- Use the provided feet pads to prevent slipping and protect floor surfaces.
- Be mindful of the weight limits and avoid overloading the desk to maintain stability and prevent damage. The desk has an ultra-high load-bearing capacity of up to 176 lbs.
- Keep children and pets away from the desk during height adjustment to prevent accidents.
- Do not place liquids directly on the desk surface without protective coasters.

Ultra-high-load-bearing tabletop



Image 2.1: Illustration of the desk's robust construction, indicating an ultra-high load-bearing capacity of 176 lbs and detailing the high-strength steel, anti-corrosion, sealing polish, and baking finish layers.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Desk Components (Desktop sections, Legs, Frame)
- Control Panel
- Power Adapter and Cable
- Cable Clip
- Feet Pads (4 units)
- Headphone Hook
- User Manual (1 unit)
- Assembly Hardware (Screws, Allen wrenches, etc.)

4. SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for correct assembly. All holes are pre-drilled, and accessories are pre-labeled for ease of installation.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Desktop:** Connect the desktop sections according to the included diagrams, ensuring the curved edge faces the user.
3. **Attach Legs and Frame:** Secure the desk legs and crossbar frame to the desktop using the provided hardware. Ensure all connections are tight and stable.
4. **Install Control Panel:** Mount the control panel to the underside of the desk in the designated location.
5. **Connect Power:** Plug the power adapter into the control box and then into a wall outlet.
6. **Cable Management:** Use the included cable clips to organize power and data cables for a tidy workspace.



Image 4.1: Exploded view demonstrating the quick and simple installation process, showing pre-drilled holes and pre-labeled accessories.

Assembly Video Guide:

Your browser does not support the video tag.

Video 4.1: Official installation steps for the Veken Electric Standing Desk. This video provides a visual guide to the assembly process.

5. OPERATING INSTRUCTIONS

The Veken Electric Standing Desk features an intuitive control panel for easy height adjustment and memory presets.

Height Adjustment:

- Use the **Up** (▲) and **Down** (▼) buttons on the control panel to manually adjust the desk height.
- The desk can be adjusted smoothly within a range of 27.9 inches to 45.6 inches.

Memory Presets:

The control panel allows you to save preferred sitting and standing heights for quick adjustments.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **'M'** button (Memory) followed by a number button (**'1'**, **'2'**, or **'3'**) to save the current height to that preset.
3. To recall a saved height, simply press the corresponding number button (**'1'**, **'2'**, or **'3'**). The desk will automatically move to the preset height.

Ergonomic desktop

Curved desktop, fitting the body curve, more comfortable



Image 5.1: A user operating the Veken Electric Standing Desk in a sitting position, demonstrating the ergonomic curved edge for comfortable use.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Veken Electric Standing Desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the laminated finish.
- **Check Connections:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure cables are not pinched or tangled, especially during height adjustments.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent strain on the motor and frame.

7. TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common problems and solutions.

Common Issues:

- **Desk Not Adjusting:** Check if the power cable is securely plugged into both the desk and the wall outlet. Ensure no obstructions are blocking the desk's movement.
- **Uneven Height Adjustment:** This can sometimes be caused by incorrect installation of internal components. Refer to the specific installation videos below.
- **Error Codes:** If the control panel displays an error code, consult the full user manual for specific code meanings and troubleshooting steps.

Troubleshooting Video Guides:

Your browser does not support the video tag.

Video 7.1: Guide on how to correctly install the transmission rod. Incorrect installation can lead to operational issues.

Your browser does not support the video tag.

Video 7.2: Guide on the correct installation direction for the side plates. Improper orientation can affect desk stability and function.

8. SPECIFICATIONS

Brand	Veken
Model Number	ODHOME123
Product Dimensions	63"W x 28"D x 27.9"-45.6"H
Minimum Height	27.9 Inches
Maximum Height	45.6 Inches
Item Weight	43.4 Pounds
Load Capacity	176 LBS
Color	White
Top Material Type	Blockboard (Laminated Finish)
Base Material	Cold-rolled Steel
Special Features	Adjustable Height, Electric, Ergonomic, Memory Preset
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or contact Veken customer service.

- **Manufacturer Warranty:** Details regarding the manufacturer's warranty are typically provided within the product packaging.
- **Customer Support:** If you have any questions, require assistance with assembly, or need troubleshooting help, please reach out to Veken customer support through the contact information provided on the official Veken website or your purchase platform.

