

Manuals.plus /

› STF /

› STF Allure Portable Speaker ST-S12629 User Manual

STF ST-S12629

STF Allure Portable Speaker ST-S12629 User Manual

Model: ST-S12629

INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient operation of your STF Allure Portable Speaker, model ST-S12629. Please read this manual thoroughly before using the device and retain it for future reference.

SAFETY INFORMATION

- Do not expose the speaker to water or excessive moisture.
- Avoid extreme temperatures.
- Do not disassemble or attempt to repair the speaker yourself. This will void the warranty.
- Keep out of reach of children.
- Use only the provided charging cable.

PACKAGE CONTENTS

Please check the package for the following items:

- STF Allure Portable Speaker (ST-S12629)
- USB Charging Cable
- User Manual (this document)

Note: No additional components are included beyond the speaker, charging cable, and manual.

PRODUCT OVERVIEW

The STF Allure Portable Speaker (ST-S12629) features powerful audio output, versatile connectivity, and dynamic RGB lighting. Below are key components and controls.

Front View



Image: Front view of the STF Allure Portable Speaker, showcasing the dual 5-inch speakers with RGB lighting and the included USB charging cable.

Top Panel Controls



Image: Close-up of the top panel of the STF Allure Portable Speaker, showing control buttons for playback, volume, EQ, mode selection, and power.

- **Power Button:** Press and hold to turn on/off. Short press to toggle LED lights.
- **Mode Button:** Short press to switch between Bluetooth, FM Radio, USB, Micro SD, and AUX modes.
- **EQ Button:** Short press to cycle through equalizer presets.
- **Play/Pause Button:** Play or pause audio. In FM mode, short press to auto-scan.
- **Previous/Volume Down Button:** Short press for previous track. Long press to decrease volume.
- **Next/Volume Up Button:** Short press for next track. Long press to increase volume.
- **Menu Button:** (Functionality may vary by mode, typically for settings or TWS pairing).

Rear Panel Ports



Image: Rear view of the STF Allure Portable Speaker, highlighting the various input ports including DC IN, USB, Micro SD, AUX, and Microphone.

- **DC IN Port:** For charging the speaker using the provided USB cable.
- **USB Port:** For playing audio from a USB flash drive (up to 32 GB).
- **Micro SD Card Slot:** For playing audio from a Micro SD card (up to 32 GB).
- **AUX Input (3.5mm):** For connecting external audio devices via an auxiliary cable.
- **Microphone Input (6.3mm):** For connecting a microphone.

SETUP

1. Charging the Speaker:

Before first use, fully charge the speaker. Connect the provided USB charging cable to the DC IN port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator will illuminate. A full charge takes approximately 3 hours.

2. Powering On/Off:

Press and hold the Power button on the top panel for a few seconds to turn the speaker on or off.

OPERATING INSTRUCTIONS

Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing "BLUE" on the display and an audible prompt.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "STF Allure" in your device's Bluetooth list and select it to pair.
4. Once paired, the speaker will emit an audible confirmation, and "BLUE" will stop flashing. You can now play audio from your device.
5. Use the Play/Pause, Previous/Volume Down, and Next/Volume Up buttons on the speaker or your device to control playback.

True Wireless Stereo (TWS) Function

The TWS function allows you to connect two STF Allure speakers for a stereo sound experience.

1. Ensure both STF Allure speakers are turned on and in Bluetooth mode, but not connected to any device.
2. On one of the speakers (this will be the primary speaker), press and hold the "Menu" button (or the designated TWS button if available, refer to specific model markings) until you hear a pairing tone.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation tone.
4. Now, connect your Bluetooth device to the primary speaker as described in the "Bluetooth Mode" section. Both speakers will play audio in stereo.

FM Radio Mode

1. Press the "Mode" button repeatedly until "FM" appears on the display.
2. Press the "Play/Pause" button once to start an automatic scan for available FM stations. The speaker will save the found stations.
3. Use the "Previous/Volume Down" and "Next/Volume Up" buttons to navigate between saved stations.

USB / Micro SD Card Mode

1. Insert a USB flash drive or a Micro SD card (up to 32 GB, formatted to FAT32) containing MP3 audio files into the respective port on the rear panel.
2. The speaker will automatically switch to USB or Micro SD mode and begin playing audio. If not, press the "Mode" button until the correct mode is selected.
3. Use the Play/Pause, Previous/Volume Down, and Next/Volume Up buttons to control playback.

AUX Input Mode

1. Connect one end of a 3.5mm auxiliary cable (not included) to the AUX input port on the speaker.
2. Connect the other end of the auxiliary cable to the audio output jack of your external device.
3. Press the "Mode" button repeatedly until "AUX" appears on the display.
4. Control audio playback directly from your connected external device.

Microphone Input

1. Connect a 6.3mm microphone (not included) to the Microphone input port on the rear panel.
2. Adjust the microphone volume using the controls on the microphone itself or the speaker's main volume control.

LED RGB Lighting

The speaker features dynamic RGB lighting. Short press the Power button to cycle through different lighting modes or turn the lights off.

MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- Avoid dropping the speaker or subjecting it to strong impacts.
- If the speaker will not be used for an extended period, charge it periodically to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; incorrect mode selected; device not paired.	Increase volume; press "Mode" button to select correct input; re-pair Bluetooth device.
Bluetooth pairing fails.	Speaker too far from device; other devices connected; speaker not in pairing mode.	Ensure speaker and device are within 10 meters; disconnect from other devices; ensure speaker is flashing "BLUE".
TWS pairing fails.	Speakers not in Bluetooth mode; one speaker already paired to a device.	Ensure both speakers are in Bluetooth mode and not connected to any device before initiating TWS pairing.
USB/Micro SD not playing.	Incorrect file format; card/drive not formatted correctly; card/drive capacity too large.	Ensure files are MP3; format to FAT32; use cards/drives up to 32 GB.

SPECIFICATIONS

Feature	Detail
Model Name	ST-S12629
Speaker Type	Portable with Bluetooth
Speaker Size	Dual 5-inch speakers
Output Power	20W
Sound Pressure	86 dB
Bluetooth Version	5.3
Wireless Range	Up to 10 meters (33 feet)
Battery Capacity	3000 mAh
Playback Time	Up to 3 hours
Charging Time	Approximately 3 hours
Connectivity Options	Bluetooth 5.3, USB, Micro SD, FM Radio, Aux 3.5mm, Microphone 6.3mm
Max USB/Micro SD Capacity	32 GB
Control Method	Tactile Buttons
Color	White

WARRANTY AND SUPPORT

The STF Allure Portable Speaker (ST-S12629) comes with a 5-year warranty. For warranty claims or technical support, please contact STF customer service.

For further assistance, please visit the official STF website or contact their support channels. Keep your purchase receipt as proof of purchase for warranty purposes.

Note: Warranty terms and conditions may vary by region. Please refer to the official STF warranty policy for detailed information.