

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MassaMAX](#) /

› [MassaMAX A675 Massage Chair & Cover Bundle User Manual](#)

MassaMAX A675

MassaMAX A675 Massage Chair & Cover Bundle User Manual

Model: A675

1. INTRODUCTION

Thank you for choosing the MassaMAX A675 Massage Chair and Cover Bundle. This manual provides essential information for the safe and effective operation, setup, and maintenance of your new massage chair and its protective cover. Please read this manual thoroughly before use and retain it for future reference.

The MassaMAX A675 massage chair is designed to provide a comprehensive and customizable massage experience, featuring advanced technologies such as 4D massage, an i-OPEN FLEXIBLE SL Track, and full-body airbag compression. The included cover helps protect your investment from dust and wear.



Image 1.1: The MassaMAX A675 Massage Chair and its accompanying protective cover.

2. SAFETY INFORMATION

To ensure safe operation, always adhere to the following precautions:

- Read all instructions before using the massage chair.
- Do not use the chair if you have any medical conditions that may be aggravated by massage. Consult a physician if unsure.
- Keep the chair away from water or damp environments.
- Ensure the power cord is not damaged and is properly plugged into a grounded outlet.
- Do not allow children or pets to play on or around the chair.
- Unplug the chair from the power outlet before cleaning or moving it.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel.

3. SETUP

3.1 Unpacking and Placement

1. Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. Place the massage chair on a flat, stable surface, ensuring sufficient clearance around the chair for recline and extension (approximately 10 inches from a wall).
3. Connect the power cord to the chair and then to a suitable electrical outlet.

3.2 Applying the Protective Cover

The included cover is designed to protect your massage chair from dust, spills, and sunlight. Its dimensions are approximately 61.02 x 37.40 x 53.15 inches (155 x 95 x 135cm), fitting most recliners and massage chairs.

1. Ensure the massage chair is in its upright, non-reclined position.
2. Carefully drape the cover over the entire massage chair, starting from the top.
3. Adjust the cover to ensure it fully encloses the chair, providing complete protection.




Image 3.1: The protective cover showing its approximate dimensions for proper fit.



Image 3.2: The sun-proof material of the protective cover, designed for durability and protection.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Locate the power button, typically on the side panel or remote control. Press once to power on, and press again to power off.

4.2 Smart Body Scan

Upon powering on, the A675 chair initiates a Smart Body Scan. Advanced sensors detect your body shape and pressure points, customizing the massage for your unique physique. Remain still during this process for accurate mapping.

4.3 i-OPEN FLEXIBLE SL Track

The i-OPEN FLEXIBLE SL Track (125°–167° Adjustable) is a dynamic system that adjusts in real-time. Unlike regular SL tracks, this feature allows for a deeper stretch, better muscle relief, and full spinal alignment by adapting to your body's movements and positions during the massage.



Image 4.1: Diagram illustrating the adjustable range and flexibility of the i-OPEN SL Track.

4.4 4D Massage Mechanism

The advanced 4D Massage Mechanism allows for precise adjustment of the massage rollers in height, width, depth, and speed. This enables a highly customized and targeted massage experience, mimicking the nuanced movements of human hands.



Image 4.2: Visual representation of the 4D massage mechanism, showing adjustable dimensions.

4.5 Full Body Stretch Massage

This program combines roller kneading, air compression, and gentle stretching to release tension throughout the body, from the neck down to the calves. It helps to decompress the spine and improve flexibility.

4.6 Calf Kneading & Auto Footrest Extension

The chair features dual rotating rollers that knead tired calves, promoting circulation and relieving muscle soreness. The footrest automatically adjusts to ensure perfect leg positioning for users of varying heights, extending up to 7.09 inches.



Image 4.3: The automatic extendable footrest, illustrating its extension capability.

4.7 Full Body Airbags Massage + Heating Shawl & Heating Calves

Airbags strategically placed throughout the chair provide compression massage to various body parts, including shoulders, arms, waist, calves, and feet. Integrated heating elements in the shawl and calves areas provide soothing warmth to enhance relaxation and muscle relief.




Image 4.4: Diagram showing the full body airbag massage areas and heating zones.

4.8 Control Methods

The MassaMAX A675 offers multiple intuitive control options:

- **Touchscreen Control:** A user-friendly touchscreen display allows for easy navigation through massage programs, settings, and adjustments.
- **Shortcut Keys Control:** Conveniently located physical buttons provide quick access to frequently used functions.
- **AI Voice Control:** Utilize voice commands for hands-free operation and adjustment of massage settings.



Image 4.5: Overview of the various control interfaces: touchscreen, shortcut keys, and AI voice control.

5. MAINTENANCE

5.1 Cleaning the Massage Chair

- Always unplug the chair before cleaning.
- Wipe the surface of the chair with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- For stubborn stains, use a mild soap solution and wipe dry immediately.
- Avoid getting water into any electrical components.

5.2 Cleaning the Protective Cover

- The cover can be wiped clean with a damp cloth.
- For deeper cleaning, hand wash with mild detergent and air dry. Do not machine wash or tumble dry.

5.3 Storage

If the chair will not be used for an extended period, unplug it and cover it with the provided protective cover to prevent dust accumulation and maintain its condition.

6. TROUBLESHOOTING

If you encounter any issues with your MassaMAX A675 Massage Chair, please refer to the following common troubleshooting steps:

- **Chair does not power on:** Ensure the power cord is securely plugged into both the chair and a working electrical outlet. Check the circuit breaker.
- **Massage rollers are not moving:** Verify that a massage program is selected and the chair is not in a paused state.
- **Unusual noises:** Minor operational sounds are normal. If you hear loud or persistent unusual noises, power off the chair and contact customer support.
- **Remote control/touchscreen not responding:** Ensure the remote has fresh batteries (if applicable) or that the touchscreen is clean and free of obstructions.

If the problem persists after attempting these steps, please contact MassaMAX customer support for assistance.

7. SPECIFICATIONS

Key specifications for the MassaMAX A675 Massage Chair and Cover Bundle:

- **Massage Chair Model:** A675
- **Massage Technology:** 4D Massage with Smart Body Scan
- **Track Type:** i-OPEN FLEXIBLE SL Track (125°–167° Adjustable)
- **Massage Programs:** Full Body Stretch Massage, Calf Kneading
- **Air Compression:** Full Body Airbags (shoulders, arms, waist, calves, feet)
- **Heating:** Shawl and Calves
- **Footrest:** Auto-adjusting, extends up to 7.09 inches
- **Control:** Touchscreen, Shortcut Keys, AI Voice Control
- **Cover Dimensions:** Approximately 61.02 x 37.40 x 53.15 inches (155 x 95 x 135cm)
- **ASIN:** B0FF186S9P
- **Date First Available:** May 19, 2025



Image 7.1: Front view of the MassaMAX A675 Massage Chair, showcasing its design and features.

8. WARRANTY & SUPPORT

MassaMAX is committed to providing high-quality products. For information regarding your product's warranty, please

refer to the warranty card included with your purchase or visit the official MassaMAX website. For technical support, service inquiries, or to purchase replacement parts, please contact MassaMAX customer service through the contact information provided on the MassaMAX store page or your purchase documentation.

Visit the MassaMAX Store: [MassaMAX Amazon Store](#)

© 2025 MassaMAX. All rights reserved.