

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bewinner](#) /

› [Bewinner Neckband Headphones V5.4-100H User Manual](#)

## Bewinner Bewinner3shypxgg6d

# Bewinner Neckband Headphones V5.4-100H User Manual

Model: Bewinner3shypxgg6d

## INTRODUCTION

Thank you for choosing the Bewinner Neckband Headphones V5.4-100H. This manual provides essential information for the proper setup, operation, and maintenance of your new headphones. Please read it thoroughly before use to ensure optimal performance and longevity of the product.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Bewinner Neckband Headphones V5.4-100H
- 4 x Earcaps (various sizes)
- 1 x USB Charging Cable
- 1 x User Manual



Image: Contents of the Bewinner Neckband Headphones package, including the headphones, USB charging cable, and multiple earcaps.

## SETUP

### 1. Charging the Headphones

Before first use, fully charge the headphones. The estimated charging time is approximately 1 hour.

1. Locate the charging port on the neckband.
2. Connect the supplied USB charging cable to the charging port on the headphones.
3. Connect the other end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The indicator light will show the charging status (refer to the LED indicator section for details).
5. Once fully charged, disconnect the USB cable.



Image: A close-up view of a finger opening the protective cover of the USB charging port on the neckband headphones.

## 2. Selecting Earcaps

The package includes four earcaps of various sizes. Choose the size that provides the most comfortable and secure fit for optimal sound quality and noise isolation.



Image: A detailed close-up of one of the in-ear earbuds, showing the silicone earcaps.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off

- **Power On:** Press and hold the Multi-function button (usually the center button) for approximately 3 seconds until the LED indicator flashes.
- **Power Off:** Press and hold the Multi-function button for approximately 5 seconds until the LED indicator turns off.

### 2. Pairing with a Device

The headphones use V5.4 technology for stable wireless connections.

1. Ensure the headphones are powered off.
2. Press and hold the Multi-function button for approximately 5-7 seconds until the LED indicator flashes red and blue

alternately, indicating pairing mode.

3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices.
5. Select "Bewinner V5.4-100H" (or similar name) from the list of devices.
6. Once paired, the LED indicator will flash blue slowly.

The headphones will automatically attempt to reconnect to the last paired device when powered on.

### 3. Basic Controls

The control buttons are located on the neckband for easy access.



Image: A close-up view of the control panel on the neckband, showing buttons for volume, power/multi-function, and track control.

- **Multi-function Button (Center):**

- Press once: Play/Pause music, Answer/End call.
- Press and hold (3s): Power On.
- Press and hold (5s): Power Off.
- Press and hold (5-7s from off): Enter Pairing Mode.

- **Volume Up (+) Button:**

- Press once: Increase volume.
- Press and hold: Next track.

- **Volume Down (-) Button:**

- Press once: Decrease volume.
- Press and hold: Previous track.

### 4. LED Indicator Status

- **Red LED (Solid):** Charging.
- **Red LED (Off):** Fully Charged.
- **Blue LED (Flashing Slowly):** Connected/Standby.
- **Red & Blue LED (Alternating):** Pairing Mode.

## MAINTENANCE

- **Cleaning:** Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Earcaps:** The silicone earcaps can be removed and gently washed with mild soap and water, then air-dried completely before reattaching.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. The memory silicone neckband is designed to resist tangling.

- **Battery Care:** To prolong battery life, avoid fully discharging the headphones frequently. Charge regularly, even if not in use for extended periods.

## TROUBLESHOOTING

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and check the charging indicator.
Cannot pair with device.	<ul style="list-style-type: none"> <li>• Ensure headphones are in pairing mode (alternating red/blue LED).</li> <li>• Make sure Bluetooth is enabled on your device.</li> <li>• Move the headphones closer to your device.</li> <li>• Turn off and on both the headphones and your device, then try pairing again.</li> <li>• Clear previous Bluetooth connections on your device if necessary.</li> </ul>
No sound or poor sound quality.	<ul style="list-style-type: none"> <li>• Check the volume levels on both the headphones and your connected device.</li> <li>• Ensure the headphones are properly paired and connected.</li> <li>• Try different earcaps for a better seal in your ear.</li> <li>• Move closer to your device to avoid interference.</li> </ul>
Headphones disconnect frequently.	<ul style="list-style-type: none"> <li>• Ensure there are no obstacles between the headphones and your device.</li> <li>• Move away from sources of strong electromagnetic interference.</li> <li>• Ensure the headphones are fully charged.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model	Bewinner3shypxgg6d
Technology Version	V5.4
Battery Type	500mAh Li-Ion Battery
Charging Time	Approx. 1 Hour
Usage Time	Approx. 100 Hours
Driver Unit	10mm
Material	ABS, Memory Silicone
Ear Placement	In Ear
Form Factor	In Ear
Item Weight	6.3 ounces

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or customer service inquiries, please contact Bewinner customer support through the retailer where the product was purchased or visit the official Bewinner website. Please retain your proof of purchase for warranty claims.

