

## NICETY FZC-36-72

# NICETY 72 Colors Dual-Tip Acrylic Paint Markers Instruction Manual

Model: FZC-36-72

## INTRODUCTION

---

Thank you for choosing NICETY 72 Colors Dual-Tip Acrylic Paint Markers. This set includes 36 double-color pens, providing 72 vibrant shades for various artistic projects. These markers are designed for smooth application on multiple surfaces and feature a water-based, non-toxic, quick-drying ink formula. Please read this manual carefully to ensure proper use and maintenance of your markers.

## WHAT'S IN THE BOX

---

- 36 x Dual-Color Acrylic Paint Markers (providing 72 unique shades)
- 10 x Replacement Brush Tips



The NICETY 72 Colors Dual-Tip Acrylic Paint Markers set, neatly organized in its box, displaying the color card, numbered caps for easy identification, and a separate compartment for 10 replacement brush tips.

## SETUP AND FIRST USE



Before using your NICETY acrylic paint markers for the first time, follow these steps to ensure optimal ink flow:

1. **Shake Well:** With the cap securely on, shake each marker gently for approximately 10-20 seconds. This mixes the pigment evenly within the water-based ink.
2. **Prime the Tip:** Press the brush tip down on a scrap piece of paper several times until the ink begins to flow. Do not press excessively hard, as these markers feature automatic ink control.
3. **Test Color:** Once the ink flows consistently, test the color on a scrap surface to ensure it matches your expectation and is ready for use.



A detailed view of a NICETY dual-tip acrylic paint marker, highlighting its flexible brush tip, transparent ink window, and the recommended 'Shake & Paint' preparation steps for consistent ink flow.

# READY-TO USE MARKERS



Visual guide demonstrating the readiness steps for NICETY markers: emphasizing no excessive pressing, thorough shaking, and then beginning your creative work.

## OPERATING INSTRUCTIONS

NICETY Dual-Tip Acrylic Paint Markers are versatile tools for various art and craft applications. Each marker features two brush tips, offering flexibility for different artistic needs.

### Using the Dual Tips

- **Fine Lines (1mm):** Use the tip gently for detailed work, outlining, and intricate designs.
- **Broad Strokes (5mm):** Apply more pressure to the brush tip for wider strokes, shading, and filling larger areas. The flexible nature of the tip allows for natural adjustment between line widths.

### Consistent Ink Flow

These markers are engineered with automatic ink control to provide smooth, even color without the need for constant pressing or concerns about ink flooding. If you notice any inconsistency, gently shake the marker again to re-balance the ink.

### Multi-Surface Application

NICETY acrylic markers are designed to perform reliably on a wide range of surfaces. Colors remain bright and stable after drying.

- Rock
- Wood
- Glass
- Ceramic
- Metal
- Fabric
- Canvas
- Plastic
- Paper



Illustration demonstrating the versatility of NICETY acrylic markers on diverse materials, including paper, metal, wood, ceramic, glass, rock, and canvas.

### **Official Product Video: Usage Demonstration**

This official product video demonstrates the application and vibrant results of the NICETY 72 Colors Dual-Tip Acrylic Paint Markers on various surfaces, showcasing their smooth flow and color opacity.

## MAINTENANCE

- **Cap Securely:** Always replace the caps tightly after each use to prevent the ink from drying out.
- **Storage:** Store markers horizontally to ensure even ink distribution to both tips. Keep them away from direct sunlight and extreme temperatures.
- **Tip Replacement:** The set includes 10 replacement brush tips. If a tip becomes worn or damaged, carefully pull it out and insert a new one.
- **Cleaning:** If ink dries on the tip, gently wipe it with a damp cloth. For stubborn clogs, you may try dipping the tip in warm water for a few seconds, then re-priming on scrap paper.

## TROUBLESHOOTING

- **Inconsistent Ink Flow:** If the ink flow is uneven, ensure the marker has been shaken well. Re-prime the tip by gently pressing it on scrap paper until the ink flows consistently.
- **Colors Not Layering Well:** While NICETY markers offer good layering, some colors may require the base layer to be completely dry before applying a second coat to achieve the desired effect without mixing or smudging.
- **Tip Damage:** If a brush tip is frayed or damaged, replace it with one of the included spare tips.

## SPECIFICATIONS

Feature	Detail
Brand	NICETY
Model Number	FZC-36-72
Color Count	72 Colors (from 36 dual-color pens)
Tip Type	Dual-Tip Brush (1-5mm flexible)
Ink Type	Water-Based Acrylic
Drying Time	Quick-Dry
Safety Standards	Non-Toxic, ASTM D4236, EN71
Item Weight	2.66 pounds
Package Dimensions	10.39 x 7.48 x 2.64 inches

## SAFETY INFORMATION

NICETY acrylic paint markers are formulated with non-toxic, water-based ink and meet ASTM D4236 and EN71 safety standards. They are safe for use by artists of all ages. However, adult supervision is recommended for young children. Avoid contact with eyes and mouth. In case of contact, rinse thoroughly with water.

## WARRANTY AND SUPPORT

Specific warranty details and direct support contact information are not provided in the available product data. For any product-related inquiries or support, please refer to the seller's contact information on the platform where the product was purchased.