

## VEVOR SX006

# VEVOR Corner Bread Box User Manual

Model: SX006

## 1. INTRODUCTION

---

Thank you for choosing the VEVOR Corner Bread Box. This manual provides essential information for the safe and efficient use of your new bread storage container. Please read these instructions carefully before assembly and use, and retain them for future reference.

This double-layer bamboo bread box is designed to optimize kitchen counter space, offering a ventilated environment to keep your bread and other baked goods fresh. Its corner-fitting design and adjustable internal partition provide versatile storage solutions.

## 2. SAFETY INSTRUCTIONS

---

- Ensure the bread box is placed on a stable, flat surface to prevent tipping.
- Keep the bread box away from direct heat sources, open flames, and excessive moisture.
- Do not overload the shelves to maintain stability and prevent damage.
- This product is not intended for use by children without adult supervision.
- Avoid using abrasive cleaners or sharp objects that could scratch or damage the bamboo wood or acrylic door.

## 3. PRODUCT OVERVIEW

---

The VEVOR Corner Bread Box is crafted from natural bamboo, featuring a double-layer design with an acrylic wavy door. It is specifically designed to fit into kitchen corners, maximizing your counter space.

### Key Features:

- **Corner Design:** Optimizes kitchen counter space.
- **Adjustable Internal Partition:** Three height options (183mm, 213mm, 243mm) for flexible storage.

- **Durable Bamboo Construction:** Natural, reliable, and food-contact approved material.
- **Ventilated Back:** Promotes airflow to extend bread freshness.
- **Acrylic Wavy Door:** Provides visibility of contents while adding aesthetic appeal.
- **Magnetic Flip Lid:** Ensures smooth opening and secure closure.
- **Flat Top:** Offers additional storage space for small items.
- **Non-slip Base:** Enhances stability on your counter.

## Natural Wood Color Double-Layer Corner Storage Bread Box

Smart use of corners for storing bread and other items



Image 3.1: VEVOR Corner Bread Box showcasing its dimensions (12.60 in x 12.60 in x 16.73 in) and corner-fitting design.

# Adjustable Internal Partition Height

Three adjustable heights: 183mm, 213mm, 243mm



Complete space



Higher Top



Equal Distribution



Lower Top

Image 3.2: Illustration of the adjustable internal partition, demonstrating various height configurations for different storage needs (Complete space, Higher Top, Equal Distribution, Lower Top).

# Natural Bamboo Wood

Secure Material, Food Contact Approved



Sturdy



Waterproof



Shock  
resistant



Ventilated



Image 3.3: Highlights the natural bamboo wood material, emphasizing its sturdy, waterproof, shock-resistant, and ventilated properties.

## 4. SETUP

---

The VEVOR Corner Bread Box is designed for simple assembly. Follow these steps to set up your bread box:

### Included Components:

- 1 x Bread Box (main panels)
- 1 x Handle
- 14 x M5\*30 Screws
- 1 x M4\*16 Screw

- 7 x Dowels
- 3 x M3\*10 Screws
- 3 x Footings
- 1 x Laminate (adjustable shelf)
- 1 x Wrench

### Assembly Steps:

1. **Attach the Assembly Panels:** Carefully align and connect the main bamboo panels of the bread box.
2. **Tighten the Screws:** Use the provided screws and wrench to secure the panels firmly on both sides.
3. **Install Handle and Footings:** Attach the handle to the door and the non-slip footings to the base.
4. **Insert Adjustable Shelf:** Place the laminate (shelf) into your desired height setting using the pre-drilled holes.



Image 4.1: Visual guide for the easy three-step assembly process: 1. Attach the Assembly Panels, 2. Tighten the Screws on Both Sides, 3. Completed Assembly.

## 5. OPERATING INSTRUCTIONS

---

### Storing Items:

- Open the acrylic wavy door by gently pulling the handle. The magnetic closure will release.
- Place bread, pastries, or other items on the shelves.
- Close the door firmly until the magnetic closure engages.

### Adjusting Shelf Height:

- Empty the bread box of all contents.
- Carefully remove the internal laminate (shelf).
- Re-insert the laminate into the desired set of pre-drilled holes to achieve one of the three adjustable heights (183mm, 213mm, or 243mm).
- Ensure the shelf is securely seated before placing items back inside.

# Wave Acrylic Door Panel

Practical and aesthetic, also guards privacy



Image 5.1: The bread box featuring its wave acrylic door panel, which allows visibility of contents and adds to its aesthetic.

## More Practical and Thoughtful Details




Image 5.2: Close-up views of practical details including the magnetic cover, flat top for storage, rubber anti-slip feet, and wooden handle.

## 6. MAINTENANCE

---

Proper care will ensure the longevity and appearance of your VEVOR Corner Bread Box.

### Cleaning:

- Wipe the bread box clean with a damp cloth.
- For stubborn stains, use a mild soap solution and immediately wipe dry.
- **Hand Wash Only:** This item is not dishwasher safe.

- Do not immerse the bread box in water.

### General Care:

- Avoid placing hot items directly on the bamboo surface.
- Do not use in a microwave.
- Periodically check screws and connections to ensure they remain tight.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your VEVOR Corner Bread Box, please refer to the following common solutions:


- **Door not closing properly:** Check if any items are obstructing the door. Ensure the magnetic closure is clean and free from debris. Verify that the bread box is on a level surface.
- **Shelf feels unstable:** Remove the shelf and re-insert it, ensuring it is fully seated in the designated slots at your chosen height.
- **Bread becoming stale quickly:** Ensure the bread box is not placed in direct sunlight or near heat sources. Verify that the door is fully closed to maintain the internal environment. The ventilated back is designed for optimal airflow, but extreme conditions can affect freshness.
- **Wobbling:** Ensure all assembly screws are tightened. Check that the non-slip footings are properly installed and the bread box is on a flat, stable surface.

For issues not covered here, please contact VEVOR customer support.

## 8. SPECIFICATIONS

---

<b>Brand</b>	VEVOR
<b>Model Number</b>	SX006
<b>Color</b>	Natural Wood Color
<b>Main Material</b>	Bamboo Wood, Wave Acrylic, MDF Board
<b>Product Dimensions (L x W x H)</b>	12.60" x 12.60" x 16.73" (320 x 320 x 425 mm)
<b>Net Weight</b>	7.28 lb / 3.3 kg
<b>Capacity</b>	43.52 Liters
<b>Closure Type</b>	Flip Top (Magnetic)
<b>Special Features</b>	Corner design, adjustable internal partition, ventilated back, magnetic closure, non-slip base
<b>Care Instructions</b>	Hand Wash Only



Item Model Number: **SX006**

Color: **Natural Wood Color**

Product Shape: **Corner Shape**

Net Weight: **7.28 lb / 3.3 kg**

Main Material:

Product Dimension:

**Bamboo Wood (Lid with Horizontal Wave Acrylic, Two Corner Side Panels, MDF Board)**

**12.60 x 12.60 x 16.73 in / 320 x 320 x 425 mm**

**Accessories:**

handle **x 1 pcs**

M5\*30screw **x 14 pcs**

dowel **x 7 pcs**

M4\*16screw **x 1 pcs**

footing **x 3 pcs**

lamine **x 1 pcs**

M3\*10screw **x 3 pcs**

wrench **x 1 pcs**

Image 8.1: Detailed view of the product dimensions and a list of included accessories for assembly.

## 9. WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. For specific warranty information regarding your VEVOR Corner Bread Box, please refer to the warranty card included with your purchase or visit the official VEVOR website.

### Customer Support:

If you have any questions, require technical assistance, or need to report a problem, please contact VEVOR customer support through their official channels. Contact information can typically be found on the VEVOR website or on your product packaging.

Website: [www.vevor.com](http://www.vevor.com)

© 2024 VEVOR. All rights reserved.