



Manuals.plus /

› MXV /

› MXV 70-Inch Fireplace TV Stand Instruction Manual (Model EF573A)

MXV EF573A

MXV 70-Inch Fireplace TV Stand Instruction Manual

Model: EF573A

1. INTRODUCTION

Thank you for purchasing the MXV 70-Inch Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

This versatile furniture piece combines a spacious TV stand with an integrated electric fireplace, offering both aesthetic appeal and functional heating. It features a 3-sided glass design for an expansive view of the flame, adjustable LED lighting, and ample storage solutions.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in fire, electric shock, or personal injury.

- Always disconnect the power cord from the outlet before cleaning, performing maintenance, or moving the fireplace unit.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Ensure the unit is placed on a stable, level surface to prevent tipping.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- This product is designed for indoor use only.

- The electric fireplace is equipped with Thermal Overload Protection and Child Lock Protection for enhanced safety.

3. PACKAGE CONTENTS

Before assembly, ensure all parts and hardware are present. This product is shipped in two separate boxes, which may arrive on different days. Refer to the included parts list in your packaging to verify all components.

Typical components include:

- Main TV stand panels (Engineered Wood)
- Electric Fireplace Insert (36.0"L x 11.8"W x 18.1"H)
- Glass doors and shelves
- Hardware pack (screws, dowels, hinges, etc.)
- LED light strips and remote control
- Instruction manual



Image: Overview of the TV stand dimensions and packaging information, indicating shipment in two boxes.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this MXV Fireplace TV Stand. Please follow the detailed, step-by-step instructions provided in the separate assembly guide included in your package. All hardware and parts are clearly numbered for easy identification.

4.1 Preparation

- Clear a spacious area for assembly.
- Lay out all components on a soft, clean surface to prevent scratches.
- Identify all parts and hardware using the provided list.
- Gather necessary tools (e.g., screwdriver, hammer).

4.2 Assembly Steps

1. Begin by assembling the main frame of the TV stand according to the numbered diagrams.

2. Install the adjustable shelves into the side cabinets. These shelves allow for flexible storage configurations.
3. Integrate the electric fireplace insert into the central compartment. Ensure it is securely seated.
4. Attach the glass doors to the side cabinets.
5. Install the LED light strips within the cabinets as desired.
6. Utilize the large cable holes at the rear of the unit for organized wire management.



Image: Details on the stable base, cable management features, and adjustable shelves for customized storage.

70 Inch Fireplace TV Stand

Tabletop weight capacity: 132 Lbs

Shelves weight capacity: 33 Lbs

Size: 70" W x 13.8" D x 31.4" H



Shipped in two boxes , maybe shipped separately



Image: Visual representation of the TV stand's compatibility with televisions up to 80 inches in size.

5. OPERATING INSTRUCTIONS

The MXV Fireplace TV Stand features an integrated electric fireplace with various settings for ambiance and heating, along with multi-color LED light strips for the cabinets.

5.1 Electric Fireplace Operation

The electric fireplace can be controlled via the control panel on the unit or the included remote control.

- **Power:** Press the power button to turn the fireplace ON/OFF.
- **Flame Brightness:** Cycle through 5 settings from dim to bright to adjust the intensity of the flame effect.
- **Flame Colors:** Select from 12 different flame colors to match your mood or decor.
- **Heat Settings:** Choose between 1000W or 1500W heat modes. The fireplace provides auxiliary heating for spaces up to 400 square feet.

- **Temperature Control:** Adjust the desired room temperature from 60°F to 99°F.
- **Timer Function:** Set an automatic shut-off timer from 0.5 to 9 hours.
- **Child Lock:** Activate the child lock feature for safety.

MULTI-COLOR LED LIGHT STRIP

Customize your space with backlights and realistic flame



Image: Detailed view of the panoramic fireplace features, including flame brightness levels and color options.

36 INCH PANORAMIC FIREPLACE

5000 BTU

CAN PROVIDE AUXILIARY
HEATING FOR A 400 SQUARE FEET SPACE



1000W/1500W
2 Heat Modes



60°F to 99°F
Temperature



0.5-9H Timer
Function



Thermal Overload
Protection



CSA
Certificated



Child Lock
Protection



Image: Information on the fireplace's heating capacity and integrated safety features.

5.2 LED Light Strip Operation

The multi-color LED light strips in the cabinets can be customized using the provided remote control.

- **Color Selection:** Choose from 12 different LED colors to illuminate your cabinet contents.
- **Brightness Control:** Adjust the intensity of the LED lights.
- **Modes:** Some remotes may offer various lighting modes (e.g., fade, flash). Refer to your remote's specific instructions.



Image: Visual guide to the multi-color LED light strips and their remote control functionality.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your MXV Fireplace TV Stand.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the engineered wood finish.
- **Cleaning the Fireplace Glass:** Use a glass cleaner specifically designed for fireplace glass. Do not spray cleaner directly onto the unit; apply to a cloth first.
- **Dusting:** Regularly dust the fireplace vents and interior components to ensure proper airflow and prevent overheating.
- **Electrical Components:** Ensure the power cord is not pinched or damaged. Do not attempt to service the electrical components yourself.

7. TROUBLESHOOTING

If you encounter issues with your MXV Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord loose, thermal overload activated.	Check power outlet and cord connection. Allow unit to cool if thermal overload is suspected. Reset circuit breaker if tripped.
No heat output.	Heat function not activated, temperature setting too low.	Ensure heat mode is selected. Increase desired temperature setting.
Flame effect not visible.	Flame brightness set to minimum, flame motor issue.	Increase flame brightness setting. If issue persists, contact customer support.
LED cabinet lights not working.	Loose connection, remote battery dead, light strip damage.	Check connections of LED strips. Replace remote batteries.
Remote control not responding.	Batteries dead, obstruction, remote too far.	Replace remote batteries. Ensure no obstructions between remote and unit. Operate remote closer to the unit.

8. SPECIFICATIONS

Brand: MXV

Model Name: Fireplace TV Stand

Model Number: EF573A

Product Dimensions: 70"W x 13.8"D x 31.4"H

Item Weight: 78 Pounds

Material: Engineered Wood

Color: Gray

Finish Type: Lacquered

Installation Type: Freestanding

Power Source: Corded Electric

Fireplace Dimensions: 36.0"L x 11.8"W x 18.1"H

Heat Output: 1000W/1500W (5000 BTU), heats up to 400 sq ft

Temperature Range: 60°F to 99°F

Timer: 0.5-9 hours

Flame Brightness Settings: 5 levels

Flame Colors: 12 options

LED Light Strip Colors: 12 options

TV Size Compatibility: Up to 80 inches

Tabletop Weight Capacity: 132 lbs

Shelves Weight Capacity: 33 lbs per shelf

Special Features: Adjustable shelves, large cable holes, Thermal Overload Protection, Child Lock Protection, CSA Certificated.

9. WARRANTY AND SUPPORT

The MXV Fireplace TV Stand comes with a Limited Warranty. Please refer to the warranty information included in your product packaging for specific terms and conditions.

For technical assistance, missing parts, or warranty claims, please contact MXV customer support through the retailer where the product was purchased. Have your model number (EF573A) and purchase date ready when contacting support.