

## Zerodeko 412016F0ZP

# Zerodeko Square Air Fryer Basket Instruction Manual

Model: 412016F0ZP

## INTRODUCTION

---

This manual provides essential information for the proper use and maintenance of your Zerodeko Square Air Fryer Basket. Designed as a replacement or accessory for various air fryers, this stainless steel basket facilitates efficient and even cooking of a variety of foods. Please read these instructions carefully before first use to ensure optimal performance and longevity of your product.


## PRODUCT OVERVIEW

---

The Zerodeko Square Air Fryer Basket is constructed from durable stainless steel, featuring a mesh design for optimal air circulation and a convenient handle for safe handling. It is designed to be a versatile accessory for your air frying needs.




**Figure 1:** The Zerodeko Square Air Fryer Basket, showcasing its mesh construction and integrated handle. This basket is designed for even heat distribution during air frying.



**Figure 2:** Detailed dimensions of the air fryer basket, measuring approximately 20.5 cm (8.06 inches) in length and width, and 6.5 cm (2.55 inches) in height. These measurements are crucial for ensuring compatibility with your air fryer.



**Figure 3:** Demonstrates the ergonomic handle of the basket, designed for easy and safe lifting and placement into and out of the air fryer.




Replacement air fryer basket

**FUNCTION**

**MATERIAL**

Made of stainless steel material



**Figure 4:** Highlights the stainless steel mesh material and the secure attachment of the handle, emphasizing the product's durable construction and design for optimal air circulation.



## Air fryer basket

Our air fryer basket has a handle, basket is easy to take out

**Figure 5:** The air fryer basket in use, placed inside an air fryer with a piece of cooked meat, illustrating its function in the cooking process.



**Figure 6:** A visual representation of the basket's versatility, showing it used for cooking french fries, chicken wings, and a whole roasted chicken, demonstrating its multi-purpose application.



**Figure 7:** Multiple close-up views detailing the fine mesh construction, the secure handle attachment points, and the overall robust design of the basket.



**Figure 8:** A detailed view of the handle's attachment to the basket, highlighting the sturdy construction that ensures durability and safe handling.



**Figure 9:** The square air fryer basket positioned next to an air fryer, containing a roasted chicken, illustrating its practical use in a kitchen setting.

## SPECIFICATIONS

- **Model Number:** 412016F0ZP
- **Material:** Stainless Steel
- **Dimensions:** 20.50 cm x 20.50 cm x 6.50 cm (8.07 inches x 8.07 inches x 2.56 inches)
- **Item Weight:** 5.3 ounces
- **Color:** Silver
- **Manufacturer:** Zerodeko

## SETUP

1. **Unpack:** Carefully remove the air fryer basket from its packaging.
2. **Inspect:** Check the basket for any signs of damage or manufacturing defects. Do not use if damaged.
3. **Initial Cleaning:** Before first use, wash the basket thoroughly with warm, soapy water. Rinse completely and dry with a soft cloth. Refer to the "Care and Maintenance" section for detailed cleaning instructions.
4. **Compatibility Check:** Ensure the basket fits properly within your specific air fryer model. The dimensions

are provided in the "Specifications" section.

## OPERATING INSTRUCTIONS

---

This basket is designed to enhance the air frying process by promoting even cooking and easy handling. Always follow your air fryer's specific operating instructions in conjunction with using this accessory.

1. **Prepare Food:** Place your food items directly into the Zerodeko Square Air Fryer Basket. Avoid overcrowding to ensure optimal air circulation and even cooking.
2. **Insert into Air Fryer:** Using the integrated handle, carefully place the basket into the main cooking chamber of your air fryer. Ensure it is seated securely.
3. **Cook:** Operate your air fryer according to its manufacturer's instructions for the specific food you are preparing. The mesh design of this basket allows hot air to circulate efficiently around the food.
4. **Remove Food:** Once cooking is complete, use the handle to carefully lift the hot basket out of the air fryer. Always use oven mitts or heat-resistant gloves when handling the hot basket.
5. **Serve:** Transfer the cooked food to a serving dish.

**Note:** The basket will become very hot during operation. Exercise extreme caution to prevent burns.

## CARE AND MAINTENANCE

---

Proper care will extend the life of your Zerodeko Square Air Fryer Basket and maintain its performance.

- **Cleaning After Each Use:** Allow the basket to cool completely before cleaning. Wash with warm, soapy water and a non-abrasive sponge or brush to remove food residue.
- **Stubborn Residue:** For baked-on food, soak the basket in warm, soapy water for 15-30 minutes before scrubbing.
- **Rinsing:** Rinse thoroughly under running water to remove all soap residue.
- **Drying:** Dry immediately with a soft cloth to prevent water spots and maintain the stainless steel finish. Air drying is also acceptable.
- **Dishwasher Safe:** The stainless steel basket is generally dishwasher safe, but hand washing is recommended for best results and to prolong its lifespan.
- **Storage:** Store the clean, dry basket in a cool, dry place.
- **Avoid Abrasives:** Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can scratch the stainless steel surface.

## TROUBLESHOOTING

---

If you encounter issues with your air fryer basket, consider the following:

- **Food Sticking:** Ensure the basket is clean before use. Lightly spray or brush the basket with cooking oil before adding food, especially for items prone to sticking.
- **Uneven Cooking:** Avoid overcrowding the basket. Cook in smaller batches if necessary. Ensure your air fryer's fan is functioning correctly.
- **Difficulty Cleaning:** Refer to the "Care and Maintenance" section. Soaking can help loosen stubborn food particles.
- **Basket Does Not Fit:** Double-check the dimensions provided in the "Specifications" section against your air fryer's internal measurements. This basket is designed as a replacement or accessory and may not be

universally compatible with all air fryer models.

## **WARRANTY AND SUPPORT**

---

For information regarding warranty coverage or product support, please refer to the retailer's return policy or contact Zerodeko customer service through the platform where the product was purchased. Keep your proof of purchase for any warranty claims.