

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bear](#) /
- › [Bear NutriEase AllStage Baby Food Blender Instruction Manual](#)

Bear NutriEase AllStage

Bear NutriEase AllStage Baby Food Blender Instruction Manual

Model: NutriEase AllStage

- [Introduction](#)
- [Safety Information](#)
- [Components](#)
- [Setup](#)
- [Operation](#)
- [Maintenance](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the safe and efficient use of your Bear NutriEase AllStage Baby Food Blender. This appliance is designed to steam and blend ingredients for homemade baby food, offering various textures suitable for different developmental stages.

Bear NutriEase AllStage Baby Food Maker



Image: The Bear NutriEase AllStage Baby Food Blender, showcasing its digital control panel and three age-stage settings for food consistency (4-7 months smooth, 8-10 months medium, 11 months+ chunky).

2. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged before cleaning or assembly.
- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children. This appliance is not a toy.
- Ensure the lid is securely locked before operating the blending function. The appliance features a safety lock that prevents operation if the lid is not correctly in place.

- Use only purified water in the water tank to prevent limescale buildup and ensure optimal performance.
- Do not operate the appliance if any part is damaged. Contact customer support for assistance.
- Avoid touching hot surfaces during and immediately after operation.
- Do not exceed the maximum fill line of 350 mL (11.83 fl oz) to prevent spills.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Bear NutriEase AllStage Baby Food Blender:

- **Main Unit:** Contains the motor and control panel.
- **Stainless Steel Bowl:** For steaming and blending ingredients.
- **Stainless Steel Blade:** Detachable for blending.
- **Steamer Basket:** For steaming ingredients.
- **Lid with Safety Lock:** Secures the bowl during operation.
- **Spatula:** For handling food.
- **Cleaning Brush:** For maintenance.

✓ Bear

Safe and Healthy Stainless Steel Construction

Free from harmful chemicals such as BPA, BPS, lead and phthalates



Plastic

Odorous, susceptible to stain and cracking



Glass

Fragile, poor heat conduction leading to undercooked food

Image: Illustration of the durable stainless steel construction, including the blending bowl and blade, highlighting the BPA-free materials.

4. SETUP AND FIRST USE

Before first use, wash all detachable parts (stainless steel bowl, blade, steamer basket, lid) with warm soapy water, rinse thoroughly, and dry. The main unit should be wiped with a damp cloth.

1. **Fill Water Tank:** Fill the tank with purified water.
2. **Insert Steamer Basket:** Place the steamer basket into the inner cup.
3. **Install Blade:** Securely install the blending blade.
4. **Add Ingredients:** Add diced ingredients (e.g., 1x1 cm pieces) into the steamer basket.
5. **Attach Lid:** Attach the splash guard and cover the top lid, ensuring it aligns and locks securely.



Image: A step-by-step visual guide demonstrating the assembly process, from filling the water tank to securing the lid before operation.

5. OPERATING INSTRUCTIONS

The Bear NutriEase AllStage Baby Food Blender offers various functions for preparing healthy baby food.

5.1. Basic Steaming and Blending

1. Prepare ingredients as described in the Setup section.
2. Select the desired cooking program (e.g., Veggie, Fruit, Root, Meat, Fish, Stew) using the digital control panel.
3. Press the "Start/Cancel" button to begin the cooking cycle. The appliance will automatically steam and then blend the food according to the selected program.

4. Once complete, the appliance will signal. Carefully remove the lid and transfer the food.

Prepares all Kinds of Baby Food



Image: The baby food maker positioned among a variety of ingredients, illustrating its capability to prepare different types of baby food including vegetables, fruits, and proteins.

5.2. Age Stage Settings

Customize food consistency based on your baby's developmental stage:

- **4-7 Month:** For smooth purees.
- **8-10 Month:** For medium consistency.
- **11 Month+:** For chunky textures.

Select the appropriate age stage button on the control panel to adjust the blending intensity and duration.

5.3. Manual Blending

For precise control over food consistency, use the "Manual Blend" function. Press and hold the "Manual Blend" button for desired blending duration. Release to stop.

5.4. Preset and Keep Warm Functions

The appliance features a "Preset" function to schedule cooking in advance and an automatic "Keep Warm" function to maintain food temperature after cooking.



Image: A visual representation of the "Preset" function for preparing food overnight and the "Keep Warm" function for serving fresh food during the day.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygienic operation of your baby food blender.

6.1. Daily Cleaning

- Unplug the appliance and allow it to cool completely.
- Remove all detachable parts (bowl, blade, steamer basket, lid).
- Wash these parts with warm, soapy water or place them in the dishwasher (all detachable parts except the main unit are dishwasher-safe).
- Wipe the main unit with a damp cloth. Do not immerse the main unit in water.
- Wipe all parts dry with a soft cloth after each use to prevent water stains.

6.2. Auto Clean Function

The built-in "Auto Clean" function helps remove food residue from the blending bowl.

1. Ensure the bowl is empty of food.
2. Add a small amount of water to the bowl.
3. Select the "Auto Clean" mode on the control panel.
4. Press "Start/Cancel" to activate. The function will run for a short cycle to clean the interior.
5. After the cycle, discard the water and rinse the bowl.

High-Temp & High-Speed Auto Clean Function

Removes baby food residue effortlessly, perfect for busy parents.

Select the 'Auto Clean' Mode
Easy deep clean in Mins



Detachable Parts for Easy Cleaning



Dishwasher-Safe



Image: The appliance's control panel highlighting the "Auto Clean" function, alongside an illustration of detachable parts being easily cleaned under running water.

6.3. Descaling the Water Tank

Water stains or limescale may accumulate on the stainless steel base due to minerals in tap water.

Periodically deep-clean the water tank:

- Use white vinegar or a descaling solution specifically designed for kitchen appliances.
- Follow the descaling product's instructions for dilution and soaking time.
- Rinse thoroughly multiple times after descaling to remove any residue.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; safety lock not engaged.	Ensure power cord is securely plugged in. Check power outlet. Ensure lid is properly closed and locked.
Blending function not working.	Lid not securely locked; ingredients too hard or too much.	Ensure lid is correctly positioned and locked. Reduce ingredient quantity or cut into smaller pieces.
Food not blending smoothly.	Insufficient liquid; ingredients too large; blade dull.	Add a small amount of water or cooking liquid. Cut ingredients smaller. Contact support if blade appears dull.
Limescale buildup in water tank.	Use of tap water with high mineral content.	Use purified water. Perform descaling as described in Section 6.3.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model	NutriEase AllStage
Voltage	230V
Heating Power	350W
Blending Power	150W
Water Tank / Blender Cup Capacity	350mL (11.83 Oz)
Net Weight	2.05 kg (4.52 lbs)
Dimensions (D x W x H)	17 x 17 x 23 cm (6.7D x 6.7W x 9.2H inches)
Material	Stainless Steel, BPA Free Materials
Special Features	All-in-one compact device for steaming, blending food, Auto blending & manual blending, Auto cleaning function, removable parts, safety lock, Nutrient-preserving stainless steel steam baskets, Preset & Keep-Warm functions.

9. WARRANTY AND CUSTOMER SUPPORT

Bear provides a 1-year warranty for the NutriEase AllStage Baby Food Blender. For any technical support or warranty claims, please contact Bear customer service. Lifetime technical support is available. Contact information for customer service can typically be found on the product packaging or the official Bear website.

