

## HENNCHEE RTPB-015P

# HENNCHEE Wearable Heated Blanket User Manual

MODEL: RTPB-015P

## Introduction

This manual provides essential information for the safe and effective use of your HENNCHEE Wearable Heated Blanket. Please read all instructions carefully before first use and retain this manual for future reference.

The HENNCHEE Wearable Heated Blanket features a 2-in-1 design, allowing it to be used as a blanket or worn as an outerwear garment. It includes five carbon fiber heating zones, dual control buttons, and a 16,000mAh battery for extended warmth. The blanket is equipped with NTC overheating protection for user safety.

## Product Components

- Wearable Heated Blanket (Sherpa and flannel material)
- 16,000mAh Lithium Polymer Battery
- USB-C Charging Cable (for battery)
- Storage Bag

## Setup Instructions

1. **Unpack the Blanket:** Carefully remove the wearable heated blanket from its storage bag.
2. **Charge the Battery:** Before first use, fully charge the provided 16,000mAh battery using the USB-C charging cable. The battery display will indicate charging progress.
3. **Connect the Battery:** Locate the internal pocket within the blanket designed for the battery. Connect the blanket's power cable to the fully charged battery. Ensure a secure connection.



Figure 1: Connecting the 16000mAh battery to the blanket's power cable.

## Operating Instructions

---

### Wearing the Blanket

The blanket can be worn in various styles. To wear it as a coat or vest:

1. **Unzip Side Openings:** Unzip the hidden zippers on both sides of the blanket to create armholes.
2. **Insert Arms:** Insert your arms through the sleeves and hold the top draping part to locate the snap buttons.
3. **Fasten for Fit:** Fasten the left snap to the right side and adjust for a comfortable fit.



Figure 2: Step 1 of wearing the blanket - Unzipping side openings.



Figure 3: Step 2 of wearing the blanket - Inserting arms.



Figure 4: Step 3 of wearing the blanket - Fastening snaps.

## Heating Controls

The blanket features dual control buttons for independent heating zones:

- One button controls the left and right chest and upper back heating zones.
- The other button controls the abdominal pocket heating zones.

Each heating zone has three adjustable heat levels:

- **High:** Approximately 149°F (lasts up to 3.5 hours)
- **Medium:** Approximately 131°F (lasts up to 4.5 hours)
- **Low:** Approximately 113°F (lasts up to 10 hours)

To activate heating, press and hold the desired control button for a few seconds. Press again to cycle through the heat levels. Press and hold to turn off.



Figure 5: Dual control buttons for chest/back and pocket heating zones.



Figure 6: Adjustable warmth settings and estimated duration.

## Safety Features

---

The HENNCHEE Wearable Heated Blanket is equipped with built-in NTC overheating protection technology. This system continuously senses the temperature and automatically adjusts the heat to prevent overheating, ensuring safe operation.



Figure 7: NTC Overheat Protection Device for enhanced safety.

## Care and Maintenance

---

To ensure the longevity and proper function of your heated blanket, follow these care instructions:

1. **Remove Battery:** Always disconnect and remove the battery pack before washing.
2. **Cap Charging Port:** Ensure the charging port on the blanket is securely capped to prevent water entry.
3. **Machine Wash:** Place the blanket in a mesh laundry bag. Machine wash on a gentle cycle with cold water.
4. **Do Not Bleach or Iron:** Avoid using bleach or ironing the blanket.
5. **Hang Dry:** Hang the blanket to air dry completely. Do not tumble dry.

## Troubleshooting

---

- **Blanket not heating:** Ensure the battery is fully charged and correctly connected to the blanket's power cable. Check that the control buttons are pressed and held to activate the heating function.
- **Short battery life:** Battery life varies depending on the heat setting. Higher settings consume more power. Ensure the battery is fully charged before use. Extreme cold environments may also affect battery performance.
- **Indicator lights not working:** Verify the battery is connected and charged. If the issue persists, contact customer support.

## Specifications

---

<b>Model Number</b>	RTPB-015P
<b>Battery Capacity</b>	16,000mAh Lithium Polymer (included)
<b>Heating Zones</b>	5 (Left Chest, Right Chest, Upper Back, 2 Abdominal Pockets)
<b>Heat Levels</b>	3 (Low: 113°F, Medium: 131°F, High: 149°F)
<b>Material</b>	Premium Flannel with Fleece Lining
<b>Item Weight</b>	3.27 pounds
<b>Package Dimensions</b>	17.63 x 8.74 x 7.6 inches

## Visual Guide

---

### Product Overview and Usage

Video 1: Official product video demonstrating the HENNCHEE Wearable Heated Blanket's features and various ways to wear it, including unpacking, battery connection, and different collar styles.

### Warranty and Support

---

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official HENNCHEE website. Keep your proof of purchase for warranty claims.