Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MYNTA MC1650

MYNTA MC1650 Massage Chair User Manual

Model: MC1650 | Brand: MYNTA

Important Safety Instructions

Before operating the MYNTA MC1650 Massage Chair, please read and understand all safety information. Failure to follow these instructions may result in injury or damage to the product.

- Always ensure the chair is placed on a stable, level surface.
- Do not exceed the maximum user weight capacity of 300 pounds (136 kg).
- Keep the chair away from heat sources and sharp objects to prevent damage to the chair and potential injury.
- Do not allow children or pets to play on or around the massage chair.
- Unplug the chair from the power outlet when not in use or before cleaning.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel for assistance.

Product Overview

The MYNTA MC1650 Massage Chair is designed to provide a comprehensive full-body massage experience. Key features include:

- **Flexible SL-Track:** Adapts dynamically to reclining positions up to 170°, ensuring consistent back contact.
- **Lumbar Heating:** Promotes relaxation, improves circulation, and relieves lower back stiffness.
- **Targeted Neck and Shoulder Relief:** Specialized programs and spot massage options for specific tension areas.
- **Zero Gravity Positioning:** Reduces spinal pressure by elevating the legs, enhancing comfort and massage effectiveness.
- **Anti-Pinch Safety Mechanism:** Built-in safety feature prevents accidental pinching.
- **Full-Body Airbag Coverage:** Includes shoulder, arm, foot, calf, and lumbar airbags with adjustable pressure settings.
- **Multiple Massage Techniques:** Offers kneading, tapping, rolling, shiatsu, and Swedish massage.
- **Bluetooth Speaker:** Integrated speakers for audio playback during massage sessions.



Image: The MYNTA MC1650 Massage Chair in a living room setting, showcasing its design and size.




Image: A diagram showing the flexible SL-Track mechanism of the massage chair, highlighting its ability to recline up to 170 degrees while maintaining full back contact.

Setup

The MYNTA MC1650 Massage Chair comes fully assembled, requiring no complex installation. Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the chair from its packaging. Ensure all packing materials are removed.
2. **Placement:** Position the chair on a flat, stable surface. Ensure there is sufficient space around the chair for reclining and footrest extension. The chair requires a minimum of 31 inches clearance for movement.
3. **Power Connection:** Connect the power cord to the chair and then to a grounded electrical outlet.



Image: A diagram illustrating the dimensions of the MYNTA MC1650 Massage Chair, including height, width, depth, and required clearance for full recline.

Operating Instructions

The MYNTA MC1650 offers intuitive controls for a personalized massage experience.

Control Methods

The chair can be controlled via a large digital panel and a smooth shortcut knob.



Image: Close-up view of the two control methods: a large digital panel for detailed settings and a convenient shortcut knob for quick adjustments.

Auto Body Scan

Upon starting a massage program, the chair performs an auto body scan to map key areas of your shoulders, neck, and back, ensuring a customized massage tailored to your body's contours.



Image: A visual representation of the SL-Track system performing an auto scan to detect the user's body shape for precise massage roller placement along the neck, back, waist, hip, and leg.

Pre-set Auto Programs

Select from 8 pre-set auto programs designed to address various relaxation and recovery needs, including "Master Choice", "Neck & Shoulder", "Stress Relief", "Office Regimen", "Sweet Dream", "Recovery", "Thighs & Hips", and "Relax".

Your browser does not support the video tag.

Video: An overview of the MYNTA 3D Massage Chair's features, including auto body scan, various massage programs, zero gravity, airbag coverage, heating, and Bluetooth connectivity.

Zero Gravity Positioning

The chair features 3 stages of Zero Gravity recline, designed to elevate your legs above your heart, minimizing spinal pressure and enhancing the massage experience. Select from Initial, Comfort, or Deep Zero Gravity stages.



Image: Illustration of the three Zero Gravity positions: Initial, Comfort, and Deep, demonstrating how the chair reclines to offer a weightless sensation.

Airbag Massage

Experience full-body compression massage with airbags located in the shoulders, arms, feet, calves, and lumbar area. Airbag intensity can be adjusted to low, medium, or high settings.



Image: A visual guide highlighting the locations of shoulder, arm, foot, calf, and lumbar airbags for comprehensive full-body compression massage.

Lumbar Heating

Activate the lumbar heating function to soothe muscles, improve blood circulation, and relieve stiffness in the lower back area.



Image: A diagram indicating the lumbar heating zone within the massage chair, designed to provide warmth to the lower back.

Foot Spa Function

The footrest features an extension of up to 7 inches, specialized foot rollers, and upgraded airbags to provide a relaxing foot massage experience.



Image: A close-up of the footrest, highlighting the 7-inch extension capability, calf airbags, and upgraded foot rollers for a comprehensive foot massage.

Bluetooth Connectivity

Connect your Bluetooth-enabled device to the chair's integrated speakers to enjoy music or audio during your massage session. Refer to your device's Bluetooth settings to pair with the massage chair.




Image: A user relaxing in the massage chair while connecting a smartphone via Bluetooth to the chair's integrated speakers for an enhanced audio experience.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your MYNTA MC1650 Massage Chair.

- **Cleaning:** Wipe the chair's surface with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Storage:** When not in use for extended periods, store the chair in a cool, dry place away from direct sunlight.
- **Inspection:** Regularly check the power cord and all connections for any signs of damage. If damage is found, discontinue use and contact customer support.

Troubleshooting

If you encounter issues with your MYNTA MC1650 Massage Chair, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not properly connected; power outlet malfunction.	Ensure power cord is securely plugged into both the chair and a working electrical outlet. Check the circuit breaker.
Massage rollers are not moving.	Program paused; safety feature activated.	Check if the program is paused. Ensure no objects are obstructing the rollers. Restart the chair.
Airbags are not inflating.	Airbag function disabled; low pressure setting.	Verify airbag function is enabled on the control panel. Adjust the air pressure setting to a higher level.
Bluetooth device not pairing.	Bluetooth not enabled on device; chair not in pairing mode.	Ensure Bluetooth is active on your device and the chair's Bluetooth is discoverable. Refer to your device's manual for pairing instructions.

If the problem persists after attempting these solutions, please contact MYNTA customer service for further assistance.

Specifications

Feature	Detail
Brand	MYNTA
Model Number	MC1650
Color	Grey
Material	Metal frame, Foam fill, Leather seat
Product Dimensions (D x W x H)	59.65" x 29.92" x 43.5"
Item Weight	209 Pounds (approx. 95 kg)
Max User Weight Capacity	300 Pounds (approx. 136 kg)
Recommended Height Range	4.9ft - 6.5ft (approx. 149cm - 198cm)
Reclining Position Count	2 (plus 3 Zero Gravity stages)
Required Assembly	No (Fully assembled)
Indoor/Outdoor Usage	Indoor

Warranty and Support

MYNTA massage chairs undergo strict quality tests before shipping. The product is packaged as one piece, requiring no installation.

- **Customer Service:** Professional customer service is available before and after purchase. For any problems, please contact MYNTA for assistance and solutions.
- **Return Policy:** The product is eligible for 30-day easy returns.
- **Protection Plans:** Optional 3-Year Protection Plan and Complete Protect monthly plans are available for purchase.

© 2026 MYNTA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FF4D27RF

More documents and user manuals: **https://manuals.plus/**