

[Manuals.plus](#) /

› [VG VOGCREST](#) /

› VG VOGCREST VG-105 2-in-1 Facial Hair Remover & Nose Trimmer User Manual

VG VOGCREST VG-105

VG VOGCREST VG-105 2-in-1 Facial Hair Remover & Nose Trimmer User Manual

Model: VG-105

1. PRODUCT OVERVIEW

The VG VOGCREST VG-105 is a versatile 2-in-1 rechargeable device designed for efficient and gentle facial and nose hair removal. Its compact, portable design makes it ideal for travel and daily use.



Image 1.1: The VG VOGCREST VG-105 device, showcasing its sleek design.

Key Features:

- **2-in-1 Design:** Includes interchangeable heads for facial hair removal and nose/ear hair trimming.
- **IPX6 Waterproof:** Safe for use in wet conditions and easy cleaning under running water.
- **Dual Stainless Steel Blades:** Features a 10000RPM motor for precise trimming without pulling or irritation.
- **Hypoallergenic Technology:** Designed for sensitive skin types.
- **One-Touch Operation:** Simple and intuitive to use.
- **Rechargeable:** USB-C charging for convenience, offering up to 180 minutes of runtime per charge.
- **Portable:** Compact, lipstick-sized design with an included travel pouch.

2. PACKAGE CONTENTS

Ensure all items are present upon unboxing:

- VG VOGCREST VG-105 Main Device

- Facial Hair Remover Head
- Nose/Ear Hair Trimmer Head
- USB-C Charging Cable
- Cleaning Brush
- Travel Pouch
- User Manual (this document)



Image 2.1: All components included in the VG VOGCREST VG-105 package.

3. SETUP

3.1 Charging the Device

Before first use, fully charge the device. A full charge takes approximately 1.5 hours and provides up to 90 days of runtime with daily 2-minute use.

1. Locate the USB-C charging port at the bottom of the device.
2. Connect the provided USB-C cable to the device and a compatible USB power source (e.g., computer, adapter, power bank, car charger).
3. The indicator light will illuminate during charging. It will change color or turn off once fully charged (refer to specific indicator behavior in the video or quick start guide if available).




Image 3.1: The device connected to a USB-C charger, illustrating the charging process.

3.2 Attaching/Changing Trimmer Heads

The VG-105 comes with two interchangeable heads for different grooming needs.

1. To remove a head, gently twist it counter-clockwise and lift it off the main device.
2. To attach a head, align the head with the device body and twist clockwise until it locks securely in place.




Image 3.2: Illustration of the interchangeable heads and how to switch them.

4. OPERATING INSTRUCTIONS

The VG-105 is designed for gentle and effective hair removal on various facial areas.

4.1 General Use

1. Ensure the device is charged and the desired trimmer head is securely attached.
2. Press the power button to turn on the device. The indicator light will show it's active.
3. Gently press the trimmer head against your skin and move it in slow, circular motions against the direction of hair growth. Avoid applying excessive pressure.
4. After use, press the power button to turn off the device.


4.2 Using the Facial Hair Remover Head

Ideal for eyebrows, upper and lower lip, cheeks, chin, and neck. Works effectively on peach fuzz or fine hair.

DUAL-RING PRECISION

ZERO TUGGING & BURNING:

Painless Facial Hair Removal
with Double-Ring Tech.



360° PAIN-FREE HAIR TRIMMER

UPGRADED DUAL-BLADE TRIMMER:

Effortlessly Remove Nose
& Ear Hair at Any Angle.

Image 4.1: Demonstrating the use of the facial hair remover head on the cheek.

4.3 Using the Nose/Ear Hair Trimmer Head

Carefully insert the nose trimmer head into the nostril or ear canal. Move it gently to trim unwanted hair. The 360-degree pain-free design ensures comfortable trimming.




Image 4.2: Demonstrating the use of the nose hair trimmer head.

4.4 Wet & Dry Use

The device features an IPX6 waterproof rating, allowing for safe use in the shower or during skincare routines. However, it is not designed for full submersion.



WET & DRY USE

IPX6 Waterproof design allows it to be used safely in wet conditions

* **IPX6 waterproof** rating means the device is **protected against powerful water jets from any direction**, but **NOT for full submersion**.

Image 4.3: The device is shown being used in a wet environment, emphasizing its waterproof capabilities.

4.5 Official Product Video

Video 4.4: An official product video from Vogcrest demonstrating the features and use of the 2-in-1 facial and nose hair remover.

5. MAINTENANCE

Regular cleaning ensures optimal performance and hygiene of your device.

5.1 Cleaning the Trimmer Heads

1. Turn off the device and detach the trimmer head.
2. Use the provided cleaning brush to gently remove any trapped hair from the blades.
3. Rinse the detached trimmer head under running water. Ensure it is completely dry before reattaching or storing.
4. Wipe the main device body with a dry cloth. Do not rinse the main body under water.

PAINLESS & SMOOTH

ZERO TUGGING & BURNING

Painless Facial Hair Removal
with Double-Ring Tech.



Image 5.1: Step-by-step guide for effortless cleaning of the trimmer heads.

6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. If the issue persists, try charging with a different USB-C cable or power source.
- **Reduced trimming performance:** Clean the trimmer head thoroughly to remove any accumulated hair or debris. Ensure the blades are not damaged.
- **Irritation or pulling:** Ensure the trimmer head is clean and properly attached. Use the device on clean, dry skin. Move the trimmer gently and slowly.
- **Device not charging:** Check the USB-C cable and power adapter for damage. Ensure the charging port is free of debris.

7. SPECIFICATIONS

Feature	Detail
Model Number	VG-105
Power Source	Battery Powered (Rechargeable)
Charging Time	Approx. 1.5 Hours (for 90 days runtime)
Waterproof Rating	IPX6
Blade Material	Stainless Steel
Recommended Uses	Ear, Face, Nose
Special Features	Detachable Head, Rechargeable, Travel Size, Waterproof
Item Weight	0.12 Kilograms (approx. 4.16 ounces)
Dimensions	5.24 x 2.92 x 1.77 inches

8. WARRANTY AND SUPPORT

VG VOGCREST is committed to providing quality women's hair removal solutions. For any product inquiries, technical

support, or warranty claims, please contact our customer service team.

Contact Email: customer@vogcrest.com

Please refer to the official VG VOGCREST website for the most up-to-date warranty information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question