

Lifezone King Size Storage Bed Frame with Hydraulic Lift & Wingback Headboard

Lifezone King Size Storage Bed Frame with Hydraulic Lift & Wingback Headboard Instruction Manual

Model: King Size Storage Bed Frame with Hydraulic Lift & Wingback Headboard

1. INTRODUCTION

Thank you for choosing the Lifezone King Size Storage Bed Frame. This bed frame is designed to provide both comfort and practical storage solutions for your bedroom. Featuring a hydraulic lift mechanism, a wingback headboard, and a sturdy platform, it eliminates the need for a box spring while offering ample under-bed storage. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new bed frame.

2. SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand or jump on the bed frame.
- When operating the hydraulic lift, ensure no objects or body parts are in the path of the moving frame to prevent injury.
- Always use two people for assembly and when lifting or moving the bed frame.
- The hydraulic lift system is designed to assist in lifting the mattress and platform. Do not attempt to lift the platform without a mattress in place, as it may spring up forcefully.
- Do not exceed the maximum weight recommendation of 1000 pounds for the bed frame.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Headboard (Wingback, Upholstered)
- Bed Frame Side Rails
- Footboard
- Hydraulic Lift Mechanism Components
- Wooden Slats and Slat Holders
- Center Support Beam and Legs
- Hardware Pack (Bolts, Screws, Washers, Allen Wrench, Small Wrench)
- Installation Manual

Note: Some small extra hardware pieces may be included as spares.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and takes approximately 90-120 minutes. Follow the numbered parts and clear diagrams provided in the included installation manual. The following steps provide a general overview.

4.1 Unpacking and Preparation

1. Clear a spacious area for assembly.
2. Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches.
3. Identify all parts using the provided parts list in the installation manual.

4.2 Frame Assembly

1. Attach the side rails to the headboard and footboard using the designated bolts and washers. Ensure all connections are snug but do not fully tighten until the entire frame is assembled.
2. Install the center support beam and its legs, ensuring they are properly aligned and secured.



Image: Fully assembled bed frame structure, showcasing the headboard and side rails.

4.3 Hydraulic Lift Installation

1. Carefully attach the hydraulic lift mechanisms to the bed frame according to the manual's diagrams. Pay close attention to the orientation of the pistons.
2. Connect the mattress support platform to the hydraulic mechanisms.

Lifting Weight Capacity



Image: Close-up of the hydraulic lift system and the mattress support platform, indicating lifting weight capacity.

4.4 Slat Installation

1. Insert the wooden slats into their designated holders on the mattress support platform. Ensure they are evenly spaced and securely seated.
2. Install the mattress retaining bar at the foot of the platform to prevent mattress slippage when lifted.



Hand Lift

Helps you lift the frame easily

Protect Device

Prevents the mattress from slipping when lifting



Easy Assembly

Helps you assemble the frame easily

Image: Detailed view of the slat system, hand lift strap, and mattress protection device.

4.5 Final Tightening

1. Once all components are in place, go back and fully tighten all bolts and screws. Do not overtighten.
2. Place your 8-14 inch King size mattress onto the platform. No box spring is needed.



Image: The bed frame with the mattress and platform lifted, showcasing the spacious under-bed storage compartment.

5. OPERATING INSTRUCTIONS

5.1 Accessing Under-Bed Storage

1. Ensure the mattress is properly seated on the platform.
2. Grasp the fabric handle or edge of the bed frame at the foot end.
3. With a firm, upward motion, lift the mattress and platform. The hydraulic pistons will assist in the lift, making it effortless for one person.
4. The platform will remain in the raised position, allowing full access to the storage area.
5. To close, gently pull the platform down. The hydraulics will control the descent. Ensure no items are obstructing the closing mechanism.

Large Under-Bed Storage Space



Image: A view of the large under-bed storage space, demonstrating its capacity for items like suitcases, shoes, and quilts.

5.2 Storage Capacity

The under-bed storage area provides significant space, equivalent to approximately six drawers. The available storage height is approximately 10.8 inches.

- Suitable for storing seasonal bedding, clothing, shoes, and other personal items.
- Distribute weight evenly within the storage compartment.

6. MAINTENANCE

- **Cleaning:** Wipe the upholstered surfaces with a dry cloth to remove dust. For spills, blot immediately with a clean, damp cloth and allow to air dry. Avoid harsh chemicals.
- **Hardware Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as needed to maintain stability and prevent squeaks.
- **Hydraulic System:** The hydraulic pistons are designed for long-term use and generally require no maintenance. If you notice a significant change in lifting assistance, contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed frame squeaks	Loose hardware; friction between parts.	Ensure all bolts and screws are securely tightened. EVA anti-noise strips are installed at contact points to minimize noise; check if any have shifted.
Hydraulic lift is difficult to raise or lower	Mattress too heavy/light; obstruction; hydraulic piston issue.	Ensure your mattress is within the recommended 8-14 inch thickness. Check for any items obstructing the lift mechanism. If the issue persists, contact customer support.
Mattress slides when lifted	Mattress retaining bar not installed or loose.	Verify that the mattress retaining bar at the foot of the platform is correctly installed and secured.
Bed frame feels unstable	Loose connections; uneven floor.	Re-tighten all assembly hardware. Ensure the bed frame is on a level surface.

8. SPECIFICATIONS

Brand:	Lifezone
Model:	King Size Storage Bed Frame with Hydraulic Lift & Wingback Headboard
Size:	King
Product Dimensions (L x W x H):	85.4"L x 78.3"W x 38.6"H
Color:	Beige
Material:	Linen Upholstered, Metal, Wood
Maximum Weight Recommendation:	1000 Pounds
Item Weight:	118.4 pounds
Special Features:	Hydraulic Lift Storage, Wingback Headboard, No Box Spring Needed, Squeak Resistant
Compatible Mattress Size:	King (8-14 inch thickness recommended)
Assembly Required:	Yes

9. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the retailer. For any questions, missing parts, or assistance with assembly or operation, please contact Lifezone customer support.

You can visit the official Lifezone store on Amazon for more information: [Lifezone Store](#)

