

Meoilkolnm b39c3b1e-ddf1-4faf-a515-ac55cc3e109b

Meoilkolnm 128GB FHD 1080P Mini Body Camera User Manual

Model: b39c3b1e-ddf1-4faf-a515-ac55cc3e109b

INTRODUCTION

Thank you for choosing the Meoilkolnm 128GB FHD 1080P Mini Body Camera. This compact and versatile body-worn camera is designed for hands-free recording in various situations. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its performance and lifespan.

WHAT'S IN THE BOX

Verify that all components are present in your package:

- 1 x 128GB Body Camera
- 1 x Waterproof Case
- 1 x Magnet Pendant
- 1 x Safety Cord
- 1 x Portable Back Clip
- 1 x USB Cable



Image: The Meoilkolnm Mini Body Camera shown with its accessories, including the waterproof case, magnet pendant, safety cord, portable back clip, and USB cable.

PRODUCT OVERVIEW

The Meoilkolnm Mini Body Camera is designed for ease of use and portability. It features a compact design, a single control button, and an indicator light for operational status.

1.27 • 02



(35.95g)

Small & Lightweight

Tiny camera, huge potential, Mount it and take it anywhere, anytime!

Image: The camera's small and lightweight design, shown held in a person's hand.

Dimensions: 64.5 x 28 x 20mm (approximately 2.5 x 1.1 x 0.7 inches).

Weight: Approximately 1.27 oz (35.95g).

The Action GH88 Camera

to film for a massive **180** minutes after fully charged (WI-FI OFF) !



Image: Visual representation of the camera's dimensions and its approximate 180-minute recording time on a full charge (Wi-Fi off).

SETUP


1. Initial Charging

Before first use, fully charge the camera. Connect the camera to a USB power source using the provided USB cable. The indicator light will show charging status (e.g., solid red while charging, off when fully charged).

2. Mounting Options

The camera offers multiple mounting options for hands-free operation:

- **Magnet Pendant:** Attach the camera to the magnet pendant and wear it around your neck with the safety cord for dual protection.
- **Portable Back Clip:** Use the 360° adjustable back clip to attach the camera to clothing, bags, or other surfaces.



Quick Capture

Simply press the home button on the front of the mini camera to start / stop recording instantly, when it's on.

Image: The camera attached to clothing, demonstrating its wearable design for quick capture.

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Press and hold the main button until the indicator light illuminates.
- **To Power Off:** Press and hold the main button until the indicator light turns off.

2. Recording Video

Once powered on, simply press the main button to start recording. Press the button again to stop recording. The indicator light will change to confirm recording status.

3. Live Preview and App Usage

For live preview, playback, and downloading content, connect the camera to its dedicated mobile application. Ensure the

camera's Wi-Fi is enabled and connect your smartphone or tablet to the camera's Wi-Fi network. For optimal performance, maintain a distance within 32ft (10m) between the camera and your device.



LIVE PREVIEW & Play Back & Download on App

Mount up the body cam and use App preview your shots and snap away like a pro. (Recommended to use within 32ft (10m))

Image: A smartphone screen showing a live preview from the camera, demonstrating the app's functionality.

4. Hands-Free Operation

Utilize the magnet pendant or portable back clip to wear the camera and record without needing to hold it. This allows for capturing moments from a first-person perspective.



A truly **no-hands** camera

Go completely hands-free and live in the moment! Set it and forget about it for easy, ultra-wide POV shots.

Image: Examples of hands-free camera usage in various activities, such as with pets, during social gatherings, and sports.

WATERPROOF CASE USAGE

The included waterproof case allows the camera to be used in wet environments. Ensure the camera is securely placed inside the case and the seals are properly closed before exposing it to water. Always test the waterproof case without the camera first to ensure no leaks.



Image: The transparent waterproof case for the Meoilkolnm Mini Body Camera.

DATA TRANSFER

To access your recorded videos and images, connect the camera to a computer or smartphone using the provided USB cable.

- **To Computer:** Connect the camera to your computer via the USB-A to Type-C cable. The camera will appear as a removable drive, allowing you to copy files.
- **To Smartphone/Tablet:** Connect the camera to your smartphone or tablet using a compatible cable (e.g., Lightning to Type-C or Type-C to Type-C). You can then manage files through your device's file manager or the dedicated app.

Upload videos/images From the Camera to phone and Computer



Check the the files on Iphone/Android via Lighting to typs-c cable or type-c to type-c cable

Check the files on Computer via provided cable usb-a to type-c

Image: The camera connected to both a smartphone and a laptop, illustrating file transfer options.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid abrasive cleaners or solvents.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the camera regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Solution
Camera not turning on	Ensure the battery is charged. Connect to a power source and try again.

Problem	Solution
Cannot record video	Check if the internal storage is full. Transfer files to free up space. Ensure the camera is powered on.
Poor video quality	Clean the camera lens. Ensure adequate lighting.
Cannot connect to app/Wi-Fi	Ensure Wi-Fi is enabled on the camera and your device. Stay within 32ft (10m) range. Restart both devices.
Waterproof case leaking	Do not use the camera in water. Check seals for damage or improper closure. Ensure no debris is obstructing the seal.

SPECIFICATIONS

Feature	Detail
Brand	Meoilkolnm
Model Name	128GB FHD 1080P Mini Body Camera with Waterproof Case
Model Number	b39c3b1e-ddf1-4faf-a515-ac55cc3e109b
Video Capture Resolution	1080p (FHD)
Video Capture Format	MP4
Supported Audio Format	AAC
Connectivity Technology	USB
Special Feature	Waterproof Case
Camcorder Type	Action Camera
Sensor Type	BSI CMOS
Water Resistance Level	Waterproof (with case)
Form Factor	Compact
Lens Type	Prime
Focus Type	Manual Focus
Compatible Devices	Smartphone, Tablet, Personal Computer
Shooting Modes	Automatic
Image Aspect Ratio	16:9
Supported Image Format	JPEG
File Format	MP4, MOV
Effective Video Resolution	1080 Pixels

SAFETY INFORMATION

- Do not expose the camera to extreme temperatures, direct sunlight for prolonged periods, or corrosive materials.
- Keep the camera and accessories out of reach of children and pets.
- Use only the provided or recommended charging cables and accessories.
- Do not attempt to disassemble or modify the camera, as this will void the warranty and may cause damage.
- Dispose of the camera and its battery responsibly according to local regulations.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or contact Meoilkolnm customer service. You can often find support contact details on the brand's official website or through your retailer.

Online Support: Visit the [Meoilkolnm Store on Amazon](#) for additional product information and support resources.

© 2023 Meoilkolnm. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FF4H8JZM>

More documents and user manuals: <https://manuals.plus/>