

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Care Bears](#) /

› [Care Bears Digital Pet Funshine Bear Instruction Manual](#)

Care Bears CB/KK1FB

Care Bears Digital Pet Funshine Bear Instruction Manual

Brand: Care Bears | Model: CB/KK1FB

1. INTRODUCTION

Welcome to the world of Care Bears Digital Pets! This manual provides comprehensive instructions for setting up, operating, and caring for your Funshine Bear Digital Pet. Designed for interactive play, this handheld virtual pet allows you to nurture, play with, and grow your very own Funshine Bear.



Figure 1: Front and back view of the Funshine Bear Digital Pet.

2. WHAT'S IN THE Box

- 1 x Care Bears Digital Pet (Funshine Bear)
- 1 x Nonstandard Battery (included and pre-installed)

3. SETUP

3.1. Powering On

Your Care Bears Digital Pet comes with a pre-installed nonstandard battery. To power on the device, locate the power button, typically on the side or back of the unit, and press it. The screen will illuminate, and your Funshine Bear will appear.

3.2. Initial Settings

Upon first power-on, you may be prompted to set the time and date. Use the control buttons (Left, Mode, Enter, Right) to navigate and adjust these settings. Refer to the 'Operating Instructions' section for general button usage.

4. OPERATING INSTRUCTIONS

Your Funshine Bear Digital Pet is an interactive virtual companion that requires daily care and attention. The device features a 1.4-inch retro pixel screen and button controls for interaction.

4.1. Basic Controls

The device is controlled using a set of buttons, typically labeled 'Left', 'Mode', 'Enter', and 'Right'. These buttons allow you to navigate menus, select actions, and interact with your Funshine Bear.

4.2. Caring for Funshine Bear

To keep your Funshine Bear happy and healthy, regular care is essential. This includes feeding, cleaning, comforting, and playing.

- **Feed:** Select the food icon from the menu to offer your Funshine Bear a meal.
- **Clean:** If your Funshine Bear makes a mess, select the cleaning icon to tidy up.
- **Comfort:** Your Funshine Bear may sometimes need comforting. Respond to its needs to maintain its happiness.
- **Play:** Engage in light-hearted mini-games to keep your Funshine Bear entertained and energized.

Gameplay



1



Nurture

2



Play

3



Feed

4



Grow

Figure 2: Examples of gameplay actions for your Digital Pet.

4.3. Interactive Features

Observe your Funshine Bear's unique personality through its signature expressions and animations on the retro pixel screen. These visual cues indicate its mood and needs.

Meet Funshine Bear



Unique Facial Expressions




Figure 3: Funshine Bear displaying unique facial expressions.

4.4. Growth and Evolution

Consistent care and interaction will allow your Funshine Bear to grow and evolve through different stages. Continue to nurture your pet to see its full development.

Your browser does not support the video tag.

Video 1: An overview of the Care Bears Digital Pets, showcasing various characters and interactive features like feeding, playing, and growing. This video highlights the different Care Bear characters available in the digital pet line.

5. KEY FEATURES

- Funshine Bear Character:** Interact with the cheerful yellow Care Bear, known for its beaming sun belly badge.
- Interactive Gameplay:** Enjoy mini-games and daily care routines to keep your digital pet happy.

- **Care & Nurture:** Responsibilities include feeding, cleaning, comforting, and playing with your Funshine Bear.
- **Signature Expressions:** Experience various animations and expressions on the retro pixel screen.
- **Portable Design:** A pocket-sized electronic toy, ideal for on-the-go entertainment.



Figure 4: Key features of the Funshine Bear Digital Pet.

6. MAINTENANCE

6.1. Cleaning

To clean your digital pet, gently wipe the exterior with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the device or screen.

6.2. Battery Care

The device uses one nonstandard battery. If the screen dims or the device becomes unresponsive, it may be time to replace the battery. Ensure proper disposal of used batteries according to local regulations.

7. TROUBLESHOOTING

- **Device Not Turning On:** Ensure the battery is correctly installed and has sufficient charge. Try replacing the battery if the issue persists.
- **Unresponsive Buttons:** Check for any debris around the buttons. If the issue continues, the device may require a battery reset (remove and reinsert the battery).
- **Screen Issues:** If the screen is dim or flickering, replace the battery. If the problem persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.36"L x 0.78"W x 2.36"H
Controller Type	Button Control
Item Weight	0.07 Kilograms (2.39 ounces)
Screen Size	1.38 Inches
Power Source	Battery Powered
Number of Batteries	1 Nonstandard Battery (included)
Age Range (Description)	8 Years + (Manufacturer recommended: 5 years and up)
Display Type	LCD
Material	Plastic
Form Factor	Mini
Item Model Number	CB/KK1FB
Manufacturer	Thumbs Up!

9. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

10. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the packaging or contact the manufacturer directly. Keep your purchase receipt for any warranty claims.