

[Manuals.plus](#) /

> [Care Bears](#) /

> Care Bears Digital Pet - Cheer Bear Nano Pet Instruction Manual

Care Bears CB/KK1CB

Care Bears Digital Pet - Cheer Bear Nano Pet

Model: CB/KK1CB

What's in the
Introduction Box Setup Operation Gameplay Features Maintenance
Troubleshooting Specifications Safety Information Warranty & Support

1. INTRODUCTION

Welcome to the world of Care Bears Digital Pets! This interactive virtual pet allows you to care for your very own Cheer Bear. Engage in daily activities, play mini-games, and watch your Cheer Bear grow and express unique emotions on its retro pixel screen. This manual provides all the information you need to get started and enjoy your new digital companion.

Meet Cheer Bear



Unique Facial Expressions



Image: The Cheer Bear Digital Pet, a bright pink device shaped like Cheer Bear's head, featuring her rainbow belly badge on the screen.

2. WHAT'S IN THE BOX

Your Care Bears Digital Pet package includes:

- 1 x Kea Kuma Digital Pet (Cheer Bear)

3. SETUP

3.1 Battery Installation

Your Care Bears Digital Pet requires 1 Nonstandard Battery (included). To install or replace the battery:

1. Locate the battery compartment on the back of the device.
2. Use a small screwdriver (not included) to open the battery compartment cover.

3. Insert the battery, ensuring correct polarity (+/-).
4. Replace the cover and secure it with the screw.

3.2 Initial Power-On and Time Setting

After battery installation, the device will power on. You may need to set the current time and date using the control buttons. Refer to the 'Operation' section for button functions.



Image: The back of the Cheer Bear Digital Pet, indicating the location of the battery compartment.

4. OPERATION

4.1 Basic Controls

The device features several control buttons for interaction:

- **Mode Button:** Cycles through different menus and options.
- **Directional Buttons (Left/Right):** Navigates within menus or selects actions.
- **Enter Button:** Confirms selections or performs actions.

4.2 Nurturing Your Cheer Bear

To keep your Cheer Bear happy and healthy, perform regular care activities:

- **Feed:** Select the food icon to offer meals when your Cheer Bear is hungry.
- **Clean:** Keep your Cheer Bear's environment tidy by selecting the cleaning option.
- **Comfort:** Provide comfort and attention when your Cheer Bear seems sad or lonely.
- **Play:** Engage in mini-games to boost your Cheer Bear's happiness.



Image: A close-up of the Cheer Bear Digital Pet, highlighting its interactive display, control buttons, and keychain attachment.

5. GAMEPLAY

The Cheer Bear Digital Pet offers interactive gameplay and daily care activities designed to engage users. The retro pixel screen displays Cheer Bear's actions and emotions.

5.1 Interactive Mini-Games

Play cheerful mini-games to keep your Cheer Bear entertained. These games contribute to your pet's


happiness and growth.



Image: A visual representation of the gameplay options on the Cheer Bear Digital Pet screen, including Nurture, Play, Feed, and Grow.

5.2 Growth and Evolution

As you care for your Cheer Bear, it will progress through different stages of growth. Consistent care and interaction are key to its development.



6. FEATURES

The Care Bears Digital Pet is designed with several features to enhance your interactive experience:

- **Interactive Display Screen:** A 1.4-inch retro pixel screen brings Cheer Bear to life.
- **Control Buttons:** Easy-to-use buttons for navigation and interaction.
- **Keychain:** A convenient keychain allows you to carry your digital pet anywhere.
- **Unique Facial Expressions:** Watch Cheer Bear beam, sparkle, and delight with various expressions.



Image: A detailed view of the Cheer Bear Digital Pet, illustrating its interactive display, physical control buttons, keychain, and the unique facial expressions of the character.



Image: The Cheer Bear Digital Pet showcasing its original design from both front and back views.

6.1 Official Product Video

Your browser does not support the video tag.

Video: An official video introducing the Care Bears Digital Pets, highlighting their features and interactive nature.

7. MAINTENANCE

7.1 Cleaning

To clean your Care Bears Digital Pet, gently wipe the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

7.2 Battery Care

If the device's battery life seems short or inconsistent, consider replacing the battery with a fresh one. Ensure the battery compartment is securely closed after replacement.

8. TROUBLESHOOTING

8.1 Device Resets Unexpectedly

If your Care Bears Digital Pet resets frequently, especially after pressing buttons, check the battery compartment. Ensure the battery is properly seated and the cover is securely fastened. A loose connection can cause unexpected resets.

8.2 Pet Appears Sad or Unresponsive

If your Cheer Bear seems sad or unresponsive, it may require more attention. Ensure you are regularly feeding, cleaning, comforting, and playing with it. Consistent interaction is crucial for its well-being.

9. SPECIFICATIONS

Screen Size	1.38 Inches
Number of Batteries	1 Nonstandard Battery (included)
Is Assembly Required	No
Platform	Custom
Size	Small
Item Dimensions L x W x H	2.36"L x 0.78"W x 2.36"H
Item Weight	0.07 Kilograms
Color	Cheer Bear
Theme	Animal
Subject Character	Cheer Bear (Care Bears)
Material Type	Plastic
Age Range Description	8 Years +
Model Number	CB/KK1CB
Manufacturer	Thumbs Up!

10. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

11. WARRANTY AND SUPPORT

This product comes with a **1 Year Manufacturer Warranty**. For support or warranty claims, please refer to the manufacturer's contact information provided with your purchase or visit the official Care Bears store on Amazon: [Care Bears Store](#).