DEZLTID M148-EEA

DEZLTID Android 15 Tablet 11 Inch User Manual

Model: M148-EEA

1. Introduction

This manual provides essential information for the safe and effective use of your DEZLTID Android 15 Tablet. Please read this manual thoroughly before operating the device and retain it for future reference. Your tablet is designed for versatile use, offering a high-resolution display, powerful processing, and a suite of accessories for enhanced productivity and entertainment.



Image 1.1: The DEZLTID Android 15 Tablet, showcasing its sleek design and accompanying accessories including a keyboard, stylus, and mouse.

2. Package Contents

Verify that all items listed below are present in your product package:

- DEZLTID Android 15 Tablet (10.95 inch, Gray)
- Keyboard
- Mouse
- Stylus
- Protective Case
- Screen Protector (pre-applied)
- Card Pin (SIM/TF card tray ejector)
- Fast Charger
- OTG Cable
- User Manual




Image 2.1: A comprehensive view of all items included in the DEZLTID Android 15 Tablet package, such as the tablet, keyboard, mouse, stylus, case, and charging accessories.

3. Product Overview

3.1 Display and Audio

The tablet features an 11-inch 2K IPS display with a resolution of 2000x1200 pixels, offering clear and vibrant visuals. It utilizes G+G double glazing for durability and provides a 178° viewing angle. The 16:10 aspect ratio and 84.9% screen-to-body ratio enhance the

viewing experience. Dual BOX speakers deliver rich audio. Widevine L1 support enables high-definition streaming from compatible services.



Image 3.1: The tablet's display showcasing its 2K resolution, Widevine L1 support, eye-care features, 16:10 aspect ratio, and wide viewing angles.

3.2 Performance

Equipped with a T606 octa-core CPU and Mali-G57 GPU, the tablet delivers efficient performance for various tasks. It includes 36GB of LPDDR4X RAM and 256GB of internal storage, which can be expanded up to 1TB using a TF (microSD) card (sold separately).



Image 3.2: A close-up of the tablet's T606 octa-core processor, highlighting its role in delivering smooth performance and efficient multitasking.



Image 3.3: Visual representation of the tablet's 36GB RAM and 256GB internal storage, emphasizing its capacity for applications and media.

3.3 Operating System

The tablet runs on Android 15, providing an intuitive and accessible user experience. Features include 200% font scaling, a blue light filter for eye comfort, voice reading, Focus Mode for productivity, and robust data security with app lock capabilities. The device is GMS Certified, ensuring access to Google services.

3.4 Battery

An 8000mAh battery powers the tablet, designed for extended use with power-saving technology. It supports Type-C fast charging

for quick recharging.



Image 3.4: An illustration of the tablet's 8000mAh battery, highlighting its capacity for prolonged usage and efficient power management.

3.5 Cameras

The tablet is equipped with an 8MP front camera and a 13MP rear camera with flash, suitable for video calls, photography, and document scanning.



Image 3.5: A visual representation of the tablet's 8MP front and 13MP rear cameras, indicating their placement and capabilities for capturing images and video.

3.6 Connectivity

The tablet supports 5G/2.4G Dual WiFi (802.11a/b/g/n/ac) for seamless internet access and Bluetooth 5.0 for connecting peripherals. It also includes GPS for navigation and OTG (On-The-Go) functionality for connecting USB devices.

4. Setup

4.1 Initial Charging

Before first use, fully charge the tablet using the provided fast charger and Type-C cable. The charging indicator will show the charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the DEZLTID logo appears on the screen.
- **To Power Off:** Press and hold the Power button until the power options appear. Select "Power Off" and confirm.

4.3 Inserting TF Card

To expand storage, insert a TF (microSD) card into the designated slot. Use the provided card pin to eject the tray. Ensure the tablet is powered off before inserting or removing the card.

4.4 Connecting Accessories

- **Keyboard:** The keyboard connects wirelessly via Bluetooth. Refer to the keyboard's specific instructions for pairing.
- **Mouse:** The mouse also connects wirelessly via Bluetooth. Follow the mouse's pairing instructions.
- **Stylus:** The stylus is designed for touch interaction and does not require pairing.

5. Operation

5.1 Basic Navigation

Navigate the Android 15 interface using touch gestures. Swipe down from the top for notifications and quick settings, swipe up from the bottom for the app drawer, and use the on-screen navigation buttons (Home, Back, Recent Apps).

5.2 Display Settings

Access display settings to adjust brightness, enable the blue light filter for reduced eye strain, and utilize the 200% font scaling feature for improved readability.

5.3 Multitasking and Productivity

Android 15 supports split-screen mode for running multiple applications simultaneously. Use Focus Mode to manage time and content, enhancing concentration during work or study.

5.4 Security Features

Protect your data with built-in security features, including app lock functionality and multi-layer encryption. The operating system is designed to isolate app permissions and block malicious content.

5.5 OTG Functionality

The tablet supports USB On-The-Go (OTG), allowing you to connect compatible USB devices such as flash drives, external hard drives, or other peripherals using the provided OTG cable.

6. Maintenance

6.1 Cleaning

Use a soft, lint-free cloth to clean the tablet screen and body. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

6.2 Software Updates

Periodically check for system updates to ensure your tablet has the latest features, security patches, and performance improvements. Connect to Wi-Fi and navigate to Settings > System > System update.

6.3 Storage Management

Regularly manage your tablet's storage by deleting unnecessary files, uninstalling unused apps, and moving large media files to

external storage (TF card or cloud services) to maintain optimal performance.

7. Troubleshooting

- **Tablet does not power on:** Ensure the tablet is fully charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, press and hold the power button for 10-15 seconds for a forced restart.
- **Screen is unresponsive:** Restart the tablet. If the issue persists, ensure the screen is clean and free of debris.
- **Wi-Fi connection issues:** Check if Wi-Fi is enabled in settings. Restart your Wi-Fi router. Forget the network and reconnect.
- **Accessories (Keyboard/Mouse) not connecting:** Ensure Bluetooth is enabled on the tablet. Put the accessory in pairing mode. Refer to the accessory's specific instructions for pairing.
- **Slow performance:** Close unused applications. Clear cache data. Ensure sufficient free storage space. Restart the tablet periodically.
- **Apps crashing:** Ensure the app is updated to the latest version. Clear the app's cache and data (Settings > Apps > [App Name] > Storage). If the problem continues, reinstall the app.

8. Specifications

Feature	Specification
Model	M148-EEA
Operating System	Android 15
Display Size	10.95 Inches
Display Resolution	2000x1200 (2K IPS)
Processor	T606 Octa-Core CPU
Graphics Processor	Mali-G57
RAM	36GB (LPDDR4X)
Internal Storage	256GB
Expandable Storage	Up to 1TB (via TF card, not included)
Battery Capacity	8000mAh
Front Camera	8MP
Rear Camera	13MP with Flash
Wireless Connectivity	5G/2.4G Dual-Band Wi-Fi (802.11a/b/g/n/ac), Bluetooth 5.0
Ports	Type-C, OTG support
Color	Gray
Weight	512.56 g (1.13 lbs)
Thickness	8.1 mm (0.32 inches)
Certifications	FCC/CE, GMS Certified
Widevine Support	L1

9. Warranty and Support

DEZLTID is committed to providing high-quality service and support for your product.

- **Warranty:** Your tablet comes with a 1-year warranty and refund policy.
- **Technical Support:** Lifetime technical support is available for your DEZLTID tablet.
- **Customer Service:** A dedicated 24-hour service team is ready to assist you with any problems or inquiries.

For assistance, please refer to the contact information provided on the DEZLTID official website or the product packaging.

© 2025 DEZLTID. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question