

SUPERLEX SSV002DE

SUPERLEX SSV002DE 1050W Handheld Steam Cleaner User Manual

Model: SSV002DE | Brand: SUPERLEX

1. INTRODUCTION

Thank you for choosing the SUPERLEX SSV002DE 1050W Handheld Steam Cleaner. This powerful and versatile steam cleaner is designed for effective and hygienic cleaning across various surfaces in your home, car, and more. With its high-pressure steam and range of accessories, it tackles tough dirt, grease, and stains without the need for harsh chemicals.

Carefully unpack your SUPERLEX SSV002DE Handheld Steam Cleaner and check that all items are present and in good condition. The package includes:

- SUPERLEX Handheld Steam Cleaner Unit
- Measuring Cup
- Funnel
- Flexible Hose
- Long Nozzle Adapter
- Bent Nozzle Head
- Round Brushes (x3)
- Window Squeegee
- Ironing Brush
- Cloth Cover



Image 2: All included accessories for the SUPERLEX SSV002DE Handheld Steam Cleaner, including various nozzles and brushes.

4. SETUP

Follow these steps to prepare your steam cleaner for use:

1. **Unscrew the Safety Cap:** Ensure the unit is unplugged and cool. Turn the safety cap counter-clockwise to open.
2. **Fill the Water Tank:** Use the provided measuring cup and funnel to fill the 350ml water tank with clean tap water. Do not overfill.
3. **Secure the Safety Cap:** Screw the safety cap clockwise until it is tightly closed. This cap is designed to prevent opening under pressure.
4. **Attach Desired Accessory:** Select the appropriate nozzle or brush for your cleaning task and securely attach it to the steam cleaner's outlet.

Dampfreiniger – Vielseitig Einsetzbar



Image 3: Visual guide for filling the water tank and preparing the steam cleaner for operation.

5. OPERATING INSTRUCTIONS

Once set up, follow these steps to operate your steam cleaner:

1. **Power On:** Plug the power cord into a suitable electrical outlet. The indicator light will illuminate, signaling that the unit is heating up.
2. **Heating Time:** The steam cleaner will heat up rapidly, typically within 3-5 minutes. The indicator light will turn off when the optimal steam pressure is reached.
3. **Release Steam:** Press and hold the steam trigger to release a continuous jet of high-pressure steam. For intermittent steam, release and press the trigger as needed.
4. **Cleaning:** Direct the steam towards the surface you wish to clean. The 180° rotating nozzle allows for easy access to tight corners and difficult areas. The 4-meter power cable provides ample reach.
5. **Versatile Cleaning:** Use the various attachments for different tasks:
 - **Round Brushes:** Ideal for scrubbing stubborn dirt on grout, oven racks, and small areas.
 - **Window Squeegee:** For streak-free cleaning of windows, mirrors, and glass surfaces.
 - **Ironing Brush & Cloth Cover:** For refreshing fabrics, upholstery, and removing wrinkles.
 - **Bent Nozzle Head:** Perfect for reaching into crevices, corners, and around fixtures.
6. **Disinfection:** The high-temperature steam effectively disinfects surfaces, killing up to 99.9% of common bacteria and viruses.
7. **Power Off:** When finished, release the steam trigger, unplug the unit, and allow it to cool down completely before storing.

Dampfreiniger Handgerät



350ml
Wassertank



10 Minuten
Dauerbetrieb



180° Düsenkopf



4m Netzkabel



1050W
Leistung



Image 4: The steam cleaner effectively cleaning a kitchen sink, demonstrating its powerful steam output.

Einfache Sichere Handhabung



1
Nach dem Wasser
hinzufügen
Deckel fest verschließen



2
3-5 Min erhitzen
bis Licht erlischt



3
Dampftaste drücken
Dampfausstoß erfolgt langsam



Image 5: The steam cleaner's versatility for various cleaning tasks, including stubborn stains, windows, dust, and textiles.

Desinfizierender Handdampfreiniger

Tötet bis zu 99,9% der gängigen Bakterien und Viren für eine effektive Desinfektion.



Image 6: The steam cleaner being used to disinfect a bed, highlighting its sanitizing capabilities.



Image 7: Illustration of the steam cleaner's 1050W power and constant 110°C hot steam for quick heating and effective cleaning.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your steam cleaner.

- **Empty Water Tank:** After each use, ensure the unit is cool and depressurized, then carefully open the safety cap and empty any remaining water.
- **Clean Accessories:** Wash detachable nozzles and brushes with warm, soapy water. Rinse thoroughly and allow them to air dry.
- **Wipe Down Unit:** Wipe the exterior of the steam cleaner with a damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling (Periodically):** Depending on water hardness, mineral deposits may build up. If steam output decreases, descale the unit using a vinegar solution or a commercial descaling agent designed for steam appliances. Follow the descaling product's instructions carefully.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. TROUBLESHOOTING

If you encounter any issues with your steam cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated sufficiently; Mineral buildup.	Refill water tank; Wait for indicator light to turn off; Perform descaling procedure.
Water leaking from nozzle	Accessory not properly attached; Unit not fully heated.	Ensure accessory is securely fastened; Wait for indicator light to turn off before use.
Safety cap cannot be opened	Unit is still pressurized or hot.	Unplug the unit and allow it to cool down completely. Release any remaining pressure by pressing the steam trigger until no more steam is emitted.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

- **Model Number:** SSV002DE
- **Power:** 1050 W
- **Steam Pressure:** 3.5 bar
- **Water Tank Capacity:** 350 ml
- **Heating Time:** 3-5 minutes
- **Cable Length:** 4 meters
- **Product Dimensions:** 26 x 23 x 15 cm
- **Product Weight:** 1.5 kg
- **Special Feature:** Child Lock
- **Form Factor:** Handheld

12 in 1
Haushalt
**Dampfreiniger
Handgerät**
1050W
LEISTUNG



Vielseitig

DESINFIZIERT
**TÖTET
99.8%**
SCHÄDLICHE BAKTERIEN
UND VIREN



ULTRASCHNELLE FLECKENTFERNUNG

*Dank der starken Leistung von 1050W heizt es in nur 3 Minuten extrem schnell auf.

Image 8: Dimensions of the SUPERLEX SSV002DE Handheld Steam Cleaner.

9. WARRANTY AND SUPPORT

Your SUPERLEX SSV002DE Handheld Steam Cleaner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact the seller or manufacturer directly through the platform where you purchased the product. Have your model number (SSV002DE) and purchase details ready when contacting support.