

[Manuals.plus](#) /

› [Holiday Essence](#) /

› Holiday Essence 60 LED Mini Christmas Lights User Manual (Cool White, Green Wire, Model YOS60/2SW)

Holiday Essence YOS60/2SW

Holiday Essence 60 LED Mini Christmas Lights User Manual

Model: YOS60/2SW - Cool White, Green Wire

1. PRODUCT OVERVIEW

The Holiday Essence 60 LED Mini Christmas Lights are designed for both indoor and outdoor decorative lighting. This set features 60 cool white LED bulbs on a green wire, providing a bright and festive glow. The lights are UL certified, ensuring safety and reliability for various applications.

Key features include:

- **Professional Grade:** High-quality LED mini lights suitable for indoor and outdoor use with UL Listed certification.
- **Lighting Specifications:** 60 cool white LED bulbs on green wire, creating a bright, festive glow.
- **Energy Efficient:** LED technology provides long-lasting illumination with minimal power consumption.
- **Versatile Design:** Green wire blends seamlessly with Christmas trees and holiday greenery.
- **Durable Construction:** Weather-resistant materials ensure reliable performance.



Image 1.1: Close-up view of the cool white LED bulbs and green wire.

2. SAFETY GUIDELINES

Please read and follow all safety instructions to prevent injury or damage. This product is UL certified for safety.

- **Indoor and Outdoor Use:** These lights are designed for both indoor and outdoor applications. Ensure all connections are secure and protected from direct water exposure when used outdoors.
- **Electrical Safety:** Always unplug the lights from the power source before installation, maintenance, or when not in use. Do not overload electrical outlets.
- **Damage Inspection:** Regularly inspect the light set for any damage to the wire insulation, bulbs, or plugs. Do not use if damaged.
- **Bulb Handling:** Do not twist bulbs when inserting or removing. Follow the bulb replacement instructions carefully.
- **Children and Pets:** Keep lights out of reach of small children and pets to prevent choking hazards or electrical shock.
- **Flammable Materials:** Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- **Secure Installation:** Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.

3. PACKAGE CONTENTS

Your Holiday Essence 60 LED Mini Christmas Lights package includes the following items:

- 1 x 60 LED Mini Christmas Light Strand (Cool White, Green Wire)
- 2 x Replacement Bulbs
- 2 x Replacement Fuses



Image 3.1: Included components: light strand, replacement bulbs, and fuses.

4. SETUP AND INSTALLATION

4.1 Connecting Multiple Sets

These lights are designed to be connectable end-to-end. You can connect up to 45 strings of these lights together to cover larger areas. Ensure that the total wattage of all connected strings does not exceed the maximum recommended load for your electrical circuit.




Image 4.1: Example of connecting multiple light sets.

4.2 Placement

The green wire blends well with natural greenery, making these lights ideal for decorating Christmas trees, wreaths, and garlands. Their durable, weather-resistant construction allows for versatile placement both indoors and outdoors.

- **Indoor Applications:** Perfect for decorating Christmas trees, mantels, stair railings, and windows.
- **Outdoor Applications:** Suitable for illuminating rooftops, garden bushes, patios, and outdoor trees.

PRODUCT DETAILS





 1. Pull the lamp straight out of the socket	 2. Remove old lamp from inner base by bending leads straight.	 3. Insert leads on new lamp in holes in base and bend upwards as shown	 4. Push new lamp and base Do not twist.	⚠ WARNING: To avoid electric shock make certain the lamp leads do not extend beyond point A, or out of socket. Trim leads if necessary 
---	---	--	--	---

Image 4.2: Examples of outdoor light applications.

Package included




Image 4.3: Examples of indoor and outdoor window decorations.

5. OPERATING INSTRUCTIONS

To operate the Holiday Essence 60 LED Mini Christmas Lights, simply plug the male end of the light string into a standard electrical outlet. The lights will illuminate immediately. To turn off, unplug the light string from the outlet.

6. MAINTENANCE

6.1 Bulb Replacement

If a bulb burns out, it can be replaced using the provided spare bulbs. Follow these steps:

1. **Pull Lamp Straight Out:** Gently pull the non-working lamp straight out of its socket.
2. **Remove Old Lamp:** Remove the old lamp from its inner base by bending the leads straight.
3. **Insert New Lamp:** Insert the leads on the new lamp into the base and bend them upwards as shown in the diagram.
4. **Push New Lamp and Base:** Push the new lamp and base firmly into the socket. Do not twist.

WARNING: To avoid electric shock, maintain certain lamp leads. Do not extend beyond point A, or out of the socket. Trim leads if necessary.



For indoor and outdoor use



Image 6.1: Bulb replacement instructions.

6.2 Fuse Replacement

If the entire string of lights fails to illuminate, check the fuse located in the male plug. To replace the fuse:

1. Unplug the light string from the power outlet.
2. Slide open the fuse compartment cover on the plug.
3. Carefully remove the old fuse.
4. Insert a new fuse of the same type and rating (spare fuses are included).
5. Close the fuse compartment cover securely.

6.3 Cleaning and Storage

Before cleaning or storing, ensure the lights are unplugged. Wipe the bulbs and wires with a soft, dry cloth. Store the lights in a cool, dry place, preferably in their original packaging or a protective container, to prevent tangling and damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lights do not turn on.	No power to the outlet, loose plug, blown fuse, or damaged wire.	Check power outlet. Ensure plug is fully inserted. Replace fuse in the plug (see Section 6.2). Inspect wire for damage.
Only part of the light string is lit.	One or more bulbs are loose or burnt out.	Check and tighten all bulbs. Replace any burnt-out bulbs (see Section 6.1).
Lights flicker.	Loose bulb connection or intermittent power.	Ensure all bulbs are securely seated. Check power source for stability.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Holiday Essence
Model Number	YOS60/2SW
Light Color	Cool White
Wire Color	Green
Number of Lights	60 LED bulbs
Total Length	16 feet (192 inches)
Bulb Spacing	6 inches
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor, Outdoor
Certification	UL Certified
Material	Plastic
Color Temperature	5000 Kelvin
Luminous Flux	500 lumen
Ingress Protection (IP) Rating	IPX4
UPC	710413076232

9. WARRANTY AND CUSTOMER SUPPORT

For information regarding warranty coverage or to obtain customer support, please contact Holiday Essence directly through their official website or the retailer where the product was purchased. Please have your model number (YOS60/2SW) and purchase date available when contacting support.

