



Manuals.plus /

› Samsung /

› Samsung Galaxy Tab S10 Lite User Manual - 10.9" LCD Tablet with S Pen

Samsung S10 Lite

Samsung Galaxy Tab S10 Lite User Manual

Model: S10 Lite (SM-X400NZANXAR)

Introduction	What's in the Box	Setup	Operating Warranty & Support	Maintenance	Troubleshooting
	Specifications				

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Samsung Galaxy Tab S10 Lite. Please read it thoroughly before using your device to ensure optimal performance and longevity.

The Samsung Galaxy Tab S10 Lite is a versatile tablet featuring a 10.9-inch LCD display, an S Pen for precise input, and an Exynos 1380 processor for smooth performance. It is designed for both entertainment and productivity, offering intelligent features and seamless connectivity within the Galaxy ecosystem.



Image: The Samsung Galaxy Tab S10 Lite in Gray, shown with its S Pen, highlighting its sleek design and display.

2. WHAT'S IN THE BOX

Verify that all items are present in your product packaging:

- Samsung Galaxy Tab S10 Lite
- S Pen
- USB-C Data Cable
- Ejection Pin
- Quick Start Guide

What's in the box



Galaxy Tab S10 Lite Gray



S Pen



USB-C Data Cable



Ejection Pin

Image: A visual representation of the items included in the Samsung Galaxy Tab S10 Lite packaging: the tablet, S Pen, USB-C data cable, and ejection pin.

Note: A wall charger is sold separately. Use only Samsung-approved chargers and USB-C cables to avoid damage to your device.

3. INITIAL SETUP

3.1. Charging the Device

1. Connect the USB-C data cable to the tablet's charging port.
2. Connect the other end of the cable to a compatible USB wall charger (sold separately).
3. Allow the tablet to charge until the battery indicator shows a full charge.

3.2. Powering On/Off

- To power on: Press and hold the Power button until the Samsung logo appears.
- To power off: Press and hold the Power button, then tap 'Power off' on the screen.
- To restart: Press and hold the Power button, then tap 'Restart' on the screen.

3.3. Initial Configuration

Follow the on-screen prompts to complete the initial setup, which includes:


- Selecting your language and region.
- Connecting to a Wi-Fi network.
- Signing in with your Samsung or Google account.
- Setting up security features (PIN, pattern, password, fingerprint).
- Transferring data from a previous device (optional).

4. OPERATING YOUR TABLET

4.1. Display and Visual Experience

The Galaxy Tab S10 Lite features a vibrant 10.9-inch LCD display. The Vision Booster technology automatically adjusts screen brightness to your environment, ensuring clear visibility whether indoors or outdoors. Enjoy streaming, browsing, and reading with enhanced visual comfort.

Dive into this display



Screen Size

10.9"

Refresh Rate

90 Hz

Image: The tablet's 10.9-inch display showcasing a high-resolution image of a beach at sunset, emphasizing its visual quality.

4.2. S Pen Functionality


The included S Pen offers precise control for various tasks. Its responsive design allows for natural drawing, note-taking, and even mathematical calculations within compatible applications like Samsung Notes.

- **Note-Taking:** Use the S Pen to jot down notes, create lists, and annotate documents.
- **Drawing & Sketching:** Unleash creativity with various brush and pen tools.
- **Math Solver:** Solve handwritten mathematical problems directly in Samsung Notes.
- **Handwriting Assist:** Tidy up your handwritten notes for better readability.


Write, draw, do it all with S Pen

Math Solver

Solve handwritten math problems on the spot



Available in Samsung Notes app. Legibility of handwriting can impact accuracy of calculations.



Compatible with Samsung Notes app only. English language preinstalled, select other languages available for download. Accuracy may vary.

Handwriting Assist

Tidy up your handwritten notes

Image: The S Pen being used on the tablet screen to solve a math problem and to activate handwriting assist features in Samsung Notes.

4.3. Performance and Storage

Powered by the Exynos 1380 processor, the Galaxy Tab S10 Lite handles streaming, browsing, and multitasking with ease. It comes with 128GB of internal storage, expandable by up to 2TB using a microSD card (sold separately), providing ample space for your apps, photos, and videos.

Processor and memory

Performance you can count on
with space to keep what matters



Storage
Up to 256GB

Memory
Up to 8GB

External storage support
microSD (up to 2TB)

Portion of storage / memory occupied by existing content. microSD card sold separately.

Long-lasting battery



Battery

Up to 16 hours of battery life

Based on local, 720p resolution video playback, default video player (full screen), 162 nit brightness, earbud volume 7, Wi-Fi and mobile network off. Results vary with settings, usage and other factors.

Image: A graphic illustrating the tablet's specifications including up to 256GB storage, up to 8GB memory, and microSD expansion up to 2TB, alongside battery life information.

4.4. AI Tools and Smart Features

The tablet integrates intelligent features to simplify daily tasks:

- **Circle to Search:** Quickly search for information on your screen by circling an object or text.
- **AI Hot Key:** Access AI functionalities directly from a compatible keyboard (sold separately) for web searches, scheduling, and more.
- **Object Eraser:** Edit photos by easily removing unwanted objects from images.

One-tap access to AI



AI Key function requires Samsung Book Cover Keyboard / AI Key or Samsung Book Cover Keyboard Slim / AI Key (sold separately).

Image: The tablet connected to a keyboard accessory, highlighting the AI Hot Key for quick access to artificial intelligence features.

Instant edits with Object Eraser

Before



After



Results may vary based on the overall image and the object being removed.

Image: A before-and-after comparison demonstrating the Object Eraser feature, showing an unwanted object removed from a photograph on the tablet screen.

4.5. Galaxy Ecosystem Connectivity

Your Galaxy Tab S10 Lite seamlessly connects with other Samsung Galaxy devices. You can answer calls, continue notes, and control smart home devices through SmartThings Map View directly from your tablet.

Your Galaxy devices, connected



Both the Galaxy Tab S10 Lite and a Galaxy mobile phone are required to have One UI 3.1 or later. Devices must be logged in to the same Samsung account and be on the same Wi-Fi network. Products sold separately.

Image: The Galaxy Tab S10 Lite displayed alongside a Galaxy smartphone and earbuds, illustrating the seamless connectivity within the Samsung Galaxy ecosystem.

5. BATTERY MANAGEMENT

The Galaxy Tab S10 Lite is equipped with a long-lasting battery, providing up to 16 hours of video playback. When charging is needed, Super Fast Charging allows for a full charge in approximately two hours (with a 45W wall charger, sold separately).

- To optimize battery life, reduce screen brightness, disable unused features like Wi-Fi or Bluetooth when not needed, and close background applications.
- Avoid exposing the device to extreme temperatures, which can affect battery performance.

6. MAINTENANCE

6.1. Cleaning Your Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.

- Avoid using harsh chemicals, abrasive materials, or aerosol sprays directly on the device.

6.2. Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. You can usually find this option in the device settings under 'Software update'.

6.3. Storage Management

Periodically review your installed applications, photos, and videos. Delete unnecessary files or transfer them to cloud storage or a microSD card to free up internal storage and maintain optimal performance.

7. TROUBLESHOOTING

If you encounter issues with your Galaxy Tab S10 Lite, try the following common troubleshooting steps:

- **Device Not Responding:** Press and hold the Power button and Volume Down button simultaneously for about 7 seconds to force a restart.
- **App Issues:** Try clearing the app's cache and data (Settings > Apps > [App Name] > Storage > Clear cache/Clear data) or uninstalling and reinstalling the app.
- **Connectivity Problems:** Restart your Wi-Fi router or Bluetooth device. On your tablet, toggle Wi-Fi/Bluetooth off and on.
- **Slow Performance:** Close unused apps, clear cache, or restart the device. Consider a factory reset as a last resort (back up your data first).
- **S Pen Not Working:** Ensure the S Pen is properly seated in its charging slot (if applicable) or check for any physical damage. Restart the tablet.

For more complex issues, refer to the Samsung support website or contact customer service.

8. SPECIFICATIONS

Feature	Detail
Model Name	S10 Lite (SM-X400NZANXAR)
Display Size	10.9 Inches
Display Resolution	2112 x 1320 Pixels
Operating System	Android
RAM Memory	6 GB
Storage Capacity	128 GB (Expandable up to 2TB with microSD)
Processor	Exynos 1380
GPU	ARM
Connectivity	Wi-Fi
Special Features	Stylus Support (S Pen included)
Battery Power Rating	8000 mAh
Item Weight	1.16 pounds
Product Dimensions	6.53 x 10.01 x 0.26 inches
Color	Gray

9. WARRANTY AND SUPPORT

9.1. Warranty Information

Your Samsung Galaxy Tab S10 Lite comes with a limited manufacturer's warranty. Please refer to the warranty card included in your packaging or visit the official Samsung website for detailed terms and conditions, including coverage period and exclusions.

9.2. Customer Support

For technical assistance, troubleshooting, or service inquiries, please contact Samsung Customer Support:

- **Online Support:** Visit the official Samsung support website (samsung.com/us/support/) for FAQs, downloads, and service requests.
- **Phone Support:** Refer to your Quick Start Guide or the Samsung support website for regional contact numbers.

Please have your device model number (SM-X400NZANXAR) and serial number ready when contacting support.