

PROALLER OB20U-003

PROALLER Heated Blanket 200 x 150 cm

Model: OB20U-003


INTRODUCTION

Thank you for choosing the PROALLER Heated Blanket. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your heated blanket. Please read these instructions carefully before first use and retain them for future reference.


IMPORTANT SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage to the blanket or injury, please observe the following safety guidelines:


- Always unplug the blanket from the power outlet when not in use or before cleaning.
- Do not fold or curl the blanket tightly during use. This can cause localized overheating.
- Do not press or place heavy objects on the blanket while it is operating.
- Do not use this heated blanket in conjunction with other heating products (e.g., electric mattress pads, hot water bottles).
- Avoid situations that may cause the blanket to overheat locally, as this can lead to malfunction.
- Keep the controller dry and away from water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.



Please don't fold or curl up



Please don't press the blanket.



Please do not use with other heating products

Kind tips:

Please avoid the above situations during use. Because this will cause the blanket to overheat locally and cause it to no longer work.

Figure 1: Important safety warnings to prevent overheating and damage.

PRODUCT OVERVIEW

The PROALLER Heated Blanket is designed for comfort and warmth, featuring a double-sided design and multiple heat settings. Its generous size makes it suitable for use on sofas, settees, or beds.

- **Material:** One side features soft flannel, and the other side features plush Sherpa for maximum comfort.
- **Size:** 200 x 150 cm, providing ample coverage.
- **Heating:** Designed for fast heating and energy efficiency.



Figure 2: Double-sided design with soft flannel and plush Sherpa.



Figure 3: Blanket in use, highlighting fast heating and energy-efficient features.

SETUP

Follow these steps to set up your heated blanket:

1. Unpack the heated blanket and its controller from the packaging.
2. Lay the blanket flat on your desired surface (bed, sofa). Ensure there are no folds or creases.
3. Locate the connector on the blanket and firmly plug in the controller cable. Ensure a secure connection.
4. Plug the power cord of the controller into a standard electrical outlet.
5. The blanket is now ready for operation.

OPERATING INSTRUCTIONS

Your PROALLER Heated Blanket features a user-friendly controller with adjustable heat and timer settings.



Figure 4: Controller with heat and time settings.

Heat Settings

- The blanket offers 10 adjustable heat settings, allowing you to customize your warmth level.
- Press the heat button (usually indicated by a temperature icon or 'Heat') to cycle through the available settings.
- Start with a lower setting and increase gradually until you find your preferred comfort level.



Figure 5: Illustration of the blanket's heating area and 10 heat settings.

Timer Settings

- The blanket includes a timer function, allowing you to set an automatic shut-off time from 1 to 9 hours.
- Press the timer button (usually indicated by a clock icon or 'Timer') to select your desired operating duration.
- The blanket will automatically turn off after the set time has elapsed.

MAINTENANCE

Proper care will extend the life of your heated blanket. Always follow these cleaning instructions:

- **Before Washing:** Always unplug the power connector from the blanket and the wall outlet. Ensure the controller is completely detached.
- **Washing:** The blanket is machine washable. Use a gentle cycle with cold or lukewarm water. Do not use hot water.
- **Drying:** Tumble dry on a low heat setting or line dry. Ensure the blanket is completely dry before reconnecting the controller and using it.
- **Do Not:** Dry-clean, iron, bleach, or wring the blanket. These actions can damage the internal heating elements.



Figure 6: Visual guide for cleaning and care instructions.

TROUBLESHOOTING

If you encounter any issues with your heated blanket, please refer to the following common problems and solutions:

- **Blanket not heating:**

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check that the controller is firmly connected to the blanket.
- Verify that the heat setting is turned on and not set to 'off' or '0'.
- If the blanket has an auto-shutoff feature, check if the timer has expired.

- **Blanket overheating or uneven heating:**

- Immediately unplug the blanket.
- Ensure the blanket is laid flat and not folded, bunched, or pressed by heavy objects during use.
- Do not use with other heating devices.
- Allow the blanket to cool completely before attempting to use it again. If the problem persists, discontinue use.

- **Controller display not working:**

- Unplug the blanket from the wall and disconnect the controller from the blanket. Wait a few minutes, then reconnect everything and plug it back in.
- Ensure the power outlet is functional by testing it with another appliance.

If these steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Attribute	Detail
Brand	PROALLER
Model Number	OB20U-003
ASIN	B0FF5VLLYJ
UPC / GTIN	716597876750
Dimensions	200 x 150 cm
Material	Flannel, Sherpa Plush
Color	Grey
Shape	Sofa Throw Blanket
Recommended Use	Home
Seasons	Winter
Care Instructions	Machine Wash
Package Dimensions	35.4 x 31 x 11.1 cm
Package Weight	2.19 kg

WARRANTY AND SUPPORT

Specific warranty details and customer support contact information are not available in the provided product data. For warranty claims or technical assistance, please refer to the product packaging or contact the retailer where the product was purchased. You may also visit the official PROALLER website for further support.