

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SOAR](#) /
- › [SOAR NFL True Wireless Earbuds v.7 San Francisco 49ers User Manual](#)


SOAR NFL-TWS7

SOAR NFL True Wireless Earbuds v.7 San Francisco 49ers User Manual

INTRODUCTION

Thank you for choosing the SOAR NFL True Wireless Earbuds v.7. These earbuds are designed to provide a high-quality audio experience with the convenience of wireless technology, allowing you to enjoy music and calls while representing your favorite NFL team. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your earbuds. These earbuds feature Bluetooth 5.0 technology for stable connectivity, a portable charging case with an LED display for battery status, and intuitive control buttons for easy management of audio and calls.

WHAT'S IN THE BOX



The product package includes:

- Stereo Earbuds (2)
- Wireless Charging Case
- Charging Cable
- Eartips (various sizes)

The image shows the retail packaging for the SOAR NFL True Wireless Earbuds v.7, highlighting the San Francisco 49ers team branding on the earbuds and charging case, along with key features like the digital display and playtime.

SETUP

1. Charging the Earbuds and Case



Before first use, fully charge the earbuds and the charging case. Connect the provided USB charging cable to the charging port on the case and a compatible USB power source. The LED digital display on the charging case will indicate the battery level during charging. A full charge provides approximately 10 hours of earbud playtime, with the case extending total playtime to over 30 hours.


The image displays the SOAR NFL True Wireless Earbuds v.7 inside their charging case, with the lid open. The front of the case features an LED digital display showing 'L' and 'R' indicators for each earbud's charge level, and a percentage for the case's battery.

2. Pairing with a Bluetooth Device

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select "SOAR TWS v.7" (or similar name).
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
6. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Earbuds



Gently insert the earbuds into your ears, ensuring a comfortable and secure fit. Choose the appropriate eartip size for optimal sound quality and comfort. The image shows a man wearing the SOAR NFL True Wireless Earbuds v.7, demonstrating a typical fit for listening to music, taking calls, or enjoying podcasts.

Touch Controls

The SOAR NFL True Wireless Earbuds v.7 feature intuitive touch controls on each earbud. Specific

functions may vary slightly by device, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud (e.g., Siri, Google Assistant).

MAINTENANCE

Proper care will extend the life of your SOAR NFL True Wireless Earbuds v.7.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Remove eartips periodically and clean them with a damp cloth. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** These earbuds are not water-resistant. Avoid exposure to water, sweat, or excessive moisture.
- **Temperature:** Do not expose the earbuds or case to extreme temperatures (hot or cold).

TROUBLESHOOTING

| Problem | Possible Solution |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Earbuds not pairing | Ensure earbuds are charged. Turn off and on your device's Bluetooth. Forget the device in Bluetooth settings and re-pair. Place earbuds back in case, close, then reopen to reset pairing mode. |
| Only one earbud working | Ensure both earbuds are charged. Place both earbuds back in the charging case, close the lid, wait a few seconds, then open the lid and try again. Check if both earbuds are selected in your device's audio output settings. |
| No sound or low volume | Check device volume. Ensure earbuds are properly connected. Clean any debris from earbud speakers. |
| Charging case not charging | Ensure the charging cable is securely connected to both the case and the power source. Try a different charging cable or power adapter. |
| Poor sound quality | Ensure earbuds are securely fitted in your ears. Try different eartip sizes. Move closer to your paired device to reduce interference. |

SPECIFICATIONS

| Feature | Detail |
|--------------------------|------------------------------------------------------------|
| Model Name | SOAR True Wireless Earbuds V.7 |
| Connectivity Technology | Bluetooth 5.0 |
| Wireless Range | Up to 30 feet (10 meters) |
| Battery Life (Earbuds) | Approximately 10 hours |
| Total Playtime with Case | Over 30 hours |
| Charging Time | Approximately 1.5 - 2 hours for earbuds and case |
| Frequency Response | 20 Hz - 20,000 Hz |
| Control Type | Touch Control |
| Microphone | Built-in for hands-free calls |
| Water Resistance Level | Not Water Resistant |
| Included Components | Stereo Earbuds (2), Wireless Charging Case, Cable, Eartips |

WARRANTY AND SUPPORT

Warranty Information

The SOAR NFL True Wireless Earbuds v.7 come with a **1 Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or general inquiries, please contact SOAR customer support. You can typically find contact information on the official SOAR website or through the retailer where you purchased the product. When contacting support, please have your product model number (NFL-TWS7) and proof of purchase ready.

For more information, visit the [SOAR Store on Amazon](#).