

DUCOCUB J59

DUCOCUB J59 Wireless Earbuds User Manual

Model: J59 | Brand: DUCOCUB

INTRODUCTION

Thank you for choosing the DUCOCUB J59 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced Bluetooth 5.4 technology, comfortable ergonomic design, and IPX7 waterproofing. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- 2 x DUCOCUB J59 Bluetooth Earbuds
- 1 x Wireless Charging Case
- 1 x USB Type-C Charging Cable
- 1 x User Manual (this document)

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Connect the USB Type-C charging cable to the charging port on the case and to a USB power adapter (not included) or a computer's USB port.
2. The LED digital display on the charging case will show the battery percentage during charging.
3. The earbuds will charge automatically when placed inside the charging case. The individual earbud battery indicators on the case display will show their charging status.
4. A full charge for the case takes approximately 1 hour. Earbuds charge within the case.

LED DIGITAL DISPLAYS

Up to 40 hours of playback time



Image: The charging case and earbuds displaying LED battery indicators. The case shows a percentage, and individual earbud icons indicate their charge level. A USB-C cable is shown connected for charging.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when taken out of the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
2. On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "J59" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

BLUETOOTH 5.3 POWERFUL CHIPS

Compatible with most devices, providing a stable and fast connection.



Image: A smartphone screen showing Bluetooth settings with "J59" listed as a paired device. The earbuds and charging case are visible, illustrating the connection process.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears.

- Identify the left (L) and right (R) earbuds.
- Gently insert each earbud into the corresponding ear canal.
- Rotate the earbud slightly until it feels secure and comfortable.

ERGONOMIC DESIGN, COMFORTABLE AND SECURE, WON'T FALL OFF

Make the wireless earbuds sit comfortably and securely in your ears.



Image: A person wearing the earbuds, demonstrating their secure and comfortable fit. An inset shows a close-up of an earbud with "Only 3.4g" indicating its lightweight design.

2. Touch Controls

The DUCOCUB J59 earbuds feature sensitive touch controls for easy management of music and calls.

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant	Press and hold either earbud for 3 seconds

3. Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case. They will automatically disconnect and power off.

MAINTENANCE

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure charging contacts on both earbuds and case are clean and dry to prevent charging issues.

2. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

3. Water Resistance (IPX7)

The DUCOCUB J59 earbuds are rated IPX7 waterproof, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and protection against sweat and rain.

- Do not intentionally submerge the charging case, as it is not waterproof.
- Ensure earbuds are completely dry before placing them back into the charging case to prevent damage.
- IPX7 rating does not mean they are suitable for swimming or showering with hot water.

IPX7 WATERPROOF

WITHSTAND




Image: The earbuds and charging case shown with water droplets, illustrating their IPX7 waterproof capability against light rain, accidental splashes, and sweat.

TROUBLESHOOTING

1. Earbuds Not Pairing with Each Other or Device

- Ensure both earbuds are fully charged.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then remove them again.
- On your device, forget or delete "J59" from the Bluetooth device list and try pairing again.
- Ensure your device's Bluetooth is enabled and within range (up to 15 meters).

2. No Sound or Low Volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean any debris from the earbud speaker mesh.
- Try playing audio from a different application or device.

3. Charging Issues

- Ensure the USB Type-C cable is securely connected to both the case and the power source.
- Try a different charging cable or power adapter.
- Make sure the charging contacts on the earbuds and inside the case are clean and free of obstructions.
- Ensure the earbuds are correctly seated in the charging case.

4. Call Quality Issues (ENC Noise Cancellation)

The earbuds feature ENC (Environmental Noise Cancellation) for clear calls.

- Ensure the microphones (4 total) are not obstructed.
- Move to a quieter environment if possible.
- Ensure the earbuds are fully charged.



Image: Diagram showing the placement of four microphones on the earbuds, illustrating how ENC (Environmental Noise Cancellation) technology reduces background noise for clearer calls.

SPECIFICATIONS


Feature	Detail
Model	J59

Feature	Detail
Brand	DUCOCUB
Bluetooth Version	5.4
Wireless Range	Up to 15 meters
Earbud Playtime (Single Charge)	Up to 8 hours (<i>over 6 hours as per feature bullet</i>)
Total Playtime with Charging Case	Up to 40 hours (<i>30 hours as per feature bullet</i>)
Charging Time (Case)	Approx. 1 hour (USB Type-C)
Water Resistance Rating	IPX7 (Earbuds only)
Microphones	4 (with ENC Noise Cancellation)
Driver Size	14.2 mm Dynamic Drivers
Earbud Weight	3.4 grams each
Compatible Devices	Mobile phones, Tablets (Android, iOS)
Battery Type	Lithium Polymer

Note: Playtime may vary based on volume level and audio content.

MULTI-CORE DYNAMIC COIL HORN WITH STEREO SURROUND SOUND

Large dynamic horn, redesigned with international tuning masters. High, middle, and low frequencies are balanced to restore the sense of sound hierarchy.



14.2mm
Drivers



Super Light
Design

Image: An exploded view of an earbud, highlighting its internal components such as the 14.2mm dynamic driver and showing its super light design.

WARRANTY AND SUPPORT

DUCOCUB products are designed for reliability and performance. For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or the official DUCOCUB website. Please retain your proof of purchase for warranty claims.