

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› **DUCOCUB** /

› **DUCOCUB J59 Wireless Earbuds User Manual**

DUCOCUB J59

DUCOCUB J59 Wireless Earbuds User Manual

Model: J59

1. INTRODUCTION

Thank you for choosing the DUCOCUB J59 Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

Package Contents

- DUCOCUB J59 Wireless Earbuds (2 units)
- Charging Case (1 unit)
- Type-C Charging Cable (1 unit)
- User Manual (1 unit)




Image: Contents of the DUCOCUB J59 Wireless Earbuds package.

2. PRODUCT OVERVIEW

The DUCOCUB J59 Wireless Earbuds feature an ergonomic design for comfortable wear, a charging case with an LED power display, and intuitive touch controls.



Image: DUCOCUB J59 Wireless Earbuds and charging case.

Key Features:

- **Bluetooth 5.4 Technology:** For stable and fast connections.
- **14.2mm Dynamic Drivers:** For immersive sound quality.

- **ENC Noise Reduction:** Enhances call clarity.
- **Up to 48 Hours Playtime:** With the charging case.
- **LED Power Display:** Real-time battery status for earbuds and case.
- **IPX7 Waterproof Rating:** Protection against sweat and rain.
- **Smart Touch Control:** Easy management of music, calls, and voice assistant.
- **Lightweight Design:** Each earbud weighs approximately 3.4 grams.

3. SETUP AND PAIRING

Initial Charging

1. Before first use, place both earbuds into the charging case.
2. Connect the Type-C charging cable to the charging port on the case and a power source.
3. The LED display on the charging case will show the battery level, indicating charging status. Fully charge the case and earbuds before initial use.

Bluetooth Pairing

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "J59" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.



Image: Bluetooth pairing process for DUCOCUB J59 Earbuds.

4. OPERATING THE EARBUDS

The DUCOCUB J59 earbuds feature intelligent touch controls on each earbud for various functions.



Image: Touch control functions for DUCOCUB J59 Earbuds.

Touch Control Functions:

- **Play/Pause:** Double-tap (L/R earbud).
- **Next Song:** Triple-tap (Right earbud).
- **Previous Song:** Triple-tap (Left earbud).
- **Answer/End Call:** Single-tap (L/R earbud).
- **Reject Call:** Press and hold for 2 seconds (L/R earbud).
- **Activate Voice Assistant:** Press and hold for 2 seconds (L/R earbud).
- **Power On:** Press and hold for 2 seconds (L/R earbud) if earbuds are off and not in case.
- **Power Off:** Press and hold for 4 seconds (L/R earbud) or place back in charging case.

5. CHARGING

The charging case provides extended battery life for your earbuds and features an LED display to monitor power levels.

LED DIGITAL DISPLAYS

Up to 40 hours of playback time



Image: LED digital display and charging information.

Earbud Charging

- Place the earbuds into the charging case. They will automatically begin charging.
- The LED display on the case will show individual earbud battery levels.
- A full charge provides approximately 6-8 hours of playback time.

Charging Case

- Connect the Type-C cable to the charging case and a power source.
- The LED display on the case indicates its current battery percentage.
- The charging case provides an additional 30-32 hours of playtime, totaling up to 40 hours with fully charged earbuds.
- Charging the case fully takes approximately 1 hour.

6. MAINTENANCE AND CARE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and free of debris for proper charging.

Water Resistance (IPX7)

The DUCOCUB J59 earbuds are rated IPX7 waterproof, meaning they can withstand immersion in water

up to 1 meter for 30 minutes. This protects them from sweat and light rain.



Image: IPX7 Waterproof feature of the earbuds.

- Do not intentionally submerge the earbuds for extended periods or use them for swimming.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid extreme temperatures, humidity, and dust.

7. TROUBLESHOOTING

If you encounter any issues with your DUCOCUB J59 Wireless Earbuds, please refer to the following common solutions:

| Problem | Solution |
|---------------------------------|---|
| Earbuds not pairing with device | Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget/delete "J59" from your device's Bluetooth list and re-pair. Place earbuds back in case, close, then reopen to reset pairing mode. |

| Problem | Solution |
|-------------------------|--|
| Only one earbud working | <p>Ensure both earbuds are charged.</p> <p>Place both earbuds back in the charging case, close the lid, wait a few seconds, then open the lid and take them out again.</p> <p>Clean the charging contacts on both earbuds and in the case.</p> |
| Earbuds not charging | <p>Ensure the charging case has power.</p> <p>Verify the Type-C cable is securely connected to both the case and the power source.</p> <p>Clean the charging contacts on the earbuds and inside the case.</p> |
| Poor sound quality | <p>Ensure earbuds are properly seated in your ears.</p> <p>Check the audio source device's volume and sound settings.</p> <p>Move closer to your device to avoid Bluetooth interference.</p> <p>Clean any debris from the earbud speakers.</p> |

8. SPECIFICATIONS

Detailed technical specifications for the DUCOCUB J59 Wireless Earbuds:

| Feature | Detail |
|---------------------------------|--|
| Model Name | J59 |
| Connectivity Technology | Wireless (Bluetooth) |
| Bluetooth Version | 5.4 |
| Bluetooth Range | Up to 15 meters (49 feet) |
| Audio Driver Size | 14.2 mm Dynamic Driver |
| Earbud Weight | Approx. 3.4 grams per earbud |
| Charging Case Battery Capacity | 400 mAh |
| Total Playtime (with case) | Up to 48 hours |
| Earbud Playtime (single charge) | 6-8 hours |
| Charging Port | Type-C |
| Water Resistance Rating | IPX7 |
| Noise Control | Passive Noise Cancellation (ENC for calls) |

9. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures, direct sunlight, and open flames.

- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified equivalent.

10. WARRANTY AND SUPPORT

DUCOCUB products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official DUCOCUB website.

Please retain your proof of purchase for any warranty claims.