

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hournor](#) /

› [Hournor Digital Wall Clock Model 6658 Instruction Manual](#)

Hournor 6658

Hournor Digital Wall Clock Model 6658 Instruction Manual

Your guide to setting up and operating your new digital wall clock.

INTRODUCTION

Thank you for choosing the Hournor Digital Wall Clock Model 6658. This clock features a large 16.2-inch LED display, multi-color ambient night light, smart dimming, and convenient remote control. It is designed for clear visibility and ease of use in various indoor environments. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Image: The Hournor Digital Wall Clock Model 6658 displaying time, day, date, and temperature, with a remote control in the foreground.

PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Hournor Digital Wall Clock Model 6658
- 1 x Remote Control
- 1 x 12-foot USB Cable
- 1 x 5V2A Power Adapter
- 1 x Instruction Manual (this document)

Convenient Remote Control

Operate all settings effortlessly from your seat - no need to touch the clock.
Includes a 12 feet USB cable and an 5V2A adapter.



Image: The digital wall clock, its remote control, a USB cable, and a power adapter, representing the package contents.

KEY FEATURES

1. **16.2 Inch Large LED Display:** Features a 16.2-inch display with 4-inch high-contrast digits for excellent visibility. Displays time, date, day of the week, and temperature.

16.2 Inch Large LED Display

Boasts a massive 16.2-inch display with 4-inch high-contrast digits.



Image: The clock displaying 10:22 PM, Wednesday, August 20, and 76°F, highlighting its 16.2-inch width and 4.0-inch digit height.

2. **9-Color Ambient Night Light:** The base of the clock features multi-color mood lighting, which can be used as a night light to enhance room ambiance.



9-Color Ambient Night Light

Features multi-color mood lighting at the base, serving as a stylish night light.




Image: The digital clock mounted on a wall, showcasing its base illuminated in different colors (blue, red, green, purple, orange, light blue) as a night light.

- Smart 10-Level Dimming:** Adjust the display brightness manually using the remote control or enable the automatic sensor to adapt to ambient light conditions, ensuring comfortable viewing without glare.




Image: A split image showing the clock in a bright room and a dim room, illustrating its automatic dimming feature. Below are four clocks showing 100%, 75%, 50%, and 25% brightness levels.

- 4. Memory Retention & Timer Functions:** A built-in memory feature preserves time settings during power outages, preventing the need for resets. Includes versatile count-up and countdown timers (up to 99 minutes/seconds).



Image: A person using the clock's timer function during exercise. An inset shows the clock's memory retention feature: displaying time, then off during power loss, then displaying time again after power is restored.

- Convenient Remote Control:** All settings can be operated effortlessly from a distance using the included remote control.

Product Overview Video

Your browser does not support the video tag.

Video: An official product video demonstrating the Hournor Digital Wall Clock's large LED display, 9-color ambient night light, 10-level brightness adjustment, and positive timing/countdown functions.

SETUP INSTRUCTIONS

- Power Connection:** Connect the provided USB cable to the clock and plug the 5V2A power adapter into a standard wall outlet. The clock requires continuous plug-in power to operate. It is not battery-operated for primary function.

2. **Battery Installation (for Memory Retention):** For memory retention during power outages, install 2 AAA batteries (not included) into the battery compartment on the back of the clock. These batteries only save settings and do not power the display.
3. **Initial Settings:** Upon first power-up, the clock may display default settings. Use the remote control to set the correct time, date, year, and temperature unit (Fahrenheit or Celsius). Refer to the 'Operating Instructions' section for detailed steps.
4. **Wall Mounting:** The clock can be mounted on a wall using the integrated hanging holes on the back. Ensure the mounting surface is secure and the clock is level.

OPERATING INSTRUCTIONS

All functions are controlled via the remote control.

1. Setting Time and Date:

- Press the 'SET' button on the remote. The year will flash. Use the arrow keys to adjust and 'SET' to confirm.
- Repeat for month, day, hour, and minute.
- Press 'SET' again to exit time setting mode.

2. Alarm Setting:

- Press the 'ALARM' button. The alarm hour will flash. Use arrow keys to adjust and 'ALARM' to confirm.
- Repeat for alarm minute.
- Press 'ALARM' again to activate/deactivate the alarm. An alarm icon will appear/disappear on the display.

3. Brightness Adjustment:

- **Manual Dimming:** Press the 'BRIGHTNESS' button (or '+' / '-' buttons) on the remote to cycle through 10 levels of brightness (L-01 to L-10).
- **Automatic Dimming:** Press the 'AUTO' button on the remote. The clock will automatically adjust brightness based on ambient light.

4. Night Light Control:

- Press the 'LIGHT' button on the remote to cycle through the 9 available colors for the ambient night light.
- Press the 'OFF' button to turn off the night light.

5. Timer Functions:

- **Countdown Timer:** Press the 'TIMER' button. Use arrow keys to set minutes and seconds (up to 99:99). Press 'START/STOP' to begin/pause. Press 'RESET' to clear.
- **Count-up Timer:** Press the 'TIMER' button twice. Press 'START/STOP' to begin/pause. Press 'RESET' to clear.

6. **DST (Daylight Saving Time) Setting:** Press the 'DST' button on the remote to enable or disable Daylight Saving Time. The display will adjust accordingly.

7. **Temperature Unit:** Press the '°C/°F' button to switch between Celsius and Fahrenheit temperature display.

MAINTENANCE

To maintain your Hournor Digital Wall Clock in optimal condition:

- Wipe the display and body with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- Ensure the clock is placed in a dry environment, away from direct sunlight or extreme temperatures.
- If the remote control is not responding, check and replace its battery (CR2025 coin cell, not included).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	Not plugged in or power adapter issue.	Ensure the USB cable is securely connected to the clock and the power adapter is plugged into a working outlet. Verify the adapter is functional.
Settings are lost after a power outage.	Memory backup batteries are not installed or are depleted.	Install 2 new AAA batteries in the battery compartment for memory retention.
Remote control is not working.	Remote battery is low or depleted, or line of sight is blocked.	Replace the remote control battery (CR2025 coin cell). Ensure there are no obstructions between the remote and the clock.
Display is too bright/dim.	Brightness setting needs adjustment.	Use the 'BRIGHTNESS' or '+' / '-' buttons on the remote to manually adjust. If in auto mode, ensure the light sensor is not obstructed.

SPECIFICATIONS

- **Brand:** Hournor
- **Model Number:** 6658
- **Display Type:** Digital LED
- **Display Size:** 16.2 inches (diagonal)
- **Digit Height:** 4 inches (time digits)
- **Product Dimensions:** 15"W x 5"H
- **Power Source:** Corded Electric (5V2A adapter included)
- **Memory Backup:** Requires 2 x AAA batteries (not included)
- **Material:** Plastic
- **Special Features:** 10-Level Dimming, 9-Color Ambient Night Light, DST, Alarm, Date, Week, Temperature Display, Timer Functions, Remote Control
- **Indoor/Outdoor Usage:** Indoor only
- **Mounting Type:** Wall Mount
- **Item Weight:** 1.59 pounds (0.72 Kilograms)

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Hournor website. Keep your purchase receipt for warranty claims.

