



Manuals.plus /

› KEMEI /

› KEMEI Professional Hair Clipper, Trimmer, and Foil Shaver Kit User Manual (Models KM-2293, KM-PG2290D, KM-T95)

KEMEI KM-2293, KM-PG2290D, KM-T95

KEMEI Professional Hair Clipper, Trimmer, and Foil Shaver Kit User Manual

Models: KM-2293, KM-PG2290D, KM-T95

1. INTRODUCTION

Thank you for choosing the KEMEI Professional Hair Clipper, Trimmer, and Foil Shaver Kit. This comprehensive grooming kit is designed to provide salon-quality results for various hair trimming needs, including full haircuts, fading, blending, beard shaping, and detailing. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your KEMEI grooming tools.

2. PRODUCT OVERVIEW

2.1 Kit Components

Your KEMEI Professional Grooming Kit includes the following items:

- Professional Barber Clipper (KM-2293) with Charging Cradle
- Precision Hair Trimmer (KM-PG2290D)
- Close-Cutting Foil Shaver (KM-T95)
- Multiple Guide Combs for Clipper (6 sizes)
- Multiple Guide Combs for Trimmer (3 sizes)
- USB-C Charging Cables
- Cleaning Brush
- Lubricating Oil
- Hair Cutting Cape
- Storage/Travel Bag



Image: The complete KEMEI Professional Hair Clipper, Trimmer, and Foil Shaver Kit, showcasing all included components and accessories.

2.2 Key Features

- **Powerful Motors:** 8000 RPM motors for efficient cutting without snagging.
- **Durable Blades:** Professional-grade stainless steel blades with black titanium coating.
- **Adjustable Cutting Lengths:** Clipper offers 5 adjustable lengths (0.01" to 0.16"). Trimmer offers ultra-close 0mm cut.
- **Long Battery Life:** Up to 180 minutes cordless runtime per charge for each device.
- **Smart LED Display:** Real-time battery percentage and alerts.
- **Metal Body Construction:** Robust all-metal design for durability and grip.
- **USB-C Charging:** Universal charging for convenience. Clipper includes a charging cradle.



Image: Detailed view of the KEMEI clipper and trimmer, highlighting the 8000 RPM motor and 440C stainless steel black titanium blades.

3. SETUP

3.1 Initial Charging

Before first use, fully charge each device. Connect the USB-C cable to the device and a suitable USB power adapter (not included). The clipper can also be charged using its dedicated charging cradle.

- **Clipper (KM-2293):** Approximately 2.5 hours for 120 minutes runtime. Can be charged via cradle or direct USB-C.
- **Trimmer (KM-PG2290D):** Approximately 3 hours for 180 minutes runtime.
- **Foil Shaver (KM-T95):** Approximately 2 hours for 180 minutes runtime.



Image: Illustration of the charging process and battery runtimes for the KEMEI clipper, trimmer, and foil shaver.

3.2 Attaching Guide Combs

To attach a guide comb, align the comb with the blade and push firmly until it clicks into place. Ensure it is securely fastened before use. To remove, gently pull the comb away from the blade.

4. OPERATING INSTRUCTIONS

4.1 Using the Hair Clipper (KM-2293)

The hair clipper is suitable for full haircuts, fading, and blending. It features an adjustable taper lever and guide combs for varying lengths.

1. Ensure the clipper is charged.
2. Select the desired guide comb and attach it securely.
3. Adjust the taper lever for fine-tuning cutting length (0.01", 0.04", 0.08", 0.12", 0.16").
4. Turn on the clipper.
5. Guide the clipper against the direction of hair growth for an even cut.



BALD FOIL SHAVER

Shaving the beard / bald head



0.03mm ultra-thin foil mesh



Detachable and rinseable
blade head
*Avoid complete immersion



360° without dead angle

Image: The KEMEI hair clipper demonstrating its adjustable taper lever and various guide comb attachments for different hair lengths.

4.2 Using the Precision Hair Trimmer (KM-PG2290D)

The trimmer is ideal for detailed beard shaping, sideburns, necklines, and art carving, achieving an ultra-close 0mm cut.

1. Ensure the trimmer is charged.
2. For precise lines, use without a guide comb. For blending, attach one of the 3 precision guards (0.04", 0.08", 0.12").
3. Turn on the trimmer.
4. Carefully guide the trimmer along the desired areas for detailing.



Image: A man using the KEMEI precision hair trimmer to define his beard line, illustrating its use for detailed grooming.

4.3 Using the Foil Shaver (KM-T95)

The foil shaver provides a close, smooth shave for bald heads or clean beard lines.

1. Ensure the shaver is charged.
2. Turn on the shaver.
3. Gently press the shaver against the skin and move in short, circular motions or against the grain for a close shave.



Image: Close-up of the KEMEI foil shaver, highlighting its 0.03mm ultra-thin foil mesh and detachable, rinseable blade head.

5. MAINTENANCE

5.1 Cleaning the Blades

Regular cleaning ensures optimal performance and hygiene.

1. Turn off and unplug the device.
2. Use the provided cleaning brush to remove loose hairs from the blades.
3. For the foil shaver, the blade head is detachable and rinseable under running water. Avoid complete immersion of the main unit.
4. Wipe blades with a dry cloth after cleaning.



Image: Step-by-step guide on how to clean the clipper blades using the included brush.

5.2 Lubricating the Blades

Apply a few drops of lubricating oil to the blades after every few uses to maintain sharpness and smooth operation.

1. Ensure the device is clean and dry.
2. Apply 1-2 drops of the provided lubricating oil evenly across the blades.
3. Turn on the device for a few seconds to distribute the oil.
4. Wipe off any excess oil with a soft cloth.



Image: Visual instruction on how to apply lubricating oil to the clipper blades for optimal performance.

5.3 Storage

Store the grooming kit in its provided travel bag in a dry environment, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your KEMEI grooming kit, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device not turning on	Low battery; Device not charged	Charge the device fully. Check charging cable and adapter.
Poor cutting performance / pulling hair	Blades are dull or dirty; Insufficient lubrication	Clean blades thoroughly. Apply lubricating oil. Ensure blades are free of debris.
Excessive noise or vibration	Blades misaligned; Debris in motor area	Clean blades and ensure they are properly seated. If problem persists, contact customer support.

If the issue persists after attempting these solutions, please contact KEMEI customer support for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	KEMEI
Models	KM-2293 (Clipper), KM-PG2290D (Trimmer), KM-T95 (Foil Shaver)
Power Source	Battery Powered (3 Lithium Ion batteries included)
Clipper Runtime	120 minutes (2.5 hr charge)
Trimmer Runtime	180 minutes (3 hr charge)
Foil Shaver Runtime	180 minutes (2 hr charge)
Motor Speed	8000 RPM
Blade Material	440C Stainless Steel with Black Titanium
Item Weight	1195 Grams (Total Kit)
Package Dimensions	9.25 x 8.66 x 3.74 inches
Recommended Uses	Beard, Face, Head, Mustache, Hair Cutting

8. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to prevent injury or damage to the device:

- Avoid using on wet hair.
- Do not allow the device to contact eyes.
- Keep away from water sources and do not immerse the main units in water.
- Always unplug the device when not in use or before cleaning.
- Follow recommended cleaning and maintenance procedures as outlined in this manual.
- Keep out of reach of children.
- Do not disassemble the product beyond routine cleaning.

9. WARRANTY AND SUPPORT

KEMEI products are manufactured in quality-certified factories. While specific warranty details are not provided in this manual, KEMEI is committed to product performance and quality. For any product-related inquiries, technical support, or warranty claims, please contact KEMEI customer service through the retailer where the product was purchased or visit the official KEMEI website for contact information.

10. OFFICIAL PRODUCT VIDEOS

No official product videos from the seller were provided in the product data for embedding in this manual.