



Manuals.plus /

› homary /

› Homary Extendable Walnut TV Stand (Model JJ991H4B71) User Manual

homary JJ991H4B71

Homary Extendable Walnut TV Stand (Model JJ991H4B71)

USER MANUAL

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

Caution: To prevent tipping, this product must be securely attached to the wall using the anti-tip hardware provided. Be careful around sharp edges during assembly and handling.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble on a soft, clean surface to prevent scratching.
- Do not overtighten screws.
- Keep small parts away from children.
- Always use the anti-tip hardware to secure the TV stand to a wall.

2. Product Overview

The Homary Extendable Walnut TV Stand is a modern media console designed for living room entertainment. It features an adjustable length from 71 inches to 100 inches, accommodating TVs up to 80 inches. The unit includes three spacious drawers with soft-close slides for organized storage and offers a flexible, reversible layout.



Image 2.1: The Homary Extendable Walnut TV Stand, showcasing its modern design and functionality in a living room environment.



Image 2.2: Key features of the TV stand, including its extendable design and three spacious drawers for storage.

3. Assembly and Setup

Assembly of the Homary Extendable Walnut TV Stand requires careful attention to detail. It is

recommended to have two people for assembly.

3.1 Unpacking and Part Identification

1. Carefully unpack all components from the packaging.
2. Verify that all parts listed in the hardware and parts list (not provided in this manual, refer to your product packaging) are present.
3. Separate and identify all hardware components.

3.2 General Assembly Steps (Illustrative)

1. Begin by assembling the main base sections according to the provided diagrams in your product packaging.
2. Attach the side panels and internal supports.
3. Install the drawer slides into the designated compartments. Ensure they are correctly oriented for smooth operation.
4. Assemble the drawer boxes and attach the drawer fronts.
5. Insert the assembled drawers into the slides.
6. Connect the extendable sections. The design allows for a left-right layout installation, meaning the open shelf section can be positioned on either the left or right side of the drawer unit.
7. Once the main structure is complete, carefully position the TV stand in its desired location.



Image 3.1: Demonstrates the flexible left-right layout options for the extendable TV stand.

3.3 Anti-Tip Hardware Installation

It is critical to install the anti-tip hardware to prevent accidental tipping, especially in households with children or pets.

1. Locate the anti-tip hardware kit provided with your TV stand.
2. Position the TV stand against the wall in its final location.
3. Following the instructions in the anti-tip kit, attach one bracket to the back of the TV stand and the other to the wall, ensuring they align.
4. Securely fasten the strap or cable between the two brackets.
5. Test the connection to ensure the stand is firmly anchored.

4. Operating Instructions

4.1 Adjusting the Length

The TV stand features an extendable design, allowing its length to be adjusted from 71 inches to 100 inches.

- To extend: Gently pull the movable section outwards until the desired length is achieved. Ensure the

stand remains stable and balanced.

- To retract: Gently push the movable section inwards.
- Avoid sudden or forceful movements when adjusting the length.

4.2 Using the Drawers

The three drawers are equipped with soft-close slides for quiet and smooth operation.



Image 4.1: Detail of the soft-close drawer mechanism, ensuring quiet operation.

- To open: Gently pull the drawer handle.
- To close: Gently push the drawer until the soft-close mechanism engages, allowing it to close silently.
- Do not overload drawers. Refer to specifications for weight limits.



Large Storage Space

With three pull-out drawers, you can store your often-used items, keeping them handy and organized.

Image 4.2: The three pull-out drawers provide ample storage for media accessories and other items.

5. Maintenance and Care

Proper care will ensure the longevity and appearance of your Homary TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the walnut veneer.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Heat and Moisture:** Keep the TV stand away from direct heat sources and areas of high humidity. Use coasters under hot or wet items.
- **Inspection:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.

6. Troubleshooting

- **Drawers do not slide smoothly:**
 - Check if the drawer slides are properly aligned and free of obstructions.

- Ensure all screws securing the slides are tight.
- Verify that the drawer is not overloaded.
- **Stand feels unstable:**
 - Confirm all assembly screws are tightened.
 - Ensure the stand is on a level surface.
 - Verify the anti-tip hardware is correctly installed and securely anchored to the wall.
- **Extendable section is stiff or difficult to move:**
 - Check for any debris or obstructions in the sliding mechanism.
 - Ensure the stand is not overloaded or unevenly weighted.

7. Specifications




Image 7.1: Dimensional drawing of the TV stand, illustrating its adjustable length and drawer sizes.

Product Specifications

Brand	Homary
Model Number	JJ991H4B71
Material	Engineered Wood (MDF with Walnut Veneer)
Color	Walnut
Adjustable Length	71" - 100" (1790mm - 2550mm)
Overall Depth	15.7" (399mm)
Overall Height	14.2" (360mm)
Item Weight	156 pounds (70.76 kg)
Drawer Inner Dimensions (W x D x H)	19.3" x 10.8" x 4.9" (490mm x 275mm x 124mm)
Maximum TV Size	Up to 80 inches
Features	Extendable design, 3 soft-close drawers, reversible layout, anti-tip hardware included.



Image 7.2: Information on the E1 Grade MDF Board material used in the TV stand construction.

8. Warranty and Support

For specific warranty information, please refer to the documentation included with your purchase or visit the official Homary website. If you encounter any issues or require assistance with assembly, parts, or product functionality, please contact Homary customer support.

Homary Customer Support: Refer to your purchase receipt or the Homary website for contact details.