

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [MXV](#) /

› MXV 70-inch Fireplace TV Stand User Manual

MXV IF-36FSB

MXV 70-inch Fireplace TV Stand User Manual

Model: IF-36FSB | Brand: MXV

INTRODUCTION

Thank you for purchasing the MXV 70-inch Fireplace TV Stand. This modern entertainment center features an integrated 36-inch electric fireplace with LED lighting, designed to enhance your living space. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product. Please read all instructions carefully before assembly and use.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned or been dropped or damaged in any manner.
- Do not use outdoors.
- Always unplug the fireplace when not in use.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect the fireplace, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This appliance has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this fireplace only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always ensure the fireplace is placed on a stable, level surface.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m)

from the front of the heater and away from the sides and rear.

PACKAGE CONTENTS

Your MXV Fireplace TV Stand package includes all necessary components for assembly, including the TV stand panels, hardware, the 36-inch electric fireplace insert, and a remote control. Please refer to the separate assembly instruction booklet included in your packaging for a detailed list of parts and hardware. Inspect all components for damage before assembly. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

ASSEMBLY INSTRUCTIONS

The MXV Fireplace TV Stand is designed for straightforward assembly with pre-drilled holes and numbered parts. A detailed, step-by-step assembly instruction booklet is included with your product. Please follow these instructions carefully.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each part to the corresponding number in the instruction booklet.
3. **Assemble Frame:** Begin by assembling the main frame of the TV stand using the provided hardware.
4. **Install Shelves and Doors:** Attach adjustable shelves and cabinet doors as indicated in the manual.
5. **Insert Fireplace:** Carefully slide the electric fireplace insert into the designated opening. Ensure it is securely seated.
6. **Connect LED Lighting:** Follow the instructions for connecting the integrated LED light strips.
7. **Cable Management:** Utilize the integrated cable management features to organize wires from your media devices.

Note: While assembly can be done by one person, having two people may make the process easier and safer, especially when handling larger panels or the fireplace insert.



Image: The MXV 70-inch Fireplace TV Stand can accommodate TVs up to 80 inches, as illustrated by the varying TV sizes shown on the stand.

OPERATING INSTRUCTIONS

Electric Fireplace Operation

The electric fireplace can be operated using the control panel on the unit or the included remote control.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** The fireplace offers two heat settings: 750W and 1500W. Select the desired wattage for heating. The temperature range is adjustable from 62°F to 82°F.
- **Flame Brightness:** Adjust the flame brightness through 5 levels (L1-L5) to suit your preference.
- **Timer Function:** Set a timer for automatic shut-off.
- **Overheating Protection:** The unit is equipped with an automatic shut-off feature to prevent overheating. If the unit overheats, it will power off. Unplug the unit, wait 10-15 minutes, and then plug it back in.



Image: The electric fireplace offers 5 levels of flame brightness and a temperature control range from 62°F to 82°F.


LED Lighting Operation

The integrated LED lighting system offers customizable ambient lighting.

- **Color Selection:** Choose from 12 distinct LED colors to match your room's atmosphere.
- **Color Combinations:** Explore 36 different LED color combinations for dynamic lighting effects.
- **Brightness Control:** Adjust the brightness of the LED lights.



5-Level Flame Brightness



12 Flame Color





Image: The TV stand features 12 LED color options that can be changed to suit your preference.

Remote Control Functions

The included remote control allows convenient adjustment of all fireplace and LED lighting settings from a distance. Ensure the remote has working batteries and is pointed towards the fireplace unit for optimal response.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV stand and electric fireplace.

- **Cleaning:** Dust the TV stand surfaces with a soft, dry cloth. For the fireplace glass, use a soft, damp cloth and dry thoroughly. Do not use abrasive cleaners or sprays directly on the unit.
- **Ventilation:** Ensure that the air intake and exhaust vents of the electric fireplace are kept clear of dust and obstructions.
- **Cord Inspection:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.
- **Hardware Check:** Occasionally check all assembly hardware to ensure screws and fasteners remain tight.

TROUBLESHOOTING

If you encounter issues with your MXV Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not plugged in, circuit breaker tripped, overheating protection activated.	Ensure unit is plugged into a working outlet. Check circuit breaker. If overheating protection activated, unplug for 10-15 minutes then replug.

Problem	Possible Cause	Solution
No heat output.	Heat function not activated, low heat setting, fan obstruction.	Activate heat function via control panel or remote. Increase heat setting. Ensure vents are clear.
Flame effect not working.	Flame effect not activated, LED bulb issue.	Activate flame effect. If issue persists, contact customer support.
Remote control not working.	Dead batteries, obstruction, out of range.	Replace batteries. Ensure no obstructions between remote and unit. Operate within recommended range.
LED strip lights not working or incorrect colors.	Loose connection, LED strip damage.	Check all LED strip connections. If issue persists, contact customer support.

If you experience a problem not listed here, or if the suggested solutions do not resolve the issue, please contact MXV Customer Support.

PRODUCT SPECIFICATIONS

Brand	MXV
Model Name	MXV 70" Fireplace TV Stand
Model Number	IF-36FSB
Product Dimensions	13.8"D x 70"W x 23.6"H
Item Weight	94 pounds
Material	Wood
Finish Type	Painted
Installation Type	Freestanding
Power Source	Corded Electric
Heat Output	750W / 1500W
Temperature Range	62°F–82°F
Special Features	Adjustable Flame, 12-Color LED Lights, Remote Control, Overheating Protection, Cable Management
Max TV Size Accommodated	Up to 80 inches

WARRANTY INFORMATION

The MXV 70-inch Fireplace TV Stand comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. This warranty typically covers manufacturing defects and material flaws under normal use. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact MXV Customer Support. Refer to your product packaging or the included documentation for the most current contact information, including phone numbers, email addresses, or website support portals.

When contacting support, please have your model number (IF-36FSB) and proof of purchase readily available.